

[Manuals.plus](#) /

> [MiLESEEY](#) /

> MiLESEEY PF1 1000 Yards Golf Rangefinder User Manual

## MiLESEEY PF1-B-LCD

# MiLESEEY PF1 Golf Rangefinder User Manual

MODEL: PF1-B-LCD

Brand: MiLESEEY

## 1. Introduction

The MiLESEEY PF1 Golf Rangefinder is an advanced device designed to enhance your golf game by providing accurate distance measurements. Featuring next-gen flag-locking algorithms, it offers record-breaking instant flag-locking speed and precision, even with a shaky hand or a swinging flag in the wind. It boasts a range of up to 1000 yards (300+ yards to a flag) and includes essential features like slope compensation, continuous scan mode, and pulse vibration feedback.



This manual provides detailed instructions on how to set up, operate, and maintain your MiLESEEY PF1 Golf Rangefinder to ensure optimal performance and longevity.

## 2. Package Contents

Upon unboxing, please verify that all the following items are included in your package:

- MiLESEEY PF1 Golf Rangefinder
- Protective Carrying Case
- USB-C Charging Cable
- Cleaning Cloth
- User Guide (this manual)



If any items are missing or damaged, please contact MiLESEEY customer support immediately.

## 3. Setup

### 3.1. Charging the Device

The MiLESEEY PF1 is equipped with a built-in 800mAh rechargeable lithium battery. Before first use, fully charge the device. Connect the provided USB-C charging cable to the charging port on the rangefinder and plug the other end into a compatible USB power source (e.g., computer, wall adapter). A full charge provides approximately 5 hours of continuous use or up to 15,000 accurate measurements.

# BUILT IN 800mAh RECHARGEABLE BATTERY

One Charge Delivers 5 Hours of Play or 15,000 Accurate Shots Measurements



Auto-shutdown

**16** s

Rechargeable Battery

**800** mAh

Fully Charged Use

**15000** Times measurement

### 3.2. Power On/Off

To power on the rangefinder, press the Power button located on the top of the device. To power off, press and hold the Power button for a few seconds until the display turns off.

### 3.3. Diopter Adjustment

For clear viewing, adjust the diopter by rotating the eyepiece until the display and target appear sharp and in focus. This is especially useful for users with varying eyesight.

### 3.4. Unit Switching (Yards/Meters)

To switch between yards (Y) and meters (M), briefly press the Mode button. The selected unit will be displayed in the viewfinder.

## 4. Operating Modes

### 4.1. Standard Measurement

Point the rangefinder at your desired target and press the Power button. The distance to the target will be displayed almost instantly (0.1s response time).

# 0.1S LIGHTNING-FAST

Instant Distance Feedback with a Quick Button Press,  
Keeping You More Focused on Your Game!



## 4.2. Flag Lock with Pulse Vibration

This feature allows you to lock onto the flagstick quickly and accurately, even with background objects. Aim at the flag, press and hold the Power button, and slowly scan across the flag. The device will vibrate once it locks onto the flag, providing the precise distance. This function is effective for flags up to 300+ yards.

01

### Experience Ultimate Convenience


Fits Comfortably in Your Pocket,  
Perfect Companion for Every Round



02

### Precise Flagpole Identification

Enjoy Consistent Measurements  
for Every Shot



03

### Crystal-clear View

Delivering Sharp bright visuals for  
pinpoint accuracy on every swing



#### 4.3. Slope Compensation

The PF1 includes a slope compensation feature that calculates the adjusted distance based on the incline or decline to the target. This provides a "true distance" for more accurate club selection. Use the physical slope switch on the side of the device to toggle this feature On or Off.

# LIGHTED INDICATOR SLOPE SWITCH

Instant Feedback on Slope via Flashing Indicator  
Light and USGA Compliant




OFF



ON



## EASY TO TARGET



Flagpole lock in 250+ Yards



Flag lock in 400+ Yards

#### 4.4. Tournament Legal Mode

When the slope function is turned OFF using the physical switch, the indicator light will simultaneously turn off. This signals compliance with USGA rules, making the rangefinder legal for tournament play.

## SCAN MODE TO STAY AHEAD OF THE GAME

Quickly scan the crucial areas of the hole to construct successful strategic planning & stay ahead of the game.



### 4.5. Continuous Scan Mode

For quickly measuring distances to multiple targets or scanning the landscape, press and hold the Power button while sweeping the rangefinder across the area. The display will continuously update with distances to various objects, allowing for strategic planning on the course.



## 5. Maintenance

### 5.1. Cleaning

To clean the lenses, use the provided cleaning cloth or a soft, lint-free cloth. Gently wipe the lens surfaces to remove dust or smudges. For the exterior, use a soft, damp cloth. Avoid using abrasive materials, solvents, or harsh chemicals, as these can damage the device.

### 5.2. Water Resistance

The MiLESEEEY PF1 is IP65 waterproof, meaning it is protected against dust ingress and low-pressure water jets from any direction. While it can withstand rain and splashes, it is not designed for submersion in water.

# PF1 WATERPROOF GOLF RANGEFINDER

Designed for those who challenge the limit of the green



## 5.3. Storage

When not in use, store the rangefinder in its protective carrying case in a cool, dry place, away from direct sunlight and extreme temperatures. This will help preserve the device's components and battery life.

## 6. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device using the provided USB-C cable.
Display is blurry.	Diopter not adjusted.	Rotate the eyepiece to adjust the diopter until the display is clear.
Inaccurate distance readings.	Obstruction in line of sight; unstable hand; incorrect mode.	Ensure clear line of sight to target. Hold device steady. Verify correct operating mode (e.g., Flag Lock).
Flag Lock not working.	Target out of range; unstable aim.	Ensure flag is within 300+ yards. Try scanning slowly across the flag.

## 7. Specifications

Feature	Detail
Brand	MILESEEY
Model Name	PF1-B-LCD
Color	Black
Material	Acrylonitrile Butadiene Styrene
Measuring Range	Up to 1000 yards
Magnification Maximum	6x
Flag Lock Speed	0.1s
Battery Type	Rechargeable Lithium-Ion Polymer, 5V (800mAh)
Battery Life	Approx. 5 hours / 15,000 measurements

Feature	Detail
International Protection Rating	IP65 (Waterproof)
Product Dimensions	25"L x 13"W x 38"H
Included Components	User Guide

## 8. Warranty and Support

### 8.1. Warranty Information

The MiLESEEY PF1 Golf Rangefinder comes with a 2-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product meets its specified performance standards under normal use. Please retain your proof of purchase for warranty claims.

### 8.2. Customer Support

For any questions, technical assistance, or warranty inquiries, please contact MiLESEEY customer support. Refer to the contact information provided on the product packaging or the official MiLESEEY website.