PROHEL 659245

PROHEL Commode Chair

Model: 659245 User Manual

1. Important Safety Information

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Capacity:** Do not exceed the maximum weight capacity of**330 lbs (150 kg)**.
- Ensure all parts are securely assembled and locked into place before each use.
- Always use on a flat, stable, and non-slip surface.
- Do not stand on the commode chair.
- Keep children away from the commode chair during assembly and use.
- Regularly inspect the commode chair for any signs of wear, damage, or loose components. Discontinue use if any issues are found.
- Use caution when transferring to and from the commode chair. If necessary, seek assistance.

2. Package Contents

Verify that all components are present and undamaged before proceeding with assembly:

- Commode Frame (pre-assembled, foldable)
- Commode Bucket with Lid
- Seat Plate
- Backrest (removable)
- Non-slip Leg Pads (pre-installed)

3. Setup and Assembly

The PROHEL Commode Chair is designed for easy setup and portability.

1. **Unfolding the Frame:** Gently pull the sides of the folded commode frame outwards until it fully extends and locks into an open position. Ensure the buckle design engages securely.

2. **Attaching the Backrest:** If detached, slide the backrest into the designated slots on the rear of the frame until it clicks into place.
3. **Inserting the Bucket:** Place the commode bucket into the support ring beneath the seat plate. Ensure it is seated firmly.
4. **Adjusting Height:** Press the push-buttons on each leg and slide the inner leg tubes up or down to the desired height. Ensure all four legs are adjusted to the same height and the push-buttons snap securely into the adjustment holes. The chair offers five height adjustment levels.



Image 3.1: The commode chair in its folded, portable state, demonstrating its compact design for storage and transport.



Image 3.2: Detail of the stainless steel frame construction and the buckle mechanism that secures the chair in its folded or unfolded position.

4. Operating Instructions

The PROHEL Commode Chair can be used as a standalone bedside commode or positioned over a standard toilet.

- **As a Bedside Commode:** Place the chair on a level surface near the user. Ensure the commode bucket is correctly inserted. The armrests provide support for sitting and standing.
- **Over a Toilet:** Adjust the height of the commode chair so it fits securely over your existing toilet. Remove the commode bucket before positioning over the toilet. Ensure the chair is stable and centered over the toilet bowl.
- **Height Adjustment:** To adjust the height, press the spring-loaded buttons on each leg and slide the leg up or down. Ensure the buttons fully engage in the desired height holes on all four legs for stability.



Image 4.1: Illustration of the height adjustment feature, showing the push-button mechanism on the legs and the removable commode bucket.



Image 4.2: Close-up view of the thickened ABS anti-skid seat plate and the ABS skid armrests with thread design for enhanced grip and comfort.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and hygiene of your commode chair.

- **Daily Cleaning:** After each use, remove the commode bucket, empty its contents, and clean it thoroughly with a mild disinfectant cleaner and water. Rinse and dry completely.
- **Frame and Seat:** Wipe down the stainless steel frame, seat plate, and armrests with a damp cloth and a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the materials.
- **Inspection:** Periodically check all bolts, screws, and connections to ensure they are tight. Inspect the non-slip leg pads for wear and tear. Replace any worn or damaged parts immediately.
- **Storage:** When not in use, the commode chair can be folded for compact storage. Store in a dry place away from direct sunlight.

6. Troubleshooting

- **Chair feels unstable:** Ensure all four legs are adjusted to the same height and the push-buttons are fully engaged in the adjustment holes. Verify that the chair is on a flat, level surface.
- **Difficulty folding/unfolding:** Check for any obstructions or debris in the folding mechanism. Ensure the buckle design is properly aligned. Do not force the mechanism.

- **Bucket does not fit securely:** Ensure the bucket is correctly oriented and fully seated within the support ring.

7. Specifications

- **Model:** 659245
- **Material:** Stainless Steel Frame, ABS Seat Plate, Plastic Bucket
- **Weight Capacity:** 330 lbs (150 kg)
- **Product Net Weight:** 5.5 kg (12.1 lbs)
- **Hole Size (Seat Opening):** 26 cm x 23 cm (10.2 in x 9.1 in)
- **Adjustable Height:** 5 levels (minimum height approximately 62 cm / 24.4 inches)
- **Overall Dimensions (approximate, at lowest height):**
  - Width: 55 cm (21.7 in)
  - Depth: 40 cm (15.7 in)
  - Height: 62 cm (24.4 in)



Image 7.1: Diagram showing key dimensions of the commode chair, including height, width, and depth.



Image 7.2: Detail of the non-slip rubber leg pad, designed to enhance stability and prevent movement during use.

8. Warranty and Support

PROHEL is committed to providing high-quality products and professional customer service.

If you have any questions, concerns, or require assistance with your PROHEL Commode Chair Model 659245, please contact our customer support team. We aim to respond to all inquiries within 24 hours.

For support, please refer to the contact information provided at your point of purchase or visit the official PROHEL website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question