

- Manuals.plus /
- > OKD /
 - > OKD 70-inch Fluted TV Stand with Faux Marble Top, Curved Design, and Storage User Manual

OKD 70TC

OKD 70-inch Fluted TV Stand with Faux Marble Top, Curved Design, and Storage User Manual

Model: 70TC | Brand: OKD

1. INTRODUCTION

Thank you for choosing the OKD 70-inch Fluted TV Stand. This manual provides detailed instructions for the safe assembly, proper operation, and effective maintenance of your new entertainment center. Please read this manual thoroughly before beginning assembly or use to ensure optimal performance and longevity of the product.



Image 1.1: The OKD 70-inch Fluted TV Stand in a living room environment.

2. SAFETY INFORMATION

Please observe the following safety precautions during assembly and use:

- **Two-Person Assembly:** It is highly recommended that two adults assemble this TV stand. The product is heavy (approximately 50.8 kg / 112 lbs) and requires careful handling to prevent injury or damage.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 150 lbs (approximately 68 kg) for the top surface and 60 lbs (approximately 27 kg) for the internal shelves. Overloading can cause structural failure.
- **Anti-Tip Device:** If an anti-tip device is included, install it according to the instructions to prevent the unit from tipping over, especially in households with children or pets.
- **Stable Placement:** Place the TV stand on a level, stable surface to prevent wobbling or instability.
- **Component Handling:** Exercise caution when handling plastic components, as excessive force can cause them to break.

3. PACKAGE CONTENTS

Before beginning assembly, unpack all components and verify that all parts and hardware are present and undamaged. Refer to the included parts list for identification. If any parts are missing or damaged, please contact customer support immediately.

The product is shipped in robust packaging with thick foam and protective wood panels to minimize damage during transit.

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for assembly. An Allen wrench is typically provided, but using a drill with an appropriate bit can significantly expedite the process.

1. **Preparation:** Clear a spacious area for assembly. Lay out all parts and hardware, organizing them by their labels. This will make the process smoother.
2. **Base and Frame Assembly:** Begin by assembling the main frame and attaching the support legs. Ensure all connections are secure but do not overtighten screws initially.
3. **Panel Installation:** Attach the side and back panels. Note the pre-drilled cable management holes on the back panel.
4. **Shelf Installation:** Insert the adjustable shelves into the designated slots. These can be repositioned to accommodate various media devices or decorative items.
5. **Door Assembly:** Attach the four cabinet doors using the adjustable soft-close hinges. Pay close attention to the placement of screws on the hinges to ensure proper door alignment and smooth closing. Adjust hinges as needed for optimal door function.
6. **Top Surface Placement:** Carefully place the faux marble tabletop onto the assembled frame. Ensure it is properly aligned and secured.
7. **Final Adjustments:** Verify all connections are tight. Adjust the feet if necessary to ensure the stand is level.



Adjustable Laminates



Adjustable Hinges



Cable management

Image 4.1: Key features for assembly and functionality, including adjustable shelves, hinges, and cable management.

5. OPERATING INSTRUCTIONS

Your OKD TV stand is designed for functional and organized media storage.

- **Adjustable Shelves:** The internal shelves can be adjusted to different heights to accommodate various media players, gaming consoles, or other accessories. Simply remove and re-insert the shelf supports into the desired holes.
- **Cable Management:** Utilize the three pre-drilled holes on the back panel to route and organize cables from your electronic devices. This helps maintain a tidy appearance and prevents cable clutter.
- **Soft-Close Doors:** The cabinet doors are equipped with soft-close hinges, ensuring quiet and gentle closing. Avoid forcing the doors shut.

6. MAINTENANCE AND CARE

To maintain the appearance and longevity of your TV stand, follow these care guidelines:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish.
- **Faux Marble Top:** The melamine veneer faux marble top is designed for durability and water resistance. Clean spills promptly with a dry cloth.
- **Protection:** Use coasters or protective pads under hot items or items that may scratch the surface.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or discoloration over time.




Image 6.1: Detail of the faux marble tabletop, emphasizing its delicate texture and easy maintenance.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions:

- **Doors Not Closing Properly:** Check the hinge alignment. Adjustable hinges allow for fine-tuning. Loosen the

screws slightly, adjust the door position, and then retighten.

- **Wobbling Stand:** Ensure the TV stand is placed on a level surface. Adjust the feet at the bottom of the legs to stabilize the unit.
- **Missing Parts:** If any parts were missing upon unboxing, contact customer support with your purchase details for assistance.
- **Assembly Difficulty:** Review the assembly instructions carefully. Ensure all steps are followed in sequence. If difficulties persist, consider seeking assistance from a second person.

8. SPECIFICATIONS

Feature	Detail
Brand	OKD
Model Number	70TC
Dimensions (L x W x H)	177.8 x 38.61 x 60.96 cm (70 x 15.2 x 24 inches)
Weight	50.8 Kilograms (112 lbs)
Material	Engineered Wood
Color	Navy Blue
Top Surface Capacity	Up to 150 lbs (68 kg)
Assembly Required	Yes
Care Instructions	Wipe with a dry cloth

Product Dimension



Image 8.1: Product dimensions and weight capacities.

9. WARRANTY AND SUPPORT

While specific warranty details are not provided in this manual, OKD is committed to customer satisfaction. If you encounter any problems during assembly, operation, or if you have questions regarding your product, please contact our dedicated support team. They are available to provide professional assistance and ensure your satisfaction.

Please retain your purchase receipt for any support inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D1QGQR92>

More documents and user manuals: **<https://manuals.plus/>**