

[Manuals.plus](#) /

› [Lovskoo](#) /

› Lovskoo Portable Blender (ASIN: B0D1QMRGYB) Instruction Manual

Lovskoo B0D1QMRGYB

Lovskoo Portable Blender Instruction Manual

Model: ASIN B0D1QMRGYB

1. INTRODUCTION

Thank you for choosing the Lovskoo Portable Blender. This compact and powerful personal blender is designed for convenience, allowing you to prepare fresh smoothies, shakes, and juices on the go. Its USB rechargeable design and durable construction make it ideal for home, work, travel, and outdoor activities. Please read this manual carefully before use to ensure safe and optimal performance.



Image 1.1: The Lovskoo Portable Blender, illustrating its compact dimensions of 7.87 inches in height and 3.54 inches in width.

2. SAFETY INFORMATION

To prevent injury or damage to the appliance, always follow these basic safety precautions:

- Ensure the blender cup and base are securely tightened before operation. The magnetic induction automatic stop design prevents operation if not properly assembled.
- Do not immerse the motor base in water or any other liquid. Clean the base with a damp cloth only.
- Keep hands and utensils out of the blender cup while operating to prevent injury.
- Do not overfill the blender. The maximum capacity is 350ml.
- Keep out of reach of children.
- Use only the provided USB cable for charging.
- Avoid blending hot liquids, as pressure buildup can cause the container to burst.
- Do not operate the blender when empty.

3. PACKAGE CONTENTS

Verify that all items are included in your package:

- 1 x Lovskoo Portable Blender (main unit with juicer cup and motor base)
- 1 x USB Charging Cable
- 1 x Sports Cup Lid
- 1 x Cleaning Brush

4. SETUP

1. **Initial Charge:** Before first use, fully charge the blender using the provided USB cable. Connect the USB cable to the charging port on the blender base and to a compatible USB power source (e.g., power bank, computer, wall adapter). The charging time is approximately 3-4 hours. The power button's indicator light will show charging status.
2. **Assembly:** Ensure the 6-blade assembly is securely attached to the motor base. Place your ingredients into the juicer cup, ensuring they do not exceed the maximum fill line.
3. **Secure the Cup:** Screw the juicer cup onto the motor base firmly. The blender will not operate if the cup is not properly tightened due to its safety mechanism.

5. OPERATING INSTRUCTIONS

Follow these steps to operate your Lovskoo Portable Blender:

1. **Prepare Ingredients:** Cut fruits and vegetables into small pieces (approximately 1 inch or 2.5 cm) to ensure smooth blending. Add liquid (water, milk, juice) up to the maximum fill line.
2. **Start Blending:** Double-click the power button on the motor base to start the blending cycle. The indicator light will illuminate.
3. **Optimize Blending:** For best results, gently shake the bottle at a 45-degree angle during operation to ensure all ingredients are thoroughly mixed. A typical blending cycle takes about 45 seconds.
4. **Stop Blending:** The blender will automatically stop after a cycle. You can also press the power button once to stop it manually.
5. **Enjoy Your Drink:** Unscrew the juicer cup from the base. You can drink directly from the cup or replace the blade base with the included sports cup lid for easy portability.



Image 5.1: A user drinking from the portable blender, demonstrating the convenience of the sports cup lid.



Image 5.2: The portable blender with a strap, illustrating its ease of transport for various activities.

Your browser does not support the video tag.

Video 5.3: An official video demonstrating the use of the Lovskoo Portable Blender for making shakes and smoothies.

6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your blender:

- **Self-Cleaning Mode:** After use, add a small amount of water and a drop of dish soap to the blender cup. Long-press the power button to activate the self-cleaning mode. Rinse thoroughly afterward.
- **Manual Cleaning:** The juicer cup can be opened from both the top and bottom for thorough cleaning. Use the provided cleaning brush to reach corners and around the blades.
- **Do Not Soak:** For safety and to prevent damage, do not soak the motor base in water. Wipe it clean with a damp cloth.
- **Storage:** Store the blender in a clean, dry place when not in use.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on, red light flashes.	The juicer cup and motor base are not tightened securely.	Ensure the cup is firmly screwed onto the motor base until the red light stops flashing and the indicator shows it is ready.
Blender stops during operation.	Overload or low battery.	Reduce the amount of ingredients or add more liquid. Recharge the blender if the battery is low.
Ingredients are not blending smoothly.	Ingredients are too large or too little liquid.	Cut ingredients into smaller pieces. Add more liquid. Gently shake the blender during operation.

8. SPECIFICATIONS

Feature	Detail
Brand	Lovskoo
Model Number	ASIN B0D1QMRGYB
Capacity	350ml (12 ounces)
Rated Power	40W
Working Voltage	DC 5V
Battery Capacity	2000 mAh
Charging Time	3-4 hours
Rotational Speed	21,000 r/min
Number of Blades	6 (3D Stainless Steel)
Material	PP+PC (Food-grade, Non-toxic), Stainless Steel Blades
Product Dimensions	3.54"D x 3.54"W x 7.87"H (9cm x 9cm x 20cm)
Item Weight	0.66 lb (300g)
Control Type	One Button Control

9. WARRANTY AND SUPPORT

Lovskoo is committed to providing quality products and customer satisfaction. This product comes with a standard return policy of 30 days for refund or replacement. For any questions, concerns, or technical assistance, please contact our customer service team. We offer 24/7 customer support to ensure your experience with our product is excellent.

For support, please refer to the contact information provided with your purchase or visit the Lovskoo store on Amazon: [Lovskoo Amazon Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question