

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [ODK](#) /
- › [ODK L-shaped Gaming Desk Instruction Manual - Model B0D1R2DGSJ](#)

ODK B0D1R2DGSJ

ODK L-shaped Gaming Desk Instruction Manual

Model: B0D1R2DGSJ

INTRODUCTION

Thank you for purchasing the ODK L-shaped Gaming Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new desk. Please read this manual thoroughly before assembly and retain it for future reference.

SAFETY INFORMATION

- This desk requires assembly.
- During assembly, use the leg adjusters to ensure the desk is level on uneven surfaces.
- To enhance stability, consider placing weights under the desk or positioning it against a wall or other furniture to secure it.
- Do not place excessively heavy objects on the desk to prevent damage or instability.
- Keep all small parts and packaging materials away from children to prevent choking hazards.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten if necessary.

PRODUCT FEATURES

- **Integrated Storage:** Features three drawers and open shelves for ample storage of books, documents, and other items. The L-shaped design maximizes corner space, suitable for both home and office environments.
- **Built-in Power Outlet:** Equipped with two AC outlets and USB ports for convenient charging of computers, smartphones, and other devices. The drawer and rack sections are reversible, allowing for left or right-hand configuration.
- **Durable Construction:** The desktop has a load capacity of 50kg. Constructed from high-strength melamine board, resistant to dirt, scratches, heat, and water. Features reinforced pipes, cross-bracing, adjustable feet, and a robust steel frame for stability and durability.
- **Monitor Stand:** Includes a monitor stand to elevate your screen, promoting better posture and reducing strain on the neck and shoulders during extended use, ideal for gaming and telework.

- **Versatile Assembly:** Offers four different assembly configurations to suit various room layouts and user preferences.

ASSEMBLY INSTRUCTIONS

This desk is designed for customer assembly. A wrench is included in the package. Follow the steps below for proper assembly.

Step 1: Unpack and Identify Components

Carefully unpack all components from the box. Verify that all parts listed in the parts list (not provided in this data, but assumed to be in the physical manual) are present and undamaged. Separate similar parts to avoid confusion.



Image: Overview of the assembled ODK L-shaped Gaming Desk in a gaming setup, showcasing its spacious design and monitor stand.

Step 2: Assemble the Main Desk Frame

Connect the main desk panels and support frames using the provided screws and the included wrench. Ensure all connections are firm but do not overtighten initially.



4種類の組立方法は自由に選択可能

01



02



03



04



Image: Demonstrates four possible assembly configurations for the L-shaped desk, highlighting its versatility.

The desk offers four types of assembly methods, allowing you to choose the configuration that best suits your space and needs. The drawer unit and open shelves can be positioned on either the left or right side.



Image: Illustration showing how the rack component can be installed on either the left or right side of the desk.

Step 3: Install Drawers and Shelves

Assemble the three drawers and slide them into their designated slots. Attach the open shelves to the frame. Ensure they are securely fastened.



たっぷり収納でデスク周りを快適に！



Image: Close-up view of the desk's storage features, including three pull-out drawers and open shelves for organization.

Step 4: Attach Monitor Stand and Power Outlet

Secure the monitor stand to the main desktop. Install the power outlet unit, ensuring it is properly connected and accessible.



Image: Detail of the desk's power strip, featuring two AC outlets and two USB ports for convenient device charging.

Step 5: Final Adjustments

Once all components are assembled, tighten all screws. Use the adjustable feet at the bottom of the desk legs to level the desk and prevent wobbling.

Your browser does not support the video tag.

Video: A short demonstration of the ODK L-shaped desk's features, including storage, power outlets, and overall design.

OPERATING INSTRUCTIONS

Using the Power Outlet

Plug the desk's power cord into a wall outlet. You can then use the two AC outlets and two USB ports to power or charge your electronic devices. Ensure devices are compatible with the power specifications (100-240V/15A for AC, 5V-2A for USB).

Utilizing Storage

The three drawers are suitable for storing office supplies, personal items, or documents. The open shelves can hold books, decorative items, or a computer tower. Organize items to maintain a tidy workspace.

Ergonomic Use with Monitor Stand

Place your monitor(s) on the elevated stand. This helps to raise your eye level, promoting a more upright posture and reducing strain on your neck and back during long periods of work or gaming.



2 USB ポート
5V-2A



2 ACコンセント
100-240V/15A



延長コード
1.8m



左右付け替え可能

L字型デスク

Image: Comparison of ergonomic posture with and without a monitor stand, demonstrating how the stand helps prevent hunching.

MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the melamine finish.
- **Spills:** Immediately wipe up any spills to prevent water damage or staining.
- **Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as needed to maintain the desk's stability.
- **Weight Distribution:** Distribute weight evenly across the desk surface and shelves. Avoid concentrating heavy items in one area.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly.	Uneven floor; loose fasteners.	Adjust the leveling feet at the bottom of the legs. Tighten all assembly screws.
Drawers do not slide smoothly.	Improper assembly; obstruction.	Check drawer assembly. Ensure nothing is obstructing the drawer slides.
Power outlets not working.	Desk not plugged in; faulty connection.	Ensure the desk's power cord is securely plugged into a working wall outlet. Check all internal connections of the power strip.
Missing or damaged parts upon arrival.	Manufacturing defect or shipping damage.	Contact customer support immediately for assistance.

SPECIFICATIONS

Brand	ODK
Model Number	B0D1R2DGSJ

Color	Grey
Shape	L-shaped
Product Dimensions	Width: 184/146 cm, Depth: 80 cm, Height: 76 cm
Package Dimensions	130.4 x 58 x 10.4 cm
Item Weight	Approx. 23.5 kg
Material	High-strength melamine board, Steel frame
Finish Type	Powder Coated
Special Features	Ergonomic, Adjustable, Built-in Power Outlet (2 AC, 2 USB)
Assembly Required	Yes (Wrench included)

WARRANTY AND SUPPORT

If you encounter any issues with your ODK L-shaped Gaming Desk, such as missing parts or defects, please do not hesitate to contact our customer support. We are committed to providing assistance and resolving any concerns you may have.

For support, please refer to the contact information provided with your purchase or visit the ODK official website.