

Beyution BN59-01432A

Beyution BN59-01432A Replacement Voice Remote Control User Manual

Model: BN59-01432A

1. INTRODUCTION

This manual provides comprehensive instructions for the Beyution BN59-01432A Replacement Voice Remote Control. Designed for seamless compatibility with various Samsung Neo QLED 4K Smart TV models from 2023 and beyond, this remote offers intuitive control and voice command capabilities for an enhanced viewing experience.





Image: Front view of the Beyution BN59-01432A Replacement Voice Remote Control, showcasing its sleek black design and button layout.

2. SETUP

2.1 Battery Installation

The Beyution BN59-01432A remote control requires two (2) AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



**Power by
2 x AAA alkaline batteries**

(Battery is **NOT** included)

Image: Back view of the remote control, illustrating the battery compartment and indicating the need for 2 x AAA alkaline batteries.

2.2 Initial Pairing with Samsung Smart TV

Upon first use, the smart voice remote control is designed to automatically connect to your Samsung TV. Follow the steps below for initial setup:

1. Ensure your Samsung Smart TV is powered on.
2. The remote control should attempt to pair automatically.
3. If the remote control does not automatically connect, point the remote control directly towards the remote control sensor on your Samsung TV.
4. Simultaneously press and hold the **Back** button (↶) and the **Play/Pause** button (⏮) for 3 seconds or longer. Release

the buttons once a pairing confirmation message appears on your TV screen.





Image: Angled view of the remote control, showing the layout of the navigation, back, and play/pause buttons relevant for pairing.

3. OPERATING INSTRUCTIONS

The Beyution BN59-01432A remote control provides full functionality for your Samsung Smart TV. Familiarize yourself with the main control areas:

- **Power Button:** Located at the top right, used to turn the TV on or off.
- **Voice Command Button:** Located near the top, press and hold to activate voice control and speak your commands.
- **Navigation Pad:** The circular pad in the center allows for directional navigation (Up, Down, Left, Right) and selection (center button).
- **Volume Buttons (+/-):** Adjusts the TV's volume level.
- **Channel Buttons (Up/Down):** Changes TV channels.
- **Home Button:** Returns to the TV's Smart Hub or home screen.
- **Back Button:** Navigates back to the previous screen or menu.
- **Play/Pause Button:** Controls media playback.
- **Quick Access Buttons:** Dedicated buttons for popular streaming services such as Netflix, Prime Video, and Disney+ for direct access.



Image: Another angled view of the remote control, providing a clear perspective of all functional buttons for daily operation.

4. MAINTENANCE

4.1 Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Refer to section 2.1 for detailed battery installation instructions.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

4.3 Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage.

5. TROUBLESHOOTING

If you encounter issues with your Beyution BN59-01432A remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
 - Check if the batteries are correctly inserted and have sufficient charge. Replace them if necessary.
 - Ensure there are no obstructions between the remote control and the TV's sensor.
 - Re-pair the remote control with the TV by following the instructions in section 2.2.
- **Voice Command Not Working:**
 - Ensure the remote is properly paired via Bluetooth.
 - Check your TV's settings to ensure voice control is enabled.
 - Speak clearly and directly into the microphone on the remote control.
- **Intermittent Functionality:**
 - This could indicate low battery power. Replace the batteries.
 - Ensure no other devices are causing Bluetooth interference.

If these steps do not resolve the issue, please contact Beyution customer support for further assistance. Refer to the "Warranty and Support" section for contact information.

6. SPECIFICATIONS

Brand	Beyution
Model Number	BN59-01432A (BE-M-1720-BN59-01432A-VC)
Color	Black
Connectivity Technology	Bluetooth
Special Features	Ergonomic, Voice Control
Compatible Devices	Samsung Neo QLED 4K Smart TVs (2023 models including QN95C, Q80C, Q60C, QN800C, QN900C, CU8000, QN90C, CU7000 series, and others)
Power Source	2 x AAA Alkaline Batteries (not included)

Number of Buttons	20
Maximum Range	10 Meters

7. WARRANTY AND SUPPORT

Beyution is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, if you have any questions, concerns, or require assistance with your Beyution BN59-01432A Replacement Voice Remote Control, please do not hesitate to contact us.

For professional suggestions and support, please send a message to the seller through the platform where you purchased the product. We are ready to provide timely assistance.

