

JmGO N1S

JMGO N1S GTV Portable Triple Laser Projector User Manual

Model: N1S

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your JMGO N1S GTV Portable Triple Laser Projector. Please read this manual thoroughly before using the projector to ensure optimal performance and safety.

The JMGO N1S GTV is a portable triple laser projector offering 1080P Full HD resolution, 850 ISO lumens brightness, HDR10 support, and integrated Google TV for endless entertainment. Its unique gimbal design allows for flexible projection angles, including ceiling projection.

2. WHAT'S IN THE BOX

Upon unpacking, please ensure all items listed below are present and in good condition:

- JMGO N1S GTV Portable Triple Laser Projector
- Remote Control
- Power Adapter
- Power Cable
- AAA Batteries (2) for Remote Control
- Quick Start Guide
- Allen Wrench (for adjustments)



Image: JMGO N1S GTV Portable Triple Laser Projector with its included accessories, including the remote control, power adapter, and cables.

3. SETUP

3.1 Initial Placement

Place the projector on a stable, flat surface. Ensure there is adequate ventilation around the device. The unique gimbal design allows for flexible positioning.

Cinema Grade Triple Laser Stunning Visual Experience

10

HDR

850

ISO Lumens

110%

BT.2020

1600:1

Contrast Ratio

$\Delta E < 1$

Color Accuracy

1.07

Billion Colors



Image: The JMGO N1S GTV projector being adjusted to demonstrate its 135-degree projection angle, allowing for versatile placement and ceiling projection.

3.2 Power Connection

1. Connect the power cable to the power adapter.
2. Plug the power adapter into the DC input port on the projector.
3. Plug the other end of the power cable into a wall outlet.

3.3 Remote Control Setup

Insert the two AAA batteries into the remote control, ensuring correct polarity.

3.4 First Power On and Auto-Correction

Press the power button on the remote control or the projector. The projector will automatically perform auto-keystone correction, auto-focus, and screen alignment using its FlexiSmart Adaptive System to ensure a clear and perfectly framed image.

4. OPERATING INSTRUCTIONS

4.1 Navigating Google TV

The projector comes with built-in Google TV, providing access to a wide range of streaming services and apps. Use the remote control to navigate the interface:

- **Directional Pad:** Navigate through menus and select items.
- **OK Button:** Confirm selections.
- **Back Button:** Return to the previous screen.
- **Home Button:** Go to the Google TV home screen.
- **Netflix/Prime Video Buttons:** Direct access to these streaming platforms.
- **Voice Assistant Button:** Press and hold to use Google Assistant for voice commands.

Endless Fun on Google TV

One-Click Access to Netflix



Image: The Google TV interface displayed by the JMGO N1S GTV projector, showing various streaming app icons like Netflix, Prime Video, and Disney+.

4.2 Connecting External Devices

The projector supports various connectivity options:

- **HDMI:** Connect gaming consoles, Blu-ray players, or other HDMI-enabled devices.
- **USB:** Play media files directly from a USB drive.
- **Bluetooth:** Connect external Bluetooth speakers or headphones for enhanced audio.

- **Wi-Fi:** Connect to your home network for streaming and online features. Supports Wi-Fi 6.
- **3.5mm Jack:** Connect wired audio devices.

4.3 Adjusting Projection Size and Quality

The projector can display images up to 200 inches. While auto-correction handles most adjustments, you can fine-tune settings:

- **Manual Focus:** If needed, use the remote control settings to manually adjust focus.
- **Keystone Correction:** Manual keystone adjustments can be made through the settings menu if the automatic correction is not ideal for your specific setup.
- **Brightness/Contrast:** Adjust image brightness and contrast settings in the display menu to suit your viewing environment.

Ceiling Mode, Lying Free

Watch Favorites while Lying Back with No-Fuss Setup



Flexible
Projection Angle



No Tripod
Needed



One-handed
Stable Hovering

Image: The JMGO N1S GTV projector positioned to project an image onto a bedroom ceiling, demonstrating its flexible projection capabilities for comfortable viewing.

5. MAINTENANCE

5.1 Cleaning the Lens

Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Do not use abrasive cleaners or excessive force.

5.2 Cleaning the Projector Body

Wipe the exterior of the projector with a soft, dry cloth. Avoid using liquid cleaners directly on the device.

5.3 Ventilation

Ensure the ventilation vents are clear of dust and obstructions to prevent overheating. Do not block the air inlets or outlets during operation.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Power cable not connected; Power outlet issue.	Check power connections; Try a different outlet.
No Image	Input source not selected; Lens cap on; Focus issue.	Select correct input; Remove lens cap; Allow auto-focus or manually adjust.
Blurred Image	Out of focus; Incorrect projection distance.	Allow auto-focus to re-adjust or manually adjust; Adjust projector distance from screen.
Remote Not Responding	Low batteries; Obstruction between remote and projector.	Replace batteries; Ensure clear line of sight.
No Sound	Volume too low; Muted; External audio device not connected properly.	Increase volume; Unmute; Check external audio connections.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	7.3 x 6.5 x 7.5 inches
Item Weight	4.4 pounds
Model Number	N1S
Display Resolution	1920 x 1080 (1080P FHD)
Brightness	850 ISO Lumens
Contrast Ratio	1600:1

Feature	Detail
Special Features	3D-Ready, Auto Focus, Digital Keystone Correction, Portable, Wi-Fi Ready
Connectivity Technology	3.5mm Jack, Bluetooth, HDMI, USB, Wi-Fi
Recommended Uses	Business, Education, Gaming, Home Cinema
Visible Screen Diagonal	Up to 200 inches (458 cm)
Audio	2*5W Dolby Digital Speakers (JMGO Master audio system)

8. WARRANTY INFORMATION

The JMGO N1S GTV Portable Triple Laser Projector comes with a standard manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card included in your product packaging or visit the official JmGO website.

Optional extended protection plans may be available for purchase. Please check with your retailer for details.

9. CUSTOMER SUPPORT

For technical assistance, product inquiries, or warranty claims, please contact JmGO customer support:

Email: after-sales@jmgo.com

Website: [Visit the JmGO Store on Amazon](#)

Please have your product model number (N1S) and purchase information ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question