

ANDOLL HOME FT-3S

ANDOLL HOME FT-3S 4L Automatic Cat Feeder Instruction Manual

Model: FT-3S

1. INTRODUCTION

Thank you for choosing the ANDOLL HOME FT-3S 4L Automatic Cat Feeder. This manual provides detailed instructions for the safe and efficient use of your new pet feeder. Please read all instructions carefully before use and retain this manual for future reference.

Safety Precautions

- This appliance is for indoor use only.
- Do not immerse the main unit in water or other liquids.
- Use only dry pet food with a kibble size between 2-12mm (0.07-0.5 inches).
- Keep out of reach of children and pets to prevent tampering.
- Always unplug the feeder before cleaning.
- Ensure the power adapter is securely connected.

2. PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- Pet Feeder Body
- Food Storage Tank
- Feeding Bowl (Stainless Steel)
- 5V DC Power Adapter
- Desiccant Bag (pre-installed or separate)
- Instruction Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your automatic pet feeder.



Image 3.1: Main view of the ANDOLL HOME FT-3S 4L Automatic Cat Feeder, showing the food tank, control panel, and feeding bowl.

Exquisite and sturdy, Easy to clean

Thoughtful and thoughtful design makes it easy for you to use, easy to clean, and durable.



Warning: Please use a damp cloth to wipe the base

Image 3.2: Diagram illustrating the fresh food sealing mechanism, including the desiccant box and sealing ring.

Smooth Food Dispensing System

No more worry about food stuck



good quality impeller



Large dispensing
containers
with flexible baffle



Wide and
inclined food outlet

Suitable for dry food ONLY, with kibble size ranging from 2-12mm/0.07-0.5in in diameter

Image 3.3: Illustration of the smooth food dispensing system, designed to prevent food blockages.

4. SETUP

4.1 Assembly

1. Place the main feeder body on a flat, stable surface.
2. Attach the feeding bowl to the base of the feeder. Ensure it clicks into place securely.
3. Open the lid of the food storage tank and fill it with dry pet food. Ensure the kibble size is between 2-12mm (0.07-0.5 inches).
4. Close the lid firmly to maintain food freshness and prevent pets from accessing food.

4.2 Power Supply

The feeder supports two power options:

- **Primary Power:** Connect the 5V DC power adapter to the feeder's power port and plug it into a wall outlet.

- **Backup Power:** For power outage protection, install three (3) D-cell alkaline batteries (not included) into the battery compartment at the bottom of the feeder. This ensures continuous operation in case of a power interruption.

Multiple Power Supply Options

D alkaline battery or use a 5VDC/1A power adapter, as you wish



The feeder includes 5VDC/1A power adapter.

Image 4.1: Illustration of the dual power supply options for the feeder.

4.3 Initial Settings

Upon first power-up, the display will illuminate. You may need to set the current time before programming feeding schedules.

- Refer to the control panel (Image 3.1) for buttons such as SET, +, -, FEED.
- Unlock the screen if necessary by pressing and holding the appropriate button (usually SET or a dedicated unlock button) for a few seconds.
- Use the SET button to navigate through time settings (hour, minute) and the + / - buttons to adjust values.

5. OPERATING INSTRUCTIONS

5.1 Programming Feeding Schedules


The feeder allows you to schedule up to 8 meals per day, with customizable portion sizes for each meal.

Schedule Meal Times

Automatically feed your pet on schedule



4L Food Tank



2-12mm/0.07-0.5in
Kibble Size



Max 8 Meals
per Day



Max 50 Portions
per Meal



Image 5.1: Overview of scheduling capabilities, including tank capacity, kibble size, and meal frequency.

Healthy meals, Pet scientific diet

Eat fewer and more meals to make your pet healthier, set as your wish



Image 5.2: The large screen display for easy viewing and operation of settings.

1. Press the SET button to enter the feeding schedule programming mode.
2. Use the + / - buttons to select the meal number (e.g., F1 for the first meal).
3. Press SET again to adjust the feeding time (hour and minute) for the selected meal. Use + / - to change values.
4. Press SET to move to the portion size setting. Use + / - to select the desired number of portions (up to 50 portions per meal).
5. Repeat for additional meals (F2, F3, etc.) as needed.
6. After setting all desired meals, press and hold SET to save and exit programming mode.

Always at the side of your pets

10 seconds custom voice recording
Play your recording 3 times at meal time



Image 5.3: Example of a programmed feeding schedule for healthy pet diet.

5.2 Custom Voice Recording

You can record a 10-second voice message that will play 3 times at each scheduled feeding time to call your pet.

Large screen display with backlight

Easy to view and operate



Current time, next feeding time and portion shows on the main interface directly. No need to enter the secondary settings menu.



Image 5.4: The feeder's custom voice recording feature in action.

1. Locate the record button (often labeled with a microphone icon or integrated with the SET button).
2. Press and hold the record button. The feeder will indicate when recording starts (e.g., a beep or flashing icon).
3. Speak your message clearly into the microphone for up to 10 seconds.
4. Release the record button to save the message. The feeder will indicate successful saving.

5.3 Manual Feeding

To dispense food immediately outside of scheduled times:

- Press the FEED button once to dispense one portion of food.
- Press the FEED button multiple times to dispense additional portions as needed.

6. MAINTENANCE

Regular cleaning ensures hygiene and optimal performance of your feeder.

Always Fresh Food

Two layer sealing design for import and export, keeping food fresh



Image 6.1: Disassembled components for easy cleaning.

6.1 Cleaning Instructions

1. Unplug the feeder from the power outlet and remove any backup batteries.
2. Remove the food storage tank and the feeding bowl from the main body.
3. The food storage tank and feeding bowl can be hand-washed with mild soap and water. Rinse thoroughly and dry completely before reassembling.
4. Wipe the main feeder body with a soft, damp cloth. Do not immerse the main body in water.
5. Ensure all parts are completely dry before reassembling and refilling with food.

6.2 Desiccant Replacement

The desiccant bag helps keep food fresh. Replace it periodically (e.g., every 1-2 months) or when it appears saturated.

- Locate the desiccant box, typically integrated into the lid of the food tank (refer to Image 3.2).
- Remove the old desiccant bag and insert a new one.

- Close the desiccant box securely.

7. TROUBLESHOOTING

If you encounter issues with your feeder, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Feeder does not power on.	Power adapter not connected; batteries depleted or incorrectly installed.	Ensure power adapter is securely plugged in. Check and replace D-cell batteries if using backup power.
Food is not dispensing.	Food blockage; food tank empty; incorrect kibble size; dispensing mechanism jammed.	Check food level. Ensure kibble size is within 2-12mm. Clear any food blockages in the dispenser (refer to Image 3.3). Clean the dispensing mechanism.
Scheduled meals are not dispensing.	Incorrect time setting; feeding schedule not programmed correctly.	Verify the current time setting. Re-program the feeding schedule following Section 5.1.
Voice recording is not playing.	No recording saved; volume too low.	Ensure a voice message has been successfully recorded (Section 5.2). Check if there is a volume setting and adjust if available.
Pet is able to open the lid.	Lid not securely closed.	Ensure the lid is firmly closed and latched after refilling food.

8. SPECIFICATIONS

- **Model:** FT-3S
- **Brand:** ANDOLL HOME
- **Capacity:** 4 Liters
- **Material:** BPA Free ABS, Stainless Steel
- **Dimensions (LxWxH):** 7 x 7 x 13 inches
- **Item Weight:** 5 Pounds
- **Kibble Size Compatibility:** 2-12mm (0.07-0.5 inches)
- **Max Meals Per Day:** Up to 8
- **Max Portions Per Meal:** Up to 50
- **Voice Recording:** 10 seconds
- **Power Supply:** 5V DC Adapter (included), 3 x D-cell Alkaline Batteries (not included)
- **Target Species:** Cat (suitable for small and medium animals)

9. WARRANTY AND SUPPORT

9.1 Warranty Information

This ANDOLL HOME FT-3S Automatic Cat Feeder comes with a **1-year manufacturer's warranty** from the date of

purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or neglect.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your ANDOLL HOME FT-3S Automatic Cat Feeder, please contact ANDOLL HOME customer support through the retailer where the product was purchased or refer to the contact information provided on the product packaging or official brand website.

© 2025 ANDOLL HOME. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question