

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Jensen](#) /

> [Jensen Bluetooth 3-Speed Turntable CD Player Home Stereo System User Manual](#)

Jensen 1250

Jensen® Bluetooth® 3-Speed Turntable CD Player Home Stereo System User Manual

Model: JMC-1250

PRODUCT OVERVIEW

The Jensen 3-speed stereo turntable, equipped with a CD changer and dual cassette deck, caters to music enthusiasts who appreciate the versatility of playing various formats. It brings the old-school charm of making mix tapes into the modern era. This Jensen record player features cutting-edge Bluetooth 3.0 technology, allowing users to effortlessly stream their preferred tunes directly to their devices. This capability ensures an easy and hassle-free link between the record player and any device with Bluetooth functionality, offering users the highest level of convenience and an enhanced audio experience. The Jensen stereo features a turntable and is designed for multi-format compatibility, enabling users to enjoy music from MP3s, CDs, and CD-R/RW discs with excellent sound quality and reliability. This stereo with turntable is designed to be compatible across various formats, allowing for a seamless experience whether you are playing MP3 files, standard CDs, or even CD-R/RW discs. This flexibility ensures that users can enjoy a wide range of music media, from the latest digital tracks to cherished mixes on CDs, all with exceptional sound quality and reliability. A 2-speaker configuration offers an enriched stereo sound, beautifully crafted for improved acoustics and clarity. Perfect for music lovers and audiophiles, it delivers every note with exceptional precision, creating an immersive listening experience. Control your system effortlessly from anywhere in the room with the included remote. Easily adjust volume, change the input source, and navigate your media without moving, improving convenience and accessibility. Whether you're looking to enjoy vintage vinyl records or modern beats, this turntable bridges the gap between classic audio and contemporary technology, making it easier than ever to enjoy your music collection without the hassle of wires or complicated setups.



Figure 1: Front view of the Jensen Home Stereo System, showcasing the main unit with turntable, CD changer, dual cassette deck, and two detachable speakers, along with the remote control.

SETUP GUIDE

Follow these steps to set up your Jensen Home Stereo System:

- 1. Unpacking:** Carefully remove all components from the packaging. Ensure all items listed in the packing list are present: main unit, two speakers, remote control, and dust cover.
- 2. Placement:** Place the main unit and speakers on a stable, flat surface. Ensure adequate ventilation around the unit. Keep the system away from direct sunlight, heat sources, and moisture.
- 3. Speaker Connection:** Connect the speaker wires from the main unit to the corresponding terminals on the back of each speaker. Ensure correct polarity (+ to + and - to -) for optimal sound.
- 4. Power Connection:** Plug the AC power cord into a wall outlet.
- 5. Remote Control Batteries:** Open the battery compartment on the remote control and insert two AAA batteries (not included), observing the correct polarity.
- 6. Dust Cover Installation:** Carefully place the clear dust cover over the turntable platter on the top of the main unit.



Figure 2: The Jensen Home Stereo System with the turntable dust cover open, revealing the turntable platter and tonearm, ready for vinyl playback.

OPERATING INSTRUCTIONS

General Operation

- **Power On/Off:** Press the **POWER** button on the front panel or remote control to turn the unit on or off.
- **Volume Control:** Rotate the **VOLUME** knob on the main unit or use the **VOL+ / VOL-** buttons on the remote to adjust the sound level.
- **Function Selection:** Press the **FUNCTION** button repeatedly on the main unit or remote to cycle through modes: PHONO (Turntable), CD, TAPE, FM, AM, Bluetooth.

Turntable Operation (PHONO)

1. Select **PHONO** function.
2. Open the dust cover.
3. Place a record on the turntable platter.
4. Select the appropriate speed (33 $\frac{1}{3}$, 45, or 78 RPM) using the **SPEED** switch. For 45 RPM records, place the included 45 RPM adapter on the spindle.
5. Release the tonearm lock.

6. Gently lift the tonearm using the cue lever and position it over the desired track on the record.
7. Lower the tonearm slowly onto the record using the cue lever. Playback will begin.
8. At the end of the record, the tonearm will automatically return to its rest position (auto-stop feature). Lift the tonearm, return it to the rest, and engage the lock when finished.

CD Player Operation

1. Select **CD** function.
2. Press the **OPEN/CLOSE** button to open the CD tray.
3. Place up to three CDs into the trays, label side up.
4. Press the **OPEN/CLOSE** button again to close the tray. The system will read the discs.
5. Press **PLAY/PAUSE** to start playback.
6. Use **SKIP/SEARCH** buttons (◀◀ / ▶▶) to navigate tracks. Hold to fast forward/rewind.
7. Press **STOP** to end playback.
8. The system supports MP3, CD, and CD-R/RW formats.

Dual Cassette Deck Operation

1. Select **TAPE** function.
2. Press the **OPEN/EJECT** button for Deck 1 or Deck 2 to open the cassette door.
3. Insert a cassette tape with the open edge facing upwards.
4. Close the cassette door.
5. Press **PLAY** on the desired deck to start playback.
6. Use **FAST FORWARD / REWIND** buttons to navigate.
7. Press **STOP/EJECT** to stop playback and eject the tape.
8. To record, ensure a blank tape is in Deck 2 (recording deck). Select the desired source (PHONO, CD, FM/AM, or TAPE 1 for dubbing). Press **RECORD** on Deck 2, then **PLAY** on Deck 2 and the source.

Bluetooth Operation

1. Select **Bluetooth** function. The display will show "BT" and flash, indicating pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "JENSEN JMC-1250" from the list of devices.
4. Once paired, the display will stop flashing and show "BT". You can now stream audio from your device to the stereo system.
5. Control playback (play/pause, skip tracks) from your connected device or using the system's controls.

AM/FM Tuner Operation

1. Select **FM** or **AM** function.
2. Extend the FM wire antenna for better reception. For AM, rotate the unit for best reception.
3. Press the **TUNING UP / DOWN** buttons to manually tune to a station.
4. Press and hold the **TUNING UP / DOWN** buttons for automatic station scanning. The tuner will stop at the next strong signal.
5. To save a station as a preset, tune to the desired station, then press **PROGRAM**, use **PRESET UP / DOWN** to select a

preset number, and press **PROGRAM** again to confirm.



Figure 3: The Jensen Home Stereo System components, showing the main unit and the two separate speakers, highlighting the modular design.

MAINTENANCE

- **General Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.
- **Dust Cover:** Keep the dust cover closed when the turntable is not in use to prevent dust accumulation on the platter and stylus. Clean the dust cover with a soft, damp cloth.
- **Stylus Care:** The stylus (needle) is delicate. Clean it periodically with a soft brush, brushing from back to front. Replace the stylus if sound quality deteriorates or if it is visibly damaged.
- **CD Player:** Use a clean, lint-free cloth to wipe CDs from the center outwards. Avoid touching the playing surface.
- **Cassette Deck:** Periodically clean the tape heads, pinch rollers, and capstans with a cotton swab lightly dampened with isopropyl alcohol. This helps maintain sound quality and prevent tape damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Power cord not securely plugged in; Power outlet not active.	Ensure power cord is firmly connected. Test the outlet with another device.
No Sound	Volume too low; Incorrect function selected; Speakers not connected properly.	Increase volume. Select the correct function (CD, PHONO, TAPE, etc.). Check speaker connections.
Turntable not spinning or skipping	Speed setting incorrect; Stylus dirty or damaged; Record dirty or warped.	Verify correct speed (33 $\frac{1}{3}$, 45, 78 RPM). Clean or replace stylus. Clean record.
CD not playing or skipping	CD dirty or scratched; CD inserted incorrectly; Disc format not supported.	Clean CD. Insert CD label side up. Ensure disc is CD, CD-R/RW, or MP3 CD.
Cassette tape not playing or jammed	Tape tangled or damaged; Tape heads dirty.	Try a different tape. Clean tape heads and pinch rollers.
Bluetooth pairing issues	Device too far; Bluetooth not enabled on device; Incorrect pairing procedure.	Ensure device is within range. Enable Bluetooth on your device. Re-attempt pairing.
Remote control not working	Batteries dead or inserted incorrectly; Obstruction between remote and unit.	Replace batteries, check polarity. Remove obstructions. Point remote directly at the unit.

SPECIFICATIONS

- **Model Name:** JMC-1250
- **Product Dimensions:** 24 x 16 x 19 inches
- **Item Weight:** 28 pounds
- **Connectivity Technology:** Bluetooth, USB
- **Included Components:** Remote control, Dust cover
- **Material:** Metal
- **Color:** Gold
- **Compatible Devices:** MP3 Player
- **Motor Type:** AC Motor
- **Manufacturer:** Jensen
- **Date First Available:** April 15, 2024

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the warranty card included with your product or visit the official Jensen website. Keep your purchase receipt as proof of purchase for warranty claims.

Official Jensen Website: www.jensen.com

IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions before operating this device. Retain this manual for future reference. Do not expose the unit to rain or moisture. Do not block any ventilation openings. Only use attachments/accessories specified by the manufacturer. Refer all servicing to qualified service personnel.

VIDEO RESOURCES

No official product videos from the seller were provided for this manual. Please check the manufacturer's website or product page for any available video tutorials or demonstrations.



© 2024 Jensen. All rights reserved.

Related Documents - 1250

	<p>JENSEN JMC-1250 Bluetooth Stereo Turntable System User Manual</p> <p>Comprehensive user manual for the JENSEN JMC-1250 Bluetooth 3-Speed Stereo Turntable, 3 CD Changer Music System with Dual Cassette Deck. Includes setup, operation, safety, troubleshooting, and specifications.</p>
	<p>Jensen JMC-1250 Bluetooth 3-Speed Stereo Turntable User Manual</p> <p>Comprehensive user manual for the Jensen JMC-1250 Bluetooth 3-Speed Stereo Turntable with CD Changer and Dual Cassette Deck. Learn about setup, operation, features, safety, and troubleshooting.</p>
	<p>Jensen JMC-1250 Bluetooth 3-Speed Stereo Turntable System User Manual</p> <p>Comprehensive user manual for the Jensen JMC-1250 Bluetooth 3-Speed Stereo Turntable Music System with Dual Cassette Deck. Learn about setup, operation, features, safety instructions, and troubleshooting.</p>
	<p>Jensen JTA-475 3-Speed Stereo Turntable User Manual</p> <p>User manual for the Jensen JTA-475 3-Speed Stereo Turntable with CD and Cassette Music System and Pitch Control. Includes setup, operation, safety instructions, and troubleshooting.</p>

 <p>Portable Bluetooth CD Music System with Cassette and Digital AM/FM Radio</p> <p>MODEL: CD-785 USER MANUAL</p>	<p>Jensen CD-785 Portable Bluetooth CD Music System User Manual</p> <p>User manual for the Jensen CD-785 Portable Bluetooth CD Music System with Cassette and Digital AM/FM Radio. Includes setup, operation, safety instructions, and troubleshooting.</p>
 <p>BLUETOOTH CD MUSIC SYSTEM WITH DIGITAL AM/FM STEREO RECEIVER AND REMOTE CONTROL</p> <p>MODEL: JBS-210 USER MANUAL</p>	<p>Jensen JBS-210 Bluetooth CD Music System User Manual</p> <p>Comprehensive user manual for the Jensen JBS-210 Bluetooth CD Music System, covering setup, operation, safety instructions, troubleshooting, specifications, and warranty information.</p>

Documents - Jensen – 1250



[ADB Potenza Universal Remote Control Technical Guide](#)

Comprehensive technical guide for the WTCtv ADB Potenza Universal Remote Control, including instructions for programming, brand setup, automatic search, learning features, volume lock, and troubleshooting common issues. Find brand codes for various electronic devices.

lang:en score:34 filesize: 352.05 K page_count: 13 document date: 2019-07-24



[\[pdf\] User Manual Instructions Guide](#)

Atlas OCAP 5 Device Universal Remote Control with Learning Created for Electronics by Manual Labour Inc WOW! Business Users Guide PREPROGRAMMED FOR YOUR SET TOP BOX wish to control Please follow the instructions detailed in this manual set up unit and then start enjoying your new remote cable service M1056L fm Page 4 Friday December 22 2006 6 10 PM atlas ocap OCAPM1056L CURRENT wowforbusiness docs wow product support broadstripe UserGuides wowway mm guides Atlas OCAP M1056L.fm Page 1 Friday, December 22, 2006 6:10 PM ATLAS OCAP 5-Device Remote Control wit ... 3 1602 1370 0531 1189, 0189, 0008, 0042, 0360, ,0121, 1289 0195 0195 1352 1263, 1389 1136 1420 0080 **1250** 1383 1414 1360, 0004, 0273, 0771, 1142, 0121 0424 0042, 0219, 0360, 1801 0424, 0463 1517, 1567 ...

lang:en score:33 filesize: 5.8 M page_count: 68 document date: 2006-12-28



[Potenza ST Universal Remote Control User Guide](#)

Comprehensive user guide for the Universal Electronics Potenza ST Universal Remote Control, detailing setup, programming, features, and troubleshooting for home entertainment systems.

lang:en score:32 filesize: 3.78 M page_count: 60 document date: 2015-04-03



[\[pdf\] User Manual Guide](#)

Potenza Manufactures Guide Created for Universal Electronics by Manual Labour Inc 1 swiftel net 2023 02 |||

Potenza ST Universal Remote Control Users Guide PREPROGRAMMED FOR YOUR SET-TOP BOX TABLE OF CONTEN ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...

lang:en score:31 filesize: 1.34 M page_count: 56 document date: 2023-02-27



[\[pdf\] User Manual Instructions](#)

Provided by ManualsAndMore Download User Manual Integra telecom rc 804m Setup Instructions rc804m manualsandmore |||

REMOTE CONTROL SET-UP INSTRUCTIONS Integra Telecom 4690 Colorado St SE I Prior Lake, MN 55372 952.22 ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...

lang:en score:31 filesize: 2.34 M page_count: 18 document date: 2019-07-23



[\[pdf\]](#) User Manual Guide

Atlas OCAP 5 Device Universal Remote Control with Learning Created for Electronics by Manual Labour Inc NexTV Manufacturer s Guide User Guides Ritter Communications Manufacturers cdn2 hubspot net hubfs 497316 Digital |||

Potenza ST Universal Remote Control Users Guide PREPROGRAMMED FOR YOUR SET-TOP BOX TABLE OF CONTEN ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...


lang:en score:31 filesize: 3.14 M page_count: 56 document date: 2020-05-21



[Universal Electronics Potenza ST Universal Remote Control User Guide](#)

Comprehensive user guide for the Universal Electronics Potenza ST Universal Remote Control. Learn setup, programming, features, and troubleshooting for controlling TVs, DVD players, set-top boxes, and more.

lang:en score:31 filesize: 873.34 K page_count: 57 document date: 2023-05-02



[\[pdf\]](#) User Manual Guide

ADB Potenza Remote Kristi Larson James Valley Telecommunications F 2100 Universal Tv Manual Pdf St 620 Control User Guide polarcomm 2019 03 |||

Remote Control Guide Device Selection Send commands to TV, audio, DVD, auxiliary device or set top ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0513 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...

lang:en score:29 filesize: 729.44 K page_count: 13 document date: 2018-01-18


[\[pdf\]](#) User Manual Instructions Guide



Atlas OCAP 5 Device Universal Remote Control with Learning Created for Electronics by Manual Labour Inc Cogeco ATLAS Télécommande appareils Users Guide d utilisation PREPROGRAMMED FOR YOUR SET TOP BOX PRÉPROGRAMMÉE POUR VOTRE DÉCODEUR Please follow the instructions detailed in this manual to set up unit and then start enjoying your new remote control cable service M1056 fm urcsupport atlasocap 4 INTRODUCTION The is our latest generation universal Use PIP ON OFF switch Picture In feature on or off if available TV SWAP images sound between main window pictures MOVE move picture different positions atlas ocap5 en cogeco ca sites default files guides web resources support user tv 80 userguide

ATLAS OCAP 5-Device Remote Control Tlcommande ATLAS OCAP 5 appareils Users Guide Guide d utilisation ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...

lang:en score:29 filesize: 5.47 M page_count: 59 document date: 2009-05-12



[\[pdf\]](#) User Manual Guide

MUG9700 SDDS 01 draft Button map URC9700 Manual Bluetooth Pairing Mode FCC GUIDE Displays program guide EXIT Exits current menu and returns to 2021 2116 2061 2467 0176 1331 2471 Zenith 2197 1869 2921963 certid org document

URC9700 User Manual Button map Manual Bluetooth Pairing Mode IR assisted pairing TV: Powers ON ... 14, 1757 1868 0178 1927, 1924, 0178, 0150, 1570, 1670, 1671, 1892, 0178, 0150 0017, 0051 1603, 1990 **1250**, 0178, 0150, 1797 0060 0180 0156, 0178 3382, 2104, 2735, 3423, 4093 1398, 1797 1755 2183 0178 1...

lang:en score:28 filesize: 4.08 M page_count: 2 document date: 2016-03-01



[\[pdf\]](#) Guide

ADB Remote Potenza STHow To Guides Mosaic Guiding you how to set up services and more!User Guide for STexperiencemosaic support guides https experiencemosaic 2020 03 User ST ||| Potenza ST Universal Remote Control Users Guide PREPROGRAMMED FOR YOUR SET-TOP BOX Note: Some keys ... olk Audio Proscan RCA Rio Samsung Sansui Sanyo Sharp Sharper Image Sherwood Sirius Sonic Blue 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...


lang:tl score:28 filesize: 410.98 K page_count: 29 document date: 2009-03-11



[Universal Electronics Potenza ST Universal Remote Control User Guide](#)

User guide for the Universal Electronics Potenza ST Universal Remote Control, detailing setup, features, programming, and troubleshooting for consolidating home entertainment devices.

lang:en score:28 filesize: 3.86 M page_count: 60 document date: 2007-10-15



[Jensen JMC-1250 Bluetooth 3-Speed Stereo Turntable System User Manual](#)

Comprehensive user manual for the Jensen JMC-1250 Bluetooth 3-Speed Stereo Turntable Music System with Dual Cassette Deck. Learn about setup, operation, features, safety instructions, and troubleshooting.


lang:en score:27 filesize: 1.84 M page_count: 12 document date: 2019-07-23



[Universal Electronics Atlas OCAP 5-Device Remote Control User Guide](#)

User guide for the Universal Electronics Atlas OCAP 5-Device Remote Control, detailing setup, programming, features, and troubleshooting for managing multiple home entertainment devices.

lang:en score:27 filesize: 1.03 M page_count: 58 document date: 2010-06-10



[\[pdf\] Reference Guide Guide](#)

ToneSpeak Guitar Reference Guide indd cobis Manchester 1290 12 British Voiced Speaker 8 Ohm 1 parts express pedocs buyer guides |||

GUITAR Speaker reference guide 12 Guitar Speakers ToneSpeak Model Ausn **1250** - American-voiced speaker - 50 wa s, 8 or 16 ohm - 100 dB - 50 oz. ferrite magnet Tonal Characteristics Compare to Balance, punch, fullness, and Eminence GA-SC64 clarity are at the forefront of Jensen C12N this speaker. ...

lang:en score:26 filesize: 393.55 K page_count: 4 document date: 2023-04-12



[\[pdf\]](#) User Manual Guide

Atlas OCAP 5 Device Universal Remote Control with Learning Created for Electronics by Manual Labour Inc any form or means electronic mechanical magnetic optical manual otherwise without prior written permission of M6695 transmitted transcribed stored in retrieval system translated to language digit code your device If performed correctly the selected mode key will blink twice NOTE emits a long entry is invalid Repeat steps 2 through 4 and try entering same remote manufacturers guide wightman ca content support tv guides control

Potenza ST Universal Remote Control Users Guide PREPROGRAMMED FOR YOUR SET-TOP BOX TABLE OF CONTEN ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...


lang:en score:26 filesize: 3.21 M page_count: 57 document date: 2015-04-27



[Atlas OCAP 5-Device Remote Control User Guide - Universal Electronics](#)

User guide for the Universal Electronics Atlas OCAP 5-Device Remote Control (M1056). Learn setup, programming, features like Macro Keys and Master Power, and troubleshooting for your home entertainment system.

lang:en score:25 filesize: 5.46 M page_count: 60 document date: 2008-04-30



[\[pdf\]](#) User Manual Guide

Atlas OCAP 5 Device Universal Remote Control with Learning Created for Electronics by Manual Labour Inc ATLAS remoto de dispositivo Users Guide Guía del usuario PREPROGRAMMED FOR YOUR SET TOP BOX PREPROGRAMADO PARA SU aparato URC1056 help astound portal api v1 articles 8323 data files ictg Remotes Manuals source webfile |||

ATLAS OCAP 5-Device Remote Control Control remoto de dispositivo ATLAS OCAP 5 Users Guide Gua del us ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...

lang:en score:25 filesize: 1.1 M page_count: 58 document date: 2008-03-31



[Universal Electronics Potenza ST Universal Remote Control User Guide](#)

Comprehensive user guide for the Universal Electronics Potenza ST Universal Remote Control, covering setup, programming, troubleshooting, and advanced features for controlling multiple home entertainment devices.


lang:en score:24 filesize: 3.14 M page_count: 56 document date: 2008-10-15



[\[pdf\] User Manual Guide](#)

Atlas OCAP 5 Device Universal Remote Control with Learning Created for Electronics by Manual Labour Inc 3 On the back of remote control push tab and lift off battery cover Locate two 2 enclosed AA batteries Match marks those in case then insert them user guide ip mypremieronline assets documents Potenza ST Universal Remote Control Users Guide PREPROGRAMMED FOR YOUR SET-TOP BOX TABLE OF CONTEN ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...

lang:en score:23 filesize: 3.13 M page_count: 56 document date: 2012-01-13



[\[pdf\] User Manual Guide Diagram](#)

Motorola DRC800 fm Bgraham Press this Tip To DVD VCR 4 in 1 Note TV mechanical optical manual or otherwise without the prior written permission of MOTOROLA and stylized M logo are registered trademarks US Universal Remote Control User Guide OVERVIEW Your new universal remote operates your other manufacturer 39 s cable set transmitted transcribed stored any retrieval system translated to language form by means electronic motorola rc800 wowforbusiness docs wow product support broadstripe wowway mm guides

Motorola DRC800 4-in-1 Universal Remote Control User Guide OVERVIEW Your new Motorola DRC800 univers ... , 0250, 0463, 0150, 0178, 0179, 0016 0150, 0030, 0178 0047, 0017, 0051, 0135, 0032 0021 0093, 0150, **1250**, 0178 0843, 0700 0835, 0093, 0055 0835 0060, 0030, 0185 0180 0156, 0178, 0866 0030, 1704, 0056 ...

lang:en score:23 filesize: 194.36 K page_count: 2 document date: 2006-09-21



[\[pdf\] User Manual Instructions Guide](#)

Atlas OCAP 5-Device Universal Remote Control with Learning Created for Electronics by Manual Labour Inc Cogeco Please follow the instructions detailed in this manual to set up unit and then start enjoying your new remote control cable service M1056 fm Atlas-OCAP-M1056A d3n9vq79a11zds cloudfront net 2017 08 Use PIP ON-OFF switch Picture-In-Picture feature on or off if available TV SWAP images sound between main window pictures MOVE move picture different positions www porium

ATLAS OCAP 5-Device Remote Control Tlcommande ATLAS OCAP 5 appareils Users Guide Guide d utilisation ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...

lang:en score:22 filesize: 5.48 M page_count: 59 document date: 2020-05-28



[JENSEN JMC-1250 Bluetooth Stereo Turntable System User Manual](#)

Comprehensive user manual for the JENSEN JMC-1250 Bluetooth 3-Speed Stereo Turntable, 3 CD Changer Music System with Dual Cassette Deck. Includes setup, operation, safety, troubleshooting, and specifications.

lang:en score:21 filesize: 1.82 M page_count: 12 document date: 2017-08-07

[\[pdf\] User Manual Guide Diagram](#)

Motorola DRC800 fm Braham Press this Tip To DVD VCR 4 in 1 Note TV mechanical optical manual or otherwise without the prior written permission of MOTOROLA and stylized M logo are registered trademarks US Universal Remote Control User Guide OVERVIEW Your new universal remote operates your other manufacturer 39 s cable set 1447885043 d15yx0mnc9teae cloudfront net sites default files Motorola DRC800 4-in-1 Universal Remote Control User Guide OVERVIEW Your new Motorola DRC800 univers ... , 0250, 0463, 0150, 0178, 0179, 0016 0150, 0030, 0178 0047, 0017, 0051, 0135, 0032 0021 0093, 0150, **1250**, 0178 0843, 0700 0835, 0093, 0055 0835 0060, 0030, 0185 0180 0156, 0178, 0866 0030, 1704, 0056 ...

lang:en score:20 filesize: 193.96 K page_count: 2 document date: 2006-11-13

[\[pdf\] User Manual Guide Diagram](#)

Motorola PVR Remote User Guide Press this Tip To DVD VCR DRC800 4 in 1 Note Armstrong Universal Control OVERVIEW Your new universal remote operates your or other manufacturer 39 s cable set mechanical optical manual otherwise without the prior written permission of MOTOROLA and stylized M logo are registered trademarks top box up to three devices In addition provides remote4 armstrongonewire Content Documents 80 documents support

Motorola DRC800 4-in-1 Universal Remote Control User Guide OVERVIEW Your new Motorola DRC800 univers ... , 0250, 0463, 0150, 0178, 0179, 0016 0150, 0030, 0178 0047, 0017, 0051, 0135, 0032 0021 0093, 0150, **1250**, 0178 0843, 0700 0835, 0093, 0055 0835 0060, 0030, 0185 0180 0156, 0178, 0866 0030, 1704, 0056 ...



lang:en score:20 filesize: 198.04 K page_count: 2 document date: 2011-05-10

[\[pdf\] User Manual Guide](#)

Atlas OCAP 5 Device Universal Remote Control with Learning Created for Electronics by Manual Labour Inc Potenza ST C Spire Users Guide PREPROGRAMMED FOR YOUR SET TOP BOX Nebula fm Page 1 Monday October 15 2007 4 55 PM 3 On the back of remote control push tab and lift off battery cover Locate two 2 enclosed AA batteries Match marks those in case User cspire resources docs home services

Potenza ST Universal Remote Control Users Guide PREPROGRAMMED FOR YOUR SET-TOX BOX TABLE OF CONTEN ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...

lang:en score:20 filesize: 3.14 M page_count: 56 document date: 2014-07-03





[\[pdf\]](#) Guide

Untitled 2022 23 CNU MGolf Media Guide Web s3 us east 2 amazonaws sidearm nextgen sites crusports documents 2023 4 25 |||

ATHLETIC FACILITIES JAMES RIVER COUNTRY CLUB FREEMAN CENTER
TOWNEBANK STADIUM JENNINGS FAMILY SDQ..... 78-78-77-
DQ Team 12th..... 315-309-303-325--**1250** 1995 - MAY 16-19
HULMAN LINKS GOLF COURSE TERRE HAUTE, IND. CNU 10th of 23 teams Scott
Causby....

lang:en score:20 filesize: 20.07 M page_count: 48 document date: 2023-04-25




[\[pdf\]](#) User Manual Guide Diagram

Provided by ManualsAndMore Download User Manual Motorola DRC800 motorola drc800 user manual 4 manualsandmore |||

DRC800 4-in-1 Universal Remote Control User Guide Overview Your new 4-in1 universal remote operates ... , 0016 MGA 0150, 0030, 0178 Midland 0047, 0017, 0051, 0135, 0032 Minutz 0021 Mitsubishi 0093, 0150, **1250**, 0178 Monivision 0843, 0700 Motorola 0835, 0093, 0055 Moxell 0835 MTC 0060, 0030, 0185 Multitec...

lang:en score:20 filesize: 594.59 K page_count: 10 document date: 2019-07-24



[\[pdf\]](#) User Manual Guide Diagram

Motorola DRC800 fm Bgraham Press this Tip To DVD VCR 4 in 1 Note TV mechanical optical manual or otherwise without the prior written permission of MOTOROLA and stylized M logo are registered trademarks US Universal Remote Control User Guide OVERVIEW Your new universal remote operates your other manufacturer 39 s cable set transmitted transcribed stored any retrieval system translated to language form by means electronic residential wavebroadband resources support docs

Motorola DRC800 4-in-1 Universal Remote Control User Guide OVERVIEW Your new Motorola DRC800 univers ... , 0250, 0463, 0150, 0178, 0179, 0016 0150, 0030, 0178 0047, 0017, 0051, 0135, 0032 0021 0093, 0150, **1250**, 0178 0843, 0700 0835, 0093, 0055 0835 0060, 0030, 0185 0180 0156, 0178, 0866 0030, 1704, 0056 ...


lang:en score:19 filesize: 173.6 K page_count: 2 document date: 2011-10-15



[Potenza ST Universal Remote Control User Guide](#)

Comprehensive user guide for the Potenza ST Universal Remote Control by Universal Electronics, detailing setup, programming, features, and troubleshooting for various home entertainment devices.

lang:tl score:19 filesize: 957.1 K page_count: 27 document date: 2012-05-10



[\[pdf\] User Manual Guide Diagram](#)

Provided by ManualsAndMore Download User Manual Motorola DRC800 motorola drc800 user manual 1 manualsandmore |||

Motorola DRC800 4-in-1 Universal Remote Control User Guide OVERVIEW Your new Motorola DRC800 univers ... , 0250, 0463, 0150, 0178, 0179, 0016 0150, 0030, 0178 0047, 0017, 0051, 0135, 0032 0021 0093, 0150, **1250**, 0178 0843, 0700 0835, 0093, 0055 0835 0060, 0030, 0185 0180 0156, 0178, 0866 0030, 1704, 0056 ...

lang:en score:19 filesize: 166.93 K page_count: 2 document date: 2019-07-23



[Jensen JMC-1250 Bluetooth Stereo Turntable System User Manual](#)

Comprehensive user manual for the Jensen JMC-1250 Bluetooth 3-speed stereo turntable and 3 CD changer music system with dual cassette deck. Includes setup, operation, safety, maintenance, and troubleshooting.

lang:en score:19 filesize: 1.81 M page_count: 12 document date: 2015-03-17



[pdf] User Manual Installation Guide Instructions

JMC 1250 English UM USA 0514 Miriam USER MANUAL 1250USER 1250A198lo3hIKLm media amazon images I A198lo3hIKL ref dp product quick view |||

BLUETOOTH 3-SPEED STEREO TURNTABLE 3 CD CHANGER MUSIC SYSTEM WITH DUAL CASSETTE DECK USER MANUAL JMC-1250 PLEASE READ THIS USER MANUAL COMPLETELY BEFORE OPERATING THIS UNIT AND RETAIN THIS BOOKLET FOR FUTURE REFERENCE. WARNING TO PREVENT FIRE OR SHOCK HAZARD, DO NOT USE THIS PLUG WITH AN EXTENSION C...

lang:en score:19 filesize: 1.82 M page_count: 12 document date: 2017-08-07



[pdf] User Manual Installation Guide Instructions


Microsoft Word JMC 1250P English UM USA 0416 CWL USER MANUAL 1250 Spectra Merchandising Please read this user manual completely before operating unit and retain booklet for future reference PLEASE READ THIS COMPLETELY BEFORE OPERATING UNIT AND RETAIN BOOKLET FOR FUTURE REFERENCE EIB spectraintrl images stories jn

BLUETOOTH 3-SPEED STEREO TURNTABLE 3 CD CHANGER MUSIC SYSTEM WITH DUAL CASSETTE DECK USER MANUAL JMC-1250 PLEASE READ THIS USER MANUAL COMPLETELY BEFORE OPERATING THIS UNIT AND RETAIN THIS BOOKLET FOR FUTURE REFERENCE. P WARNING TO PREVENT FIRE OR SHOCK HAZARD, DO NOT USE THIS PLUG WITH AN EXTENSI...

lang:en score:19 filesize: 3.09 M page_count: 26 document date: 2016-04-13

[pdf] User Manual Guide Diagram

Motorola DRC800 fm Bgraham Press this Tip To DVD VCR 4 in 1 Note TV Controls type of device mechanical optical manual or otherwise without the prior written permission MOTOROLA and stylized M logo are registered trademarks US Universal Remote Control User Guide OVERVIEW Your new universal remote operates your other manufacturer s cable set The will now control you selected Step If did not perform function pressed repeat step 3 to retry previous code that worked case must re AUDIO See Checking Codes for more information on noting sets CHECKING CODES any user serviceable parts Opening except battery cover may cause permanent damage No part publication be reproduced transmitted transcribed stored retrieval system translated language form by means electronic 39 top box up three devices In addition provides 0037 Noblex 0240 Olympus 0035 Optimus 0162 0048 0104 0432 Orion 0184 0209 0002 1479 0479 Panasonic 1035 0616 0225 Penney 0042 0038 1237 Pentax Philco Philips UniversalRemote DRC800RemoteCodes drc800 guide motorolaDRC800 SupportArticle1519 GETBINARY xbin ID 1519 remotecodelist remotes motorola atmc Images ATMC facebook site images support controls mediacomcc custhelp euf assets documents guides eplusbroadband broadband resources cablevision qc ca fr Television fpb cc sectv Web andycable rushmore products Remotes charter 80 customers Visitors wavebroadband img manuals en DRC 800 |||



Motorola DRC800 4-in-1 Universal Remote Control User Guide OVERVIEW Your new Motorola DRC800 univers ... , 0250, 0463, 0150, 0178, 0179, 0016 0150, 0030, 0178 0047, 0017, 0051, 0135, 0032 0021 0093, 0150, 1250, 0178 0843, 0700 0835, 0093, 0055 0835 0060, 0030, 0185 0180 0156, 0178, 0866 0030, 1704, 0056 ... lang:en score:19 filesize: 193.96 K page_count: 2 document date: 2004-01-29




[\[pdf\]](#) Guide

Nebula Potenza ST fm Page 1 Monday October 15 2007 4 55 Users Guide Control Universal Remote PREPROGRAMMED FOR YOUR SET TOP BOX PM RemoteUCnoivnetrosal User for Electronics experiencemosaic 2020 03 |||

Potenza ST Potenza ST Universal RemoteUCnoivnetrosal Remote Control Users Guide Users Guide For mor ... 20 1189 1390, 1627 0701, 0820, 0840 0702 1229, 1629, 1841, 1933 1370 0531 1189, 0189 1352 1389 0080 **1250** 1414 1360, 0004, 1142 1801 1517 1532 0110, 0189, 0891, 1304, 1306 1801 0135, 1298, 1320 0110, 1...

lang:en score:19 filesize: 3.36 M page_count: 56 document date: 2013-04-24



[URC9700 Universal Remote Control User Manual](#)

User manual for the URC9700 universal remote control, providing instructions on setting up TVs and audio devices, button functions, volume lock/unlock, and direct code entry.

lang:en score:18 filesize: 2.49 M page_count: 2 document date: 2019-03-21




[\[pdf\]](#) User Manual

Manual Effects dingens2k Replica User t rex effects s |||


USER MANUAL REPLICA HELLO HELLO, HELLO... and congratulations on your purchase of Replica, the w ... H x D Weight excl. battery and packaging Higher than 1 M ohm Lower than 1 K ohm External 12V DC, -**1250** mA power supply. Runs on 100/115/230V AC/50-60Hz depending on the country 10,8V DC 12,5V DC 113...

lang:en score:18 filesize: 1.68 M page_count: 5 document date: 2014-08-04



[\[pdf\]](#) User Manual Guide Diagram


Provided by ManualsAndMore Download User Manual Motorola DRC800 manualsandmore |||
Motorola DRC800 4-in-1 Universal Remote Control User Guide OVERVIEW Your
new Motorola DRC800 univers ... , 0250, 0463, 0150, 0178, 0179, 0016 0150, 0030,
0178 0047, 0017, 0051, 0135, 0032 0021 0093, 0150, **1250**, 0178 0843, 0700 0835,
0093, 0055 0835 0060, 0030, 0185 0180 0156, 0178, 0866 0030, 1704, 0056 ...
lang:en score:18 filesize: 191.46 K page_count: 2 document date: 2019-07-23



[Trio Vision Universal Remote Control Programming Guide with Setup Codes](#)


Comprehensive guide for programming Trio Vision universal remote controls,
including detailed instructions for TV and Master Power setup, and extensive brand
setup codes for televisions, DVD players, VCRs, audio devices, cable boxes, and
satellite receivers.

lang:en score:18 filesize: 910.83 K page_count: 20 document date: 2016-04-21



[\[pdf\]](#) User Manual Owner's Manual


Owner Manual Toaster da Whirlpool 1250 Watt 2 skivers model 5KMT2204 2500 4 5KMT4205 bem/ErK
Hvis netledningen beskadiges skal den af hensyn til sikkerheden udskiftes 6GTNY0 TOASTER
W10506383A complete FINAL DK whirlpool content dam emea kitchenaid document owner manual |||
Model 5KMT2204 Model 5KMT4205 Toaster vejledning Indhold TOASTER
SIKKERHED Vigtige sikkerhedsforsk ... e personskade, brand eller elektrisk std.
Spnding: 220-240 Volt Frekvens: 50/60 Hertz Wattforbrug: **1250** Watt 2-skivers model
5KMT2204 2500 Watt 4-skivers model 5KMT4205 BEMRK: Hvis netledningen b...
lang:da score:18 filesize: 2.21 M page_count: 14 document date: 2025-02-24



[Motorola DRC800 4-in-1 Universal Remote Control User Guide](#)

This guide provides instructions for setting up and using the Motorola DRC800 4-in-1 Universal Remote Control, compatible with most cable set-top boxes and other entertainment devices. Learn about button functions, programming methods, volume lock, and device key reassignment.


lang:en score:18 filesize: 572.6 K page_count: 10 document date: 2016-12-29



[\[pdf\] User Manual Guide](#)

Provided by ManualsAndMore Download User Manual Layer3 TV URC9700 manualsandmore ||| URC9700 User Manual Button map TV: Powers ON and Off your TV VOLUME: Controls and mutes TV volume ... 14, 1757 1868 0178 1927, 1924, 0178, 0150, 1570, 1670, 1671, 1892, 0178, 0150 0017, 0051 1603, 1990 **1250**, 0178, 0150, 1797 0060 0180 0156, 0178 3382, 2104, 2735, 3423, 4093 1398, 1797 1755 2183 0178 1...


lang:en score:17 filesize: 1.92 M page_count: 2 document date: 2019-07-24



[Motorola DRC800 4-in-1 Universal Remote Control User Guide](#)

User guide for the Motorola DRC800 4-in-1 Universal Remote Control, detailing its features, setup, programming, and troubleshooting.

lang:en score:17 filesize: 167.41 K page_count: 2 document date: 2021-01-29




[\[pdf\] User Manual](#)

Provided by ManualsAndMore Download User Manual Onkyo HT R640 Supplementary HTR640 manualsandmore |||

Remote Control Codes 1. While holding down the REMOTE MODE button that you want to set, press the ... 154, 0463, 0150, 0009 0001 0037 0625 0150, 0030 0047, 0017, 0051 0487 0154, 0250, 0236, 0180, 0150, **1250**, 0030, 0108, 0056, 0512, 0836, 1150, 1171, 1182 0700 0060, 0030, 0056, 0512 0051, 0264, 0226, 0...

lang:it score:17 filesize: 237.18 K page_count: 12 document date: 2019-07-23




[pdf] User Manual

Provided by ManualsAndMore Download User Manual Onkyo TX SR604 Code TXSR604

manualsandmore |||

Remote Control Codes 1. While holding down the REMOTE MODE button that you want to set, press the ... 154, 0463, 0150, 0009 0001 0037 0625 0150, 0030 0047, 0017, 0051 0487 0154, 0250, 0236, 0180, 0150, **1250**, 0030, 0108, 0056, 0512, 0836, 1150, 1171, 1182 0700 0060, 0030, 0056, 0512 0051, 0264, 0226, 0...

lang:it score:17 filesize: 245.17 K page_count: 12 document date: 2019-07-23




[pdf] User Manual

Provided by ManualsAndMore Download User Manual Onkyo HT R940 Supplementary HTR940

manualsandmore |||

Remote Control Codes 1. While holding down the REMOTE MODE button that you want to set, press the ... 154, 0463, 0150, 0009 0001 0037 0625 0150, 0030 0047, 0017, 0051 0487 0154, 0250, 0236, 0180, 0150, **1250**, 0030, 0108, 0056, 0512, 0836, 1150, 1171, 1182 0700 0060, 0030, 0056, 0512 0051, 0264, 0226, 0...

lang:it score:17 filesize: 240.4 K page_count: 12 document date: 2019-07-23



[pdf] User Manual

Provided by ManualsAndMore Download User Manual RCA RCRH02BR Code List manualsandmore |||

TV Codes / Cdigos de TV Admiral.....
..... 0000, 0017, 0051 Mitsubishi **1250**, 0093,
0150, 0178 Motorola.....

lang:tl score:17 filesize: 68.39 K page_count: 1 document date: 2019-07-23



[pdf]

2 Keven Hass Marriner Marketing Mixed use development continues to increase due market pressures
Gaylord s Industries ventilation systems are known for their Lori Jensen Specialist Direct 971 223 1250
800 547 9696 ext lori jensen@gaylordventilation gaylordventilation Eliminator is the first 10900 SW Avery
Street Tualatin OR 97062 jensen@gaylord A First of It Kind hobartcorp sites default files |||
Lori Jensen Marketing Specialist Direct: 971.223.1250 800.547.9696 ext.1250
lori.jensen gaylordventilation.com www.gaylordventilation.com Gaylord s Eliminator is
the first ventilator of its kind and is designed to meet the growing need for smoke and
odor abatement especially where space is at a prem...
lang:en score:17 filesize: 268.85 K page_count: 2 document date: 2019-11-20

[pdf] User Manual

USER MANUAL ROOM MATE American Musical CONGRATULATIONS on your purchase of the new
Room Mate gold standard in tube driven reverb for guitarists now improved! marries cutting edge digital
technology and superior ana logue craftsmanship to deliver a superb vintage sound TRX ROOMATE
Manual americanmusical ItemFiles

USER MANUAL ROOM-MATE CONGRATULATIONS on your purchase of the new
Room-Mate, the gold standard in ... ODE, HICUT and GAIN SPRING, ROOM, HALL
and LFO Input Output left right inch standard 12V DC, **1250** mA external power
supply. Runs on 100/115/230V AC/50 60Hz, dependent on country 12V DC, 330
mA,...

lang:en score:17 filesize: 958.08 K page_count: 5 document date: 2013-11-07

