PRETTYCARELIFE P1-Pro-ZY

PRETTYCARELIFE P1-Pro Cordless Vacuum Cleaner

User Instruction Manual

Introduction

Thank you for choosing the PRETTYCARELIFE P1-Pro Cordless Vacuum Cleaner. This powerful and versatile stick vacuum is designed to provide efficient cleaning for various surfaces in your home. With its brushless motor, LED touch display, and long runtime, it offers a convenient and effective cleaning experience. Please read this manual thoroughly before operation to ensure proper use, maintenance, and longevity of your appliance.

Product Overview & What's Included

The PRETTYCARELIFE P1-Pro comes with a comprehensive set of components to meet your cleaning needs. Familiarize yourself with each part before assembly.




Figure 1: All included components of the PRETTYCARELIFE P1-Pro Cordless Vacuum Cleaner, including the main engine, self-stand powerful brush, 2-in-1 brush, crevice nozzle, HPC filter screen, power adapter, wall bracket, and adjustable metal tube.

Included Components:

- P1-Pro Vacuum Cleaner Mainframe x1
- 1.2L Large Dust Container x1
- Rotatable LED brush head x1
- Wall Mount Tool x1
- Filter Cottons x2
- Metal Filter x1
- 2 in 1 Brush x1
- Crevice Nozzle x1
- Adjustable Extension Tube x1
- Instruction Manual x1

Setup

Follow these steps to assemble your vacuum cleaner and prepare it for first use.

1. **Unpack All Components:** Carefully remove all parts from the packaging and ensure all listed components are present.
2. **Attach the Extension Tube:** Connect the adjustable extension tube to the main vacuum cleaner mainframe until it clicks securely into place.
3. **Attach the Brush Head:** Connect the rotatable LED brush head to the other end of the extension tube. Ensure it is firmly attached.
4. **Charge the Battery:** Before first use, fully charge the vacuum cleaner. Connect the power adapter to the charging port on the mainframe and plug it into a wall outlet. The LED display will indicate charging status.
5. **Install Wall Mount (Optional):** If desired, use the provided wall mount tool to install the vacuum for convenient storage and charging.



Figure 2: The PRETTYCARELIFE P1-Pro Cordless Vacuum Cleaner shown with its main components and various attachments, illustrating its modular design for easy assembly.

Operating Instructions

Your P1-Pro vacuum cleaner offers powerful and flexible cleaning for various surfaces.

Power On/Off & Suction Modes:

- To power on, press the power button on the LED touch display.
- The vacuum features 3 suction modes:
  - **MAX Mode (38KPa):** Provides maximum suction for deep cleaning and stubborn dirt, lasting up to 15 minutes.
  - **MID Mode (23KPa):** Balanced suction for everyday cleaning, offering up to 30 minutes of runtime.
  - **MIN Mode (16KPa):** Ideal for light cleaning and extended runtime, up to 45 minutes.
- Adjust suction levels by tapping the appropriate control on the LED touch display.



Figure 3: The intuitive LED touch display allows for easy monitoring of battery life and selection of the three distinct suction modes (Max, Mid, Min) for optimized cleaning.

Versatile Cleaning:

- **Floor & Carpet Brush:** The rotatable LED brush head is designed for both hard floors and low-pile carpets, effectively capturing debris, dust, crumbs, and pet hair. The integrated LED lights illuminate dark areas, ensuring no spot is missed.



Figure 4: The advanced brush head features smart anti-tangle technology, making it suitable for various flooring types including low-pile carpet, tile, cement, and wood floors.

- **Handheld Conversion:** Easily convert the upright vacuum into a lightweight handheld unit for cleaning crevices, ledges, blinds, and furniture. Use the 2-in-1 brush or crevice nozzle for targeted cleaning.



Figure 5: The main body detaches to become a convenient handheld vacuum, perfect for upholstery, car interiors, and hard-to-reach areas.

Self-Standing Design:

The P1-Pro features a self-standing design, allowing you to conveniently park it anywhere without needing to lean it against a wall or use a wall mount. This design also facilitates easy storage.



Figure 6: The self-standing feature allows the vacuum to remain upright on its own, providing convenient temporary storage during cleaning tasks.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dust Container:

- The 1.2L large dust container should be emptied regularly, especially when the MAX fill line is reached.
- To empty, detach the dust container from the mainframe. Position it over a trash bin and press the release button to open the bottom flap, allowing debris to fall out.

Cleaning the Filter System:

- The 5-stage filtration system effectively separates dust particles. To maintain suction power, it is recommended to clean and replace the filters regularly.

- The HEPA filter and metal filter are easily removable for cleaning. Tap off loose dirt or rinse with water. Ensure filters are completely dry before reinserting.



Figure 7: The transparent dust container allows visibility of the filter system, indicating when cleaning or emptying is required. The image shows the filter components clearly.

TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No Power / Does not turn on	Battery is not charged or not properly installed.	Ensure the battery is fully charged and correctly inserted into the mainframe.
Weak Suction Power	Dust container is full; filters are clogged; brush head is blocked.	Empty the dust container. Clean or replace the filters. Check the brush head for any obstructions (hair, debris) and clear them.
Vacuum stops during operation	Battery low; overheating.	Recharge the battery. Allow the vacuum to cool down for at least 30 minutes before resuming use.

SPECIFICATIONS

Feature	Detail
Brand	PRETTYCARELIFE
Model Name	P1-Pro-ZY
Special Feature	38Kpa Powerful Suction, Up to 45 mins Long Runtime, Maneuverable Brush Head with LED lights, 4lbs Ultra-Lightweight Main Body, LED Power Display, Suitable for Hardwood Floor & Low Pile Carpet, 99.99% High-efficient Filtration System, 3 Suction Mode, 17.3-24.4 inch Adjustable Tube, Washable Filter & Strainer, 6-in-1 Combinations
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	1.2 Liters
Wattage	150 watts
Runtime	45 minutes
Maximum Suction	1.02 Inches
Form Factor	Stick
Color	Gray
Product Dimensions	9.8"L x 7.8"W x 42"H
Item Weight	5.09 pounds
Number of Speeds	3

Feature	Detail
Control Method	Touch

Warranty and Support

For warranty information, technical support, or any inquiries regarding your PRETTYCARELIFE P1-Pro Cordless Vacuum Cleaner, please contact our customer service team. Refer to the contact information provided on our official website or the product packaging.
We are committed to providing high-quality products and excellent customer service.

© 2025 PRETTYCARELIFE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question