

[Manuals.plus](#) /

› [LocoLee](#) /

› LocoLee LED Light Kit for LEGO The Animated Series Gotham City 76271 - Standard Version Instruction Manual

LocoLee 76271

LocoLee LED Light Kit for LEGO The Animated Series Gotham City 76271

Standard Version Instruction Manual

INTRODUCTION

This instruction manual provides guidance for installing and operating your LocoLee LED Light Kit, designed specifically for the LEGO The Animated Series Gotham City 76271 model. This kit enhances your LEGO model with dynamic lighting effects. Please note that this product includes only the LED light kit; the LEGO model itself is not included and must be purchased separately or already owned.

SAFETY INFORMATION

Please read and understand all safety instructions before installation and use. This product contains small parts which may pose a choking hazard. Keep out of reach of small children to prevent accidental ingestion. Ensure all connections are secure and avoid excessive force when handling wires to prevent damage. Use only power sources with a voltage less than 5V.

PACKAGE CONTENTS

Verify that all components listed below are present in your package:

- LED Light Kit components (various high-brightness lights, light strips, connecting cables, expansion boards)
- USB Power Cable
- Instruction Manual (online access details)

Package List (NO LEGOS)




Image: Detailed view of the light kit components and accessories included in the package. Note: LEGO model is not included.

SETUP AND INSTALLATION

Installation of the LocoLee LED Light Kit requires careful attention. Detailed video and PDF installation instructions are available online. These instructions provide step-by-step guidance with numbered light bags to simplify the process.

1. **Access Instructions:** Refer to the website printed in the booklet included in your package. Enter the product code or LEGO model number (76271) to find the specific instructions.
2. **Pre-Assembly Test:** Before integrating the lights into your LEGO model, test each light component to ensure it is functioning correctly.
3. **Disassembly:** You will need to carefully disassemble a few bricks of your LEGO model to properly install the light fixtures.
4. **Wire Handling:** The light kit parts are small and designed to be flexible. However, avoid pulling wires too hard to prevent damage.
5. **Power Connection:** Connect the USB power cable to a power source (USB port, power bank, or battery pack).

Ensure the voltage is less than 5V. For optimal brightness, a USB power source is recommended over a battery pack (batteries are not included).

LED Light Kit Product Features


- 1-Light Effect Unique And Bright
- 2-Light Wires Flexible And Tough
- 3-Plug And Play
- 4-Multi Supply Methods
- 5-Step By Step Video Installation



Voltage less than 5V



Batteries not included



Installation Guide

- 1.Click the website printed in the booklet
 - 2.Enter the code behind the packing box or Lego model
 - 3.Click the picture to watch the video or PDF
- *.No Paper Instruction**

Image: Visual guide for accessing online instructions and various power supply options (USB, battery pack).

Your browser does not support the video tag.

Video: An official product video demonstrating the lighting effects of the kit installed in the LEGO The Animated Series Gotham City 76271 model.

OPERATING INSTRUCTIONS

Once installed, the LED light kit operates by simply connecting it to a compatible power source. There are no additional controls for the standard version; the lights will illuminate upon receiving power.

- **Power On:** Connect the USB power cable to a 5V or less power source.
- **Power Off:** Disconnect the USB power cable from the power source.



**Work With Lights
Glow Upgrade**

VS



**Work No Lights
Darkness Ordinary**

Image: A visual comparison demonstrating the enhanced appearance of the LEGO model with the LED light kit activated versus without lights.

LED Light Kit -Awesome Lighting Effects

Make a difference Fun for players/collectors




Image: Close-up views showcasing the detailed lighting effects on different sections of the Gotham City model, including the Batman symbol, police station, and other buildings.

MAINTENANCE

The LED light kit is designed for durability. To ensure longevity and optimal performance:

- **Cleaning:** Gently dust the lights and wires with a soft, dry cloth. Avoid using liquids or abrasive cleaners.
- **Handling:** While wires are flexible, avoid sharp bends or excessive pulling that could damage the internal connections.
- **Storage:** If storing the LEGO model with the light kit, ensure wires are not pinched or tangled.

TROUBLESHOOTING

If you encounter issues with your light kit, consider the following:

- **Lights Not Working:**
 - Check all power connections. Ensure the USB cable is securely plugged into both the light kit and the power source.
 - Verify the power source is active and providing power (e.g., try a different USB port or power adapter).
 - Confirm the voltage of your power source is 5V or less.
 - Inspect individual light components and wires for any visible damage or disconnections.
- **Dim Lights:**
 - If using a battery pack, ensure batteries are fresh and correctly inserted. USB power typically provides brighter illumination.
 - Ensure there are no loose connections causing power loss.

• **Flickering Lights:**

- Check for loose connections at the expansion boards or individual light points.
- Ensure the power source is stable.

If problems persist, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	LocoLee
Model Number	76271
Compatible LEGO Set	The Animated Series Gotham City 76271
Light Source Type	Light Emitting Diode (LED)
Power Source	USB or Battery Powered (Batteries not included)
Voltage	Less than 5 volts
Material	Plastic, Copper lines
Mounting Type	Internal Mount (within LEGO model)
Number of Light Sources	10

WARRANTY AND SUPPORT

LocoLee products undergo quality checks to ensure high standards. If you have any questions or encounter issues with your product, please do not hesitate to contact us via email at any time. We are committed to providing support and ensuring your satisfaction.

© 2024 LocoLee. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D1V1PCF8>

More documents and user manuals: <https://manuals.plus/>