

TIMEX TW4B30800

Timex Expedition Field Solar Watch TW4B30800 User Manual

Model: TW4B30800

1. INTRODUCTION

Thank you for choosing the Timex Expedition Field Solar Watch, Model TW4B30800. This timepiece combines reliable analog quartz movement with solar charging technology, offering a durable and functional accessory for daily wear and outdoor activities. This manual provides essential information for the proper setup, operation, and maintenance of your watch.

2. PRODUCT OVERVIEW

The Timex Expedition Field Solar Watch features a robust design with a focus on readability and durability. Key components include the watch case, dial, hands, crown, and silicone strap.



Figure 2.1: Front view of the Timex Expedition Field Solar Watch, showcasing the black dial, white Arabic numerals, and luminescent hour and minute hands. The watch features a silver-tone case and a black silicone strap.



Figure 2.2: Side profile of the watch, highlighting the 43mm metal case and the textured crown located on the right side.



Figure 2.3: Rear view of the watch, displaying the stainless steel case back and the black silicone strap with its buckle closure.



Figure 2.4: Detailed view of the watch's case back, engraved with "TIMEX", "STAINLESS STEEL BACK", "WR50 METERS", and "CR2016 CELL".



Figure 2.5: Angled rear perspective, providing a clearer view of the watch's buckle mechanism and the texture of the silicone strap.



Figure 2.6: The watch displayed on a wrist, illustrating its proportional fit and overall aesthetic when worn.

3. SETUP

3.1 Initial Charging

Your Timex Expedition Field Solar Watch is powered by light. Before initial use, or if the watch has stopped, expose the dial to a strong light source (natural sunlight is ideal) for several hours. A full charge can last up to 4 months in darkness.

3.2 Setting the Time

1. Pull the crown (the knob on the side of the watch) out to the furthest position.
2. Rotate the crown in either direction to set the hour and minute hands to the correct time.
3. Once the time is set, push the crown back in to its original position. The watch will begin to run.

4. OPERATING INSTRUCTIONS

4.1 Timekeeping

The watch continuously displays the current time (hours, minutes, seconds) once properly set and charged.

4.2 Water Resistance

This watch is water resistant to 50 meters (165 feet). This rating means it is suitable for short periods of recreational swimming. It is **not** suitable for diving, snorkeling, or prolonged water immersion. Avoid operating the crown while the watch is wet or submerged.

4.3 Luminescent Hands and Markers

The hands and dial markings are treated with a luminescent material that absorbs light and glows in low-light conditions. Exposure to bright light will enhance the glow.

5. MAINTENANCE

5.1 Cleaning

To clean your watch, wipe the case and strap with a soft, damp cloth. For the silicone strap, mild soap and water can be used, then rinse thoroughly and dry. Avoid harsh chemicals or abrasive materials.

5.2 Maintaining Charge

To ensure continuous operation, regularly expose your watch to light. While it can hold a charge for up to 4 months in darkness, consistent exposure to ambient light will keep it fully powered.

5.3 Storage

When storing the watch for extended periods, place it in an area where it can receive some light to prevent the charge from depleting completely.

6. TROUBLESHOOTING

- **Watch has stopped or is running intermittently:** This indicates a low charge. Expose the watch dial to a strong light source for several hours to recharge the solar cell.
- **Time is incorrect:** Refer to Section 3.2 "Setting the Time" to reset the watch to the correct time.
- **Condensation under crystal:** If condensation appears and does not dissipate quickly, this may indicate a breach in water resistance. Contact Timex customer support for assistance.

7. SPECIFICATIONS

Model Number	TW4B30800
Movement Type	Analog Quartz (Solar Powered)
Case Material	IP Steel / Low Lead Brass
Case Diameter	43 mm
Case Thickness	11 mm
Band Material	Silicone

Band Width	20 mm
Water Resistance	50 meters (165 feet)
Power Reserve	Up to 4 months (fully charged)
Lens Material	Mineral Glass
Item Weight	157 g

8. WARRANTY AND SUPPORT

Your Timex watch is covered by a limited warranty against manufacturing defects. For specific warranty terms and conditions, please refer to the warranty card included with your purchase or visit the official Timex website. For customer support, service, or inquiries, please contact Timex directly through their official website or the contact information provided in your product packaging.

Official Timex Website: www.timex.com