WolfLawS X3

X3 Wireless Gaming Headset User Manual

Model: X3

Brand: WolfLawS

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your WolfLawS X3 Wireless Gaming Headset. Designed for multi-platform compatibility, the X3 headset offers superior sound quality and comfort for extended gaming sessions. Please read this manual thoroughly to ensure optimal performance and longevity of your device.



Figure 1: WolfLawS X3 Wireless Gaming Headset, showcasing its sleek black and green design with the included 2.4GHz dongle.

What's in the Box

- X3 Headset
- 2.4GHz Dongle
- Charge Cable (USB-C)
- User Manual (this document)

Product Features

- **Multi-Platform Compatibility:** Equipped with both 2.4GHz wireless and Bluetooth dual modes for seamless

connection to Xbox controllers (official controllers only), PC, PS5, laptops, Mac, and Nintendo Switch.

- **Outstanding Sound Quality:** Features 50mm speakers and cutting-edge 3D surround sound technology for immersive audio.
- **Noise-Canceling Microphone:** Guarantees crystal-clear communication with teammates.
- **Long-lasting Battery Life:** Up to 60 hours of play on a single charge, with a quick full recharge in just 2.5 hours.
- **Minimal Latency:** Low-latency technology (<20ms) delivers instantaneous audio feedback.
- **Humanized Design:** Ergonomically crafted for superior comfort with luxurious air protein over-ear pads and adjustable headbands.
- **Effortless Control:** Conveniently located buttons for volume adjustment, microphone mute, and mode switching.

Setup & Connection

1. 2.4GHz Wireless Connection (Xbox, PS5, PC, Laptop)

The X3 headset utilizes a 2.4GHz dongle for a stable, low-latency wireless connection. This method is recommended for gaming on compatible consoles and PCs.

1. **For Xbox Controllers:**
    - Ensure your Xbox console and controller are powered on.
    - Plug the 2.4GHz dongle firmly into the bottom port of your Xbox controller. Ensure it is fully inserted to avoid audio issues.
    - Power on the X3 headset by holding the Power Button for 3 seconds. The blue indicator light on the headset will flash.
    - The dongle's blue light will also flash and then become solid once connected. The headset will automatically pair with the dongle.
    - Adjust the headset volume using the volume wheel on the headset.
2. **For PS5, PC, Laptops:**
    - Plug the 2.4GHz dongle into an available USB port on your PS5, PC, or laptop. The USB connector extends from the dongle.
    - Power on the X3 headset by holding the Power Button for 3 seconds. The blue indicator light on the headset will flash.
    - The dongle's blue light will also flash and then become solid once connected. The headset will automatically pair with the dongle.
    - Ensure the headset is set to 2.4GHz mode (refer to "Operating Instructions" for mode switching).
    - Adjust audio output settings on your device (PS5, PC, laptop) to use the X3 headset as the primary audio device.



Figure 2: Proper insertion of the 2.4GHz dongle into an Xbox controller. Ensure a tight and full connection to prevent audio issues.




Figure 3: Overview of the X3 headset's multi-connection modes, including 2.4GHz USB Dongle and Bluetooth Mode compatibility.

2. Bluetooth Mode (Mac, Tablet, Mobile, Switch)

For devices supporting Bluetooth audio, the X3 headset can connect wirelessly via Bluetooth 5.3.

1. Power on the X3 headset by holding the Power Button for 3 seconds.
2. Hold the 2.4GHz/Bluetooth Mode button for 2 seconds to switch to Bluetooth mode. The indicator light will turn blue and flash rapidly, indicating pairing mode.
3. On your device (Mac, tablet, mobile, Nintendo Switch), navigate to Bluetooth settings and select "X3 Headset" from the list of available devices.
4. Once paired, the blue indicator light on the headset will become solid.

Operating Instructions (Controls)

The X3 headset features intuitive controls located on the earcups for easy access during gameplay.



Figure 4: Detailed view of the easy function buttons on the X3 headset for user-friendly control.

- **Mic On/Off Button:** Press to toggle the microphone on or off.
- **2.4GHz/Bluetooth Modes Button:** Hold for 2 seconds to switch between 2.4GHz wireless mode and Bluetooth mode.
- **Power Button:** Hold for 3 seconds to power the headset on or off.
- **Volume Wheel:** Scroll up or down to adjust the audio volume.
- **Type-C Port:** Used for charging the headset.



Figure 5: The noise-canceling microphone of the X3 headset, designed to pick up sound clearly and accurately.

Charging

To charge your X3 Wireless Gaming Headset:

1. Connect the included USB-C charge cable to the Type-C port on the headset.
2. Connect the other end of the cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
3. The headset will fully charge in approximately 2.5 hours, providing up to 60 hours of play time.



Figure 6: Visual representation of the X3 headset's impressive 60-hour battery life and 2.5-hour charging time.

Maintenance

- Clean the headset regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- Do not attempt to disassemble or modify the headset, as this will void the warranty.
- Keep the dongle and charging cable free from dust and debris.

Troubleshooting

Problem	Possible Cause / Solution

Problem	Possible Cause / Solution
Cannot connect the headset with controller / Headset doesn't work.	Confirm if you are in Bluetooth Mode or 2.4GHz Mode. The 2.4GHz dongle cannot be connected in Bluetooth mode. You need to switch to 2.4GHz mode. Ensure the dongle is fully and tightly inserted into the controller.
No sound from the Headset / Headset Volume too low.	Make sure the (Headset Volume) on the Xbox console is set to maximum. When using the headset for the first time, the default volume on the console might be 80%. Please insert the dongle tightly and fully. Check the volume wheel on the headset.
Microphone not working.	Ensure the Mic On/Off button is set to 'On'. Check your device's audio input settings to ensure the X3 headset microphone is selected.
Audio skipping or intermittent sound.	Ensure the 2.4GHz dongle is fully inserted. Move closer to the dongle/device to reduce interference. Check for other wireless devices that might be causing interference.

Specifications

Feature	Detail
Model Name	X3
Brand	WolfLawS
Connectivity Technology	Wireless (2.4GHz / Bluetooth 5.3)
Wireless Communication Technology	2.4GHz/Bluetooth 5.3
Compatible Devices	Xbox Series X|S, Xbox One, PS5, PS4, PC, Mac, Switch, GameBoy
Audio Driver Type	Dynamic Driver (50mm speakers)
Noise Control	Sound Isolation
Microphone	Noise-Canceling, 120° Adjustable
Battery Life	Up to 60 Hours
Charging Time	2.5 Hours
Audio Latency	<20 Milliseconds
Earpiece Shape	Over-ear
Material	Plastic (with air protein over-ear pads)
Color	Black and Green
Item Weight	0.085 ounces

Warranty & Support

For warranty information, technical support, or any inquiries regarding your WolfLawS X3 Wireless Gaming Headset, please refer to the contact details provided on the product packaging or visit the official WolfLawS website. Keep your

proof of purchase for warranty claims.

© 2025 WolfLawS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question