

[manuals.plus](#) /› [Samsung](#) /› [Samsung 50 Inch DU8000 Crystal UHD LED 4K Smart TV Instruction Manual \(2024 Model\)](#)

Samsung DU8000

Samsung 50 Inch DU8000 Crystal UHD LED 4K Smart TV Instruction Manual

Model: DU8000 (2024 Model)

1. IMPORTANT SAFETY INFORMATION

Before using your new Samsung Smart TV, please read all safety instructions carefully to prevent electric shock, fire, or injury. Keep this manual for future reference.

- Do not expose the TV to rain or moisture.
- Ensure proper ventilation; do not block ventilation openings.
- Use only the power cord supplied by the manufacturer.
- Do not overload wall outlets or extension cords.
- Refer all servicing to qualified service personnel.

2. PRODUCT OVERVIEW

The Samsung DU8000 Crystal UHD LED 4K Smart TV offers a stunning visual experience with its 4K resolution and advanced picture technologies. Its sleek design integrates seamlessly into any living space.



Image: Front view of the Samsung DU8000 Crystal UHD LED 4K Smart TV, showcasing its vibrant display with an underwater scene.

Key Features:

- **Crystal UHD 4K Processor:** Enhances content to 4K resolution.
- **Dynamic Crystal Color:** Delivers a wide spectrum of colors for a lifelike picture.
- **Motion Xcelerator:** Provides smooth motion for clear details in fast-paced scenes.
- **AirSlim Design:** Ultra-thin profile for seamless wall mounting.
- **Smart TV Powered by Tizen:** Access to a vast array of streaming apps and services.

3. SETUP

3.1 Unboxing and Initial Inspection

Carefully remove the TV from its packaging. Inspect for any damage. Ensure all components listed in the packing list are present.

3.2 Stand Installation

If using the included stand, attach the stand feet to the bottom of the TV using the provided screws. Ensure they are securely fastened.

3.3 Wall Mounting (Optional)

For wall mounting, a compatible VESA wall mount (sold separately) is required. Follow the instructions provided with your wall mount. The TV's AirSlim design allows for a flush fit against the wall.




Image: The slim side profile of the Samsung DU8000 TV, demonstrating its AirSlim design for a sleek appearance.

3.4 Connecting Peripherals

Connect your devices (e.g., cable box, gaming console, Blu-ray player) to the HDMI ports. Use the USB ports for external storage or accessories. Connect the power cable to the TV and then to a wall outlet.



* Images are simulated and for illustration purposes only.

Image: The back panel of the Samsung DU8000 TV, illustrating the available connectivity ports for external devices.

3.5 Initial Power On and Network Connection

Press the power button on the remote. Follow the on-screen instructions to select your language, country, and connect to your Wi-Fi network. This step is crucial for accessing Smart TV features.

4. OPERATING INSTRUCTIONS

4.1 Remote Control Functions

The included remote control allows for easy navigation. Use the directional pad to move through menus, the 'Home' button to access the Smart Hub, and dedicated buttons for popular streaming services.

4.2 Smart Hub Navigation and App Management

The Smart Hub is your gateway to all applications, live TV, and connected devices. You can customize your app layout, add new apps from the app store, or remove unused ones.

Your browser does not support the video tag.

Video: This video demonstrates how to move and remove applications on your Samsung Smart TV, allowing for personalized organization of your home screen.


Your browser does not support the video tag.

Video: This video illustrates the various viewing options available on the Samsung Smart TV, including access to different streaming services and live TV channels.

4.3 Picture and Sound Settings

Access the settings menu to adjust picture modes (e.g., Standard, Dynamic, Movie), brightness, contrast, and color temperature. For audio, select sound modes or adjust equalizer settings for optimal listening.

- **Dynamic Crystal Color:** Provides a wide range of colors for a vibrant picture.
- **4K Upscaling:** Automatically enhances lower-resolution content to near 4K quality.
- **Motion Xcelerator:** Reduces motion blur in fast-moving scenes.
- **Contrast Enhancer:** Dynamically adjusts contrast for improved depth and color.
- **Filmmaker Mode:** Preserves the director's original vision for movies.



DYNAMIC CRYSTAL COLOR

Gorgeous color

One billion shades of color help produce greater detail on the screen. See more nuanced shades and tones that match real life.

Image: The Dynamic Crystal Color feature of the Samsung DU8000 TV, showing how it produces rich and detailed colors.



Motion Xcelerator

Experience clear motion and improved clarity.

Image: A motocross scene on the Samsung DU8000 TV, demonstrating the Motion Xcelerator feature for clear and fluid action.

Your browser does not support the video tag.

Video: An overview of the Samsung DU8000 Crystal UHD LED 4K Smart TV, highlighting its key features and sleek design.

Your browser does not support the video tag.

Video: This video showcases the ultra-slim design and stunning motion clarity of the Samsung 4K Smart TV, emphasizing its visual performance.

5. MAINTENANCE

5.1 Cleaning the TV

To clean the screen, gently wipe with a soft, dry microfiber cloth. For stubborn marks, lightly dampen the cloth with water or a screen-specific cleaning solution. Avoid harsh chemicals or abrasive materials. Clean the TV frame and stand with a soft, dry cloth.

5.2 Software Updates

Ensure your TV's software is up-to-date for optimal performance and security. Navigate to *Settings > Support > Software*

Update to check for and install available updates. Automatic updates can also be enabled.

5.3 Power Management

For energy efficiency, utilize the TV's power-saving modes. Unplug the TV from the power outlet during lightning storms or when it will be left unattended for long periods.

6. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions before contacting support.

- No Power:** Check if the power cable is securely connected to both the TV and the wall outlet. Test the outlet with another device.
- No Picture/Sound:** Verify the correct input source is selected. Check all cable connections (HDMI, audio). Restart connected devices.
- Remote Not Working:** Replace the batteries. Ensure there are no obstructions between the remote and the TV.
- Network Connection Issues:** Restart your Wi-Fi router. Reconnect the TV to the Wi-Fi network via *Settings > General > Network > Open Network Settings*.
- Picture Quality Issues:** Adjust picture settings (brightness, contrast, sharpness, color). Ensure the content source is high quality.
- Factory Reset:** As a last resort, a factory reset can resolve many software-related issues. Go to *Settings > General > Reset*. Note that this will erase all personalized settings and installed apps.

7. SPECIFICATIONS

Feature	Detail
Brand	Samsung
Model Number	E99SAMUN50DU8000
Screen Size	50 Inches
Display Technology	LED
Resolution	4K (3840 x 2160)
Refresh Rate	60 Hz
Special Features	AirSlim Design, 4K Upscaling, Motion Xcelerator, Dynamic Crystal Color, HDR10+, Contrast Enhancer, Filmmaker Mode
Connectivity Technology	Bluetooth, Wi-Fi
Product Dimensions (D x W x H)	9 x 48.5 x 29.4 inches
Item Weight	26 Pounds
Speaker Type	2CH

8. WARRANTY AND SUPPORT

8.1 Product Warranty

Your Samsung TV comes with a standard manufacturer's warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration. Additional protection plans may have been purchased separately.

8.2 Customer Support

For technical assistance, troubleshooting, or service requests, please visit the official Samsung support website or contact their customer service hotline. Have your TV's model number (DU8000) and serial number ready when contacting support. You can find more information and support resources on the [Samsung Store](#).