

[Manuals.plus](#) /

› [Atyhao](#) /

› Atyhao Stainless Steel Food Processor Model Atyhaogyvo751rt2 Instruction Manual

Atyhao Atyhaogyvo751rt2

Atyhao Stainless Steel Food Processor Model Atyhaogyvo751rt2 Instruction Manual

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient use of your Atyhao Stainless Steel Food Processor, Model Atyhaogyvo751rt2. Please read all instructions thoroughly before first use and retain this manual for future reference. This appliance is designed for chopping and grinding various food ingredients quickly and efficiently.



Image 1.1: Atyhao Stainless Steel Food Processor, fully assembled.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the appliance.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Unplug from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts. Keep hands and utensils out of the processing bowl while operating to prevent injury and damage to the food processor.
- Ensure the lid is securely locked in place before operating the appliance. The safety lock feature prevents operation if components are not correctly aligned.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.

- Do not use outdoors. This appliance is for household use only.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Close supervision is necessary when any appliance is used by or near children.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Atyhao Food Processor:

- **Motor Unit (Head):** Contains the motor and control buttons.
- **Lid:** Transparent lid with a safety lock mechanism.
- **5-Blade Assembly (Auger):** Sharp stainless steel blades for efficient chopping and grinding.
- **Stainless Steel Bowl (Cup):** 4-liter capacity processing bowl.
- **Anti-slip Mat:** Provides stability during operation.



Image 3.1: Exploded view of the Atyhao Food Processor components.



Image 3.2: All included components of the Atyhao Food Processor.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your food processor before use:

1. **Place the Anti-slip Mat:** Position the anti-slip mat on a clean, dry, and stable surface.
2. **Place the Stainless Steel Bowl:** Set the stainless steel bowl onto the anti-slip mat.
3. **Install the Blade Assembly:** Carefully place the 5-blade assembly onto the central shaft inside the bowl. Ensure it is seated correctly.
4. **Add Ingredients:** Place your desired ingredients into the stainless steel bowl. Do not overfill beyond the maximum capacity mark.
5. **Secure the Lid:** Place the transparent lid onto the bowl, aligning it properly. Rotate until it locks securely into place.
6. **Place the Motor Unit:** Position the motor unit onto the lid, ensuring the plum blossom connection port aligns and engages correctly. The unit will not operate if not properly assembled due to the safety lock feature.



Image 4.1: Step-by-step assembly guide for the food processor.

5. OPERATING INSTRUCTIONS

Once assembled, plug the food processor into a 110V power outlet. The appliance features two speed settings for versatile processing.

5.1. Speed Settings

The motor unit has control buttons for different speeds:

- **Speed 1:** For softer ingredients or coarser chopping (e.g., garlic, scallions, chili peppers).
- **Speed 2:** For harder ingredients or finer grinding (e.g., meat, peanuts, carrots, pumpkin).

Abrasion resistant, durable and powerful motor
Powerful motor with thick copper wires Long service life
Low noise operation




Image 5.1: Control buttons and suggested ingredient processing by speed.

5.2. Processing Food

Press and hold the desired speed button to operate. Release the button to stop. For best results, use short pulses rather than continuous operation, especially for delicate ingredients or to achieve a specific texture. Do not operate continuously for more than 30 seconds to prevent motor overheating. Allow a short break between cycles.

- **Meat Grinding:** For ground meat, process in short bursts until desired consistency is reached.
- **Vegetable Chopping:** Chop vegetables like garlic, chili, or celery.

All steel body
Food Accessible
Premium steel construction,
cooking for your family with
peace of mind.



Image 5.2: Examples of ingredients processed in approximately 6 seconds.



6 seconds to grind
Quick making of the filling,
no loosening of the meat



Dumpling making
Ready to eat, healthy and
safe

Image 5.3: Food processor used for quick meat grinding and dumpling preparation.

6. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and optimal performance of your food processor.

1. **Unplug:** Always unplug the appliance from the power outlet before cleaning.
2. **Disassemble:** Carefully remove the motor unit, then the lid, and finally the blade assembly from the bowl.
3. **Clean Bowl, Lid, and Blades:** The stainless steel bowl, lid, and blade assembly are recommended for hand washing. Use warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry immediately to prevent water spots or corrosion. Handle blades with extreme care as they are very sharp.
4. **Clean Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse the motor unit in water or any other liquid.
5. **Storage:** Ensure all parts are completely dry before reassembling or storing. Store the appliance in a dry place.

7. TROUBLESHOOTING

If you encounter any issues with your food processor, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; components not assembled correctly; safety lock not engaged.	Ensure the power cord is securely plugged into a 110V outlet. Verify the lid and motor unit are correctly aligned and locked into place.
Food is not processed evenly.	Too many ingredients; ingredients too large; insufficient processing time.	Reduce the quantity of ingredients. Cut larger ingredients into smaller, uniform pieces. Process for a longer duration or use short pulses.
Motor sounds strained or overheats.	Overloading; continuous operation for too long.	Do not exceed the maximum capacity. Use short pulses and allow the motor to rest between cycles. Unplug and let cool down if overheating occurs.
Blades are not rotating.	Blade assembly not installed correctly; obstruction.	Ensure the blade assembly is properly seated on the central shaft. Check for any large, hard pieces of food obstructing the blades.

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Brand	Atyhao
Model Name	Atyhaogyvo751rt2
Product Dimensions	13.38"D x 9.05"W x 9.05"H
Item Weight	3.49 pounds
Color	Stainless steel

Bowl Capacity	4 Liters
Number of Speeds	2
Power Source	Corded Electric (US Plug 110V)
Special Feature	Safety Lock
Recommended Uses	Chop, Grind (Meat, Vegetables, Garlic, etc.)
Included Components	Chopping Blade, Container (Bowl), Lid
Product Care Instructions	Hand Wash

9. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the documentation included with your purchase or visit the official Atyhao store online. You can find more information at the [Atyhao Store](#).

