

[Manuals.plus](#) /

> [taopodo](#) /

> User Manual for taopodo Bluetooth Speaker M10-BK

taopodo M10-BK

User Manual for taopodo Bluetooth Speaker M10-BK

Model: M10-BK | Brand: taopodo

1. PRODUCT OVERVIEW

The taopodo M10-BK is a portable wireless Bluetooth speaker designed to deliver high-definition sound. It features IPX5 waterproofing, ensuring durability against splashes and light rain, making it suitable for various environments. With up to 24 hours of playtime, it provides extended audio enjoyment. The speaker supports TWS (True Wireless Stereo) pairing for an enhanced stereo experience and utilizes Bluetooth 5.3 for stable and efficient connectivity.





Image: Front view of the taopodo M10-BK Bluetooth Speaker, showcasing its cylindrical design and integrated RGB lighting panel on the side.

2. PACKAGE CONTENTS

- taopodo M10-BK Bluetooth Speaker
- Charging Cable
- User Manual (this document)

3. SETUP AND INITIAL USE

3.1 Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the speaker's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will show the charging status and turn off when fully charged.

3.2 Powering On/Off

- To power on: Press and hold the **Power button** for approximately 3 seconds until you hear an audible prompt and the indicator light illuminates.
- To power off: Press and hold the **Power button** for approximately 3 seconds until you hear an audible prompt and the indicator light turns off.

3.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing blue light). If it's not flashing, briefly press the Bluetooth button to enter pairing mode.
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select **"taopodo M10-BK"** from the list of found devices.
4. Once connected, you will hear a confirmation sound, and the Bluetooth indicator light will remain solid blue.

The speaker will automatically attempt to reconnect to the last paired device when powered on, if that device is within range and has Bluetooth enabled.

4. OPERATING INSTRUCTIONS

4.1 Button Functions

Button	Function (Short Press)	Function (Long Press)
Power Button	Play/Pause (in Bluetooth mode), Answer/End Call	Power On/Off
"+" Button	Volume Up	Next Track
"-" Button	Volume Down	Previous Track
EQ Button	Cycle through EQ modes	(No function)
Light Button	Cycle through light modes	Turn lights On/Off

4.2 True Wireless Stereo (TWS) Pairing

TWS pairing allows you to connect two taopodo M10-BK speakers together for a true stereo sound experience.

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the **TWS button** (if available, or a combination of buttons as per specific model instructions, typically the Play/Pause button or a dedicated TWS button) for 2-3 seconds. The speaker will enter TWS pairing mode.
3. The primary speaker will automatically search for the secondary speaker. Once connected, you will hear a confirmation sound, and the indicator lights on both speakers will change to indicate a successful TWS connection.
4. Now, connect your device to the primary speaker via Bluetooth as described in Section 3.3. Audio will play through both speakers in stereo.

To disconnect TWS, press and hold the TWS button on either speaker again.

4.3 Using the Built-in Microphone

The speaker features a built-in microphone for hands-free calling. When a call comes in while connected via Bluetooth:

- Short press the **Power button** to answer the call.

- Short press the **Power button** again to end the call.
- Long press the **Power button** to reject an incoming call.

5. MAINTENANCE AND CARE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners, alcohol, or other chemical solvents, as these may damage the finish.
- **Water Resistance (IPX5):** The speaker is IPX5 waterproof, meaning it is protected against low-pressure water jets from any direction. It is resistant to splashes and light rain. **Do not submerge the speaker in water.** Ensure the charging port cover is securely closed before exposure to water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. If storing for a long period, charge the speaker to about 50% every few months.



Image: A person performing a yoga pose outdoors, with the taopodo M10-BK speaker visible in the lower right corner, illustrating its portability and suitability for various activities.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; Device Bluetooth off; Too far from device.	Ensure speaker is in pairing mode (flashing blue light). Turn on Bluetooth on your device. Move speaker closer to device (within 10 meters). Forget the device on your phone and try pairing again.

Problem	Possible Cause	Solution
No sound or low volume.	Volume too low on speaker or device; Speaker not connected.	Increase volume on both speaker and connected device. Ensure speaker is successfully paired.
Sound distortion.	Volume too high; Device too far; Interference.	Reduce volume. Move speaker closer to device. Avoid strong electromagnetic interference.
TWS pairing fails.	Speakers already connected to other devices; Too far apart.	Ensure both speakers are disconnected from other devices. Place speakers close to each other during TWS pairing.

7. SPECIFICATIONS

Feature	Detail
Model Name	M10-BK
Brand	taopodo
Connectivity Technology	Bluetooth 5.3
Special Feature	Built-in Microphone, IPX5 Waterproof, TWS Pairing, EQ Modes
Recommended Uses	For Surround Sound Systems, Home Use, Portable Audio
Controller Type	Button
Product Dimensions	3.54"D x 3.54"W x 8.07"H
Item Weight	7.2 ounces
Power Source	Battery Powered
Playtime	Up to 24 hours (varies with volume and content)



Bluetooth 5.3

Auriculares inalámbricos están equipados con los chips Bluetooth 5.3 de nueva generación

Image: A conceptual diagram illustrating a Bluetooth 5.3 chip, highlighting the advanced connectivity technology integrated into the speaker.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official taopodo website. Keep your purchase receipt as proof of purchase for warranty claims.

Contact Information: Please refer to the packaging or the official brand website for the most up-to-date contact details for customer service.

© 2024 taopodo. All rights reserved.
This manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D1X7ZCXY>

More documents and user manuals: <https://manuals.plus/>