

[manuals.plus](#) /

› [CCKHDD](#) /

› [Adjustable Multifunction Lid Opener User Manual](#)

**CCKHDD B0D1XTQRT7**

## Adjustable Multifunction Lid Opener User Manual

Model: B0D1XTQRT7 | Brand: CCKHDD

### INTRODUCTION

The CCKHDD Adjustable Multifunction Lid Opener is designed to provide an effortless solution for opening various types of lids and caps. Its adjustable jaw and ergonomic design make it particularly beneficial for individuals with arthritis, weak hand strength, or anyone seeking a more convenient way to open jars, bottles, and cans.

This manual provides detailed instructions on how to use and maintain your lid opener, ensuring optimal performance and longevity.

### PRODUCT OVERVIEW



Figure 1: Overview of the CCKHDD Multifunction Lid Opener and its applications.

The CCKHDD Multifunction Lid Opener features a durable stainless steel construction with an adjustable jaw mechanism. It integrates three primary functions: an adjustable jar opener, a bottle cap opener, and a can tab lifter. Its compact design allows for easy storage in any kitchen drawer.

## SETUP

The CCKHDD Adjustable Multifunction Lid Opener requires no assembly or complex setup. It is ready for immediate use upon unboxing.

## OPERATING INSTRUCTIONS

## 1. Opening Jar Lids

- Positioning:** Place the adjustable jaw of the opener around the lid of the jar. Ensure the teeth of the opener firmly grip the lid's edge.
- Adjusting:** Rotate the handle to adjust the jaw size until it securely fits the lid. The opener is designed to accommodate lids from approximately 1 cm (0.39 inches) to 10 cm (3.93 inches) in diameter.
- Twisting:** With a firm grip on both the jar and the opener, twist the opener counter-clockwise to loosen the lid. The opener provides leverage, reducing the force required.
- Removal:** Once the seal is broken and the lid is loosened, remove the opener and twist the lid off by hand.



Figure 2: Demonstrating the adjustable jaw mechanism for opening jar lids.

# Tried various methods but still couldn't open the lid



Figure 3: Examples of ineffective or potentially unsafe methods for opening jar lids, which the CCKHDD opener is designed to replace.

## 2. Opening Bottle Caps

1. **Placement:** Position the bottle opener end of the tool under the edge of the bottle cap.
2. **Leverage:** Apply downward pressure on the handle while lifting the opener to pry off the cap.

## 3. Lifting Can Tabs

1. **Hooking:** Slide the small hook at the end of the handle under the pull tab of a can.
2. **Lifting:** Gently lift the handle to raise the tab, breaking the seal and allowing for easy opening.



Figure 4: The multifunction opener in action, demonstrating its use on various types of containers.

## MAINTENANCE

- Cleaning:** After each use, wash the lid opener with warm soapy water.
- Drying:** Dry thoroughly with a soft cloth to prevent water spots and maintain the stainless steel finish.
- Storage:** Store in a dry place, such as a kitchen drawer, to prevent rust and maintain its condition.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lid is still difficult to open.	Opener not gripping lid securely.	Ensure the adjustable jaw is tightened firmly around the lid. Apply consistent pressure while twisting.

Problem	Possible Cause	Solution
Opener slips on the lid.	Lid or opener is wet or greasy.	Clean and dry both the lid and the opener thoroughly before use to ensure a firm grip.

## SPECIFICATIONS

- Model:** B0D1XTQRT7
- Brand:** CCKHDD
- Material:** Stainless Steel
- Dimensions:** Approximately 8.98 x 1.54 x 0.87 inches (22.8 x 3.9 x 2.2 cm)
- Item Weight:** Approximately 3.84 ounces (109 grams)
- Adjustable Jaw Range:** 0.39 inches to 3.93 inches (1 cm to 10 cm)
- Special Features:** Adjustable Jaw Design, 3-in-1 functionality (Jar Opener, Bottle Cap Opener, Can Tab Lifter)



Figure 5: Product dimensions and adjustable range.

## WARRANTY AND SUPPORT

For information regarding warranty, returns, or technical support, please refer to the product packaging or contact CCKHDD customer service directly through the retailer where the product was purchased. Please have your model number (B0D1XTQRT7) available when contacting support.

You may also visit the official CCKHDD brand page on Amazon for further assistance:[CCKHDD Brand Page](#)

© 2024 CCKHDD. All rights reserved.