Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOMAA 1506

JOMAA Foldable Bluetooth Keyboard with Trackpad User Manual

Model: 1506

Introduction

Thank you for choosing the JOMAA Foldable Bluetooth Keyboard with Trackpad. This portable, full-size keyboard is designed for seamless connectivity across multiple devices, offering convenience and efficiency for your mobile computing needs. Featuring an RGB backlight, a responsive trackpad, and a durable aluminum alloy shell, this keyboard is an ideal companion for your iPad, iPhone, smartphone, tablet, PC, or laptop.

Product Features

- **Durable Aluminum Alloy Shell:** Provides enhanced protection and a premium feel.
- **Wide Compatibility:** Connects via Bluetooth to mobile phones, tablets, laptops, and desktop computers (with Bluetooth function).
- **Multi-Device Connectivity:** Features three independent Bluetooth channels, allowing you to connect and switch between up to three devices.
- **Rechargeable Battery:** Built-in lithium battery, charged via Type-C cable. Includes an on-screen battery display to monitor power levels.
- **Silent Scissor-Footed Switches:** Ensures quiet typing for a comfortable user experience.
- **Lockable Fold Design:** Two latches fix the keyboard in an open position, providing stability for typing on various surfaces, including your lap.
- **Integrated Display:** Shows current case status (e.g., Caps Lock) and battery level.
- **RGB Backlight:** Enhances visibility in low-light conditions and adds aesthetic appeal.

Setup Guide

1. Charging the Keyboard

Before first use, fully charge the keyboard. Use the provided Type-C charging cable to connect the keyboard to a USB power source (e.g., computer USB port, wall adapter).



Image: The keyboard being charged via a Type-C cable. Indicators show a 500 mAh battery capacity, 2-3 hour charging time, and an auto-sleep feature after 10 minutes of inactivity.

The display screen will show the charging status. A full charge typically takes 2-3 hours and can last up to one month depending on usage, especially with backlight off.

2. Unfolding and Locking the Keyboard

Gently unfold the keyboard until it lies flat. Locate the two sliding latches on the upper part of the keyboard. Slide these latches to the locked position to secure the keyboard in its open, flat configuration. This prevents accidental folding during use and provides a stable typing surface.



Image: Illustrates the unique locking mechanism of the JOMAA keyboard, allowing it to be fixed as a whole unit, unlike traditional folding keyboards that remain flexible.



Image: A detailed view of the dual-axis hinge, highlighting its smooth and silent rotation for folding and unfolding.

3. Bluetooth Pairing

1. Turn on the keyboard by unfolding it. The display will light up.
2. Press the **Fn** key simultaneously with one of the Bluetooth channel keys (**BT1**, **BT2**, or **BT3**) to select a channel. For first-time pairing, select an unused channel.
3. Press and hold **Fn + C** (or the dedicated pairing button if available) to enter pairing mode. The Bluetooth indicator on the display will blink.
4. On your device (smartphone, tablet, laptop), go to Bluetooth settings and search for new devices.
5. Select "JOMAA Keyboard" (or similar name) from the list of available devices.
6. Follow any on-screen prompts to complete the pairing process. Once connected, the Bluetooth indicator on the keyboard's display will stop blinking.

4. Connecting Multiple Devices

The JOMAA keyboard supports connection to up to three devices simultaneously. To connect additional devices, repeat the Bluetooth pairing steps (Step 3) using a different Bluetooth channel (**BT2** or **BT3**).



Image: Diagram showing the keyboard's ability to connect to three different devices (smartphone, tablet, laptop) simultaneously, labeled as Device 1, Device 2, and Device 3.

Operating Instructions

1. Switching Between Devices

To switch between connected devices, simply press **Fn + BT1**, **Fn + BT2**, or **Fn + BT3**, corresponding to the channel your desired device is paired with.

2. Using the Trackpad

The integrated trackpad functions similarly to a laptop touchpad. Use single-finger gestures for cursor movement and clicking. Two-finger gestures may be supported for scrolling, depending on your operating system.



Image: The JOMAA keyboard displayed in two states: with its RGB backlight off (top) and with the backlight illuminated (bottom), showcasing the full keyboard layout and integrated trackpad.

3. Backlight Control

The keyboard features an RGB backlight. Specific key combinations (e.g., **Fn + Light icon** or **Fn + Alt**) are typically used to cycle through backlight colors, adjust brightness, or turn the backlight on/off. Refer to the key legends for exact controls.

4. Understanding the Display Screen

The small display screen on the keyboard provides useful information:

- **Battery Level:** Indicates the remaining battery percentage. Recharge the keyboard when the level is low.
- **Connection Status:** Shows if the keyboard is connected to a device and which Bluetooth channel is active.
- **Case Indicator:** Displays status like Caps Lock.



Image: A magnified view of the keyboard's integrated display, clearly showing the battery percentage (e.g., 98%) and a connection indicator.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- **Battery Care:** To prolong battery life, avoid fully discharging the keyboard frequently. If storing for an extended period, charge it to about 50% and recharge every few months.
- **Storage:** When not in use, fold the keyboard to protect the keys and trackpad. Store in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Keyboard Not Connecting/Pairing

- Ensure the keyboard is charged. Check the battery level on the display.
- Make sure Bluetooth is enabled on your device.
- Ensure the keyboard is in pairing mode (Bluetooth indicator blinking).
- Try forgetting the device on your host device's Bluetooth settings and re-pairing.
- Ensure you are selecting an unused Bluetooth channel on the keyboard (BT1, BT2, or BT3).
- Restart both the keyboard (fold and unfold) and your device.

Trackpad Not Responding

- Ensure the keyboard is fully unfolded and locked.
- Check if the trackpad is enabled (some keyboards have a function key to toggle it).
- Clean the trackpad surface to remove any dirt or debris.
- Reconnect the Bluetooth connection.

Backlight Not Working

- Check the battery level. Low battery may disable the backlight.
- Press the backlight control keys (**Fn + Light icon** or **Fn + Alt**) to ensure it's not turned off or set to minimum brightness.

Specifications

Feature	Detail
Model Number	1506
Connectivity Technology	Bluetooth
Compatible Devices	Laptop, Smartphone, Tablet, PC
Keyboard Layout	QWERTY
Number of Keys	64
Special Feature	Backlit, Integrated Trackpad, Foldable, Multi-Device Support
Power Source	Battery Powered (1 Lithium Ion battery included)
Item Weight	15.8 ounces (approx. 448 grams)
Open Dimensions	13.65 x 4.5 x 0.41 inches
Folded Dimensions	7.32 x 4.5 x 0.79 inches
Trackpad Size	3.63 x 2.66 inches
Manufacturer	JOMAA



Image: Detailed measurements of the keyboard in both its open and folded states, including the dimensions of the integrated touchpad and overall weight.

Warranty and Support

JOMAA products are manufactured to high quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official JOMAA website. If you encounter any issues or have questions about your JOMAA Foldable Bluetooth Keyboard, please contact JOMAA customer support for assistance. For the latest support information and FAQs, please visit:JOMAA Official Store on Amazon

© 2025 JOMAA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D1YDK65P

More documents and user manuals: **https://manuals.plus/**