

Motorola PB1M0007US

Motorola Moto G Stylus 5G (2024) User Manual

Model: PB1M0007US

Brand: Motorola

INTRODUCTION

The Motorola Moto G Stylus 5G (2024) is designed to enhance your mobile experience with its integrated stylus, vibrant display, and advanced camera system. This manual provides essential information for setting up, operating, and maintaining your device.



Figure 1: Motorola Moto G Stylus 5G (2024) device and stylus.

WHAT'S IN THE BOX

Verify that all items are present in your product packaging:

- moto g stylus 5G Device
- Stylus
- USB Cable
- SIM Tray Ejector
- Guides (Quick Start Guide, Safety and Regulatory Information)

SETUP

1. Insert SIM Card and Power On

1. Locate the SIM tray on the side of your device.
2. Insert the SIM tray ejector tool into the small hole next to the tray and press firmly until the tray pops out.
3. Place your Nano-SIM card(s) and/or microSD card (if applicable) into the tray with the gold contacts facing down.
4. Carefully reinsert the tray into the device.
5. Press and hold the Power button (located on the side) until the Motorola logo appears to power on your device.



Figure 2: Bottom view of the device, highlighting ports and stylus slot.

2. Initial Device Setup

Follow the on-screen prompts to complete the initial setup process, which includes selecting your language, connecting to Wi-Fi, signing in with your Google account, and setting up security features.

OPERATING INSTRUCTIONS

Using the Stylus

The integrated stylus allows for precise interaction with your device. To access stylus features, simply remove the stylus from its slot. A dedicated menu will appear, offering options such as:

- **Write a note:** Quickly jot down thoughts.
- **Moto Note:** Access the dedicated note-taking application for detailed notes, doodles, and creative work.
- **Screenshot:** Capture a full-screen image.
- **Free-form crop:** Select a specific area of the screen to capture.
- **GIF maker:** Create animated GIFs from screen activity.
- **Handwriting Calculator:** Perform calculations by writing numbers and operators.



Figure 3: Inserting the stylus into the device.

Display and Audio

Your device features a 6.7-inch pOLED display with a 2400 x 1080 pixel resolution and a 120 Hz refresh rate for smooth visuals. For an immersive audio experience, the device supports Dolby Atmos[®] sound.

Camera System

The Moto G Stylus 5G (2024) is equipped with a 50MP Ultra Pixel camera system featuring Optical Image Stabilization (OIS) for sharper photos in low light and smoother videos. The camera supports both rear and front-facing photography.



Figure 4: Rear camera module of the device.

Battery and Charging

The device is powered by a 5000mAh battery. It supports 30W TurboPower charging for rapid power replenishment and also features wireless charging capability. Battery life varies based on usage patterns and network conditions.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive materials or harsh chemicals.
- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security.
- **Battery Care:** To prolong battery lifespan, avoid extreme temperatures and do not leave the device fully charged or fully depleted for extended periods.
- **Stylus Care:** Ensure the stylus is properly seated in its slot when not in use to prevent loss or damage.

TROUBLESHOOTING

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Device not powering on	Ensure the battery is charged. Connect to a charger for at least 15 minutes. If unresponsive, perform a force restart by holding the Power button for 10-15 seconds.
Stylus not responding	Ensure the stylus is fully inserted and removed correctly. Restart the device. Check for system updates.
Poor Wi-Fi connection	Restart your Wi-Fi router. Forget the network on your phone and reconnect. Ensure you are within range of the Wi-Fi signal.
Apps crashing or freezing	Clear the cache and data for the problematic app (Settings > Apps > [App Name] > Storage). Update the app. If the issue persists, uninstall and reinstall the app.

SPECIFICATIONS

Feature	Detail
Model Name	Moto G Stylus 5G (2024)
Item Model Number	PB1M0007US
Operating System	Android 14
Display Size	6.7 Inches pOLED
Resolution	2400 x 1080 pixels
Refresh Rate	120 Hz
RAM Memory	8 GB
Internal Storage	256 GB (expandable via SD card)
Rear Camera	50MP Ultra Pixel with OIS
Battery Capacity	5000 mAh
Charging	30W TurboPower, Wireless Charging
Dimensions	6.4 x 0.33 x 2.94 inches
Weight	6.7 ounces (190 Grams)
Connectivity	5G, Bluetooth, Wi-Fi, USB, NFC
Audio Jack	3.5 mm

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Motorola support website. For technical assistance, software updates, or service inquiries, please contact Motorola customer support or visit their online support resources.

You can find additional support and resources on the [Motorola Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question