

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [AJAZZ](#) /

› [AJAZZ A3060 Wireless Keyboard and Mouse Combo User Manual](#)

AJAZZ A3060

AJAZZ A3060 Wireless Keyboard and Mouse Combo User Manual

INTRODUCTION

This manual provides detailed instructions for setting up, operating, and maintaining your AJAZZ A3060 Wireless Keyboard and Mouse Combo. Please read this manual carefully before use to ensure optimal performance and longevity of your product.

PACKAGE CONTENTS

- 1 x AJAZZ A3060 Wireless Keyboard
- 1 x AJAZZ A3060 Wireless Mouse
- 1 x USB 2.4G Receiver



Image: The AJAZZ A3060 wireless keyboard and mouse combo, shown with the compact USB receiver.

SETUP

1. Battery Installation

- For the Keyboard:** Locate the battery compartment on the underside of the keyboard. Insert two (2) AAA batteries, ensuring correct polarity.
- For the Mouse:** Locate the battery compartment on the underside of the mouse. Insert one (1) AA battery, ensuring correct polarity.



ONE RECEIVER FOR BOTH KEYBOARD AND MOUSE




Image: Diagram illustrating the battery compartments for the keyboard (2x AAA) and mouse (1x AA), and the location of the USB receiver storage within the mouse.

2. Connecting the USB Receiver

1. Take out the USB receiver from its storage slot on the underside of the mouse.
2. Plug the USB receiver into an available USB-A port on your computer or compatible device.
3. Ensure the mouse power switch (located on the underside) is in the 'ON' position.
4. The keyboard and mouse should automatically connect to your device. No additional drivers are required.

Typewriter Style Round Keys

Stylish keyboard design with an elevated circular-shaped keys and space between every key to avoid mistyping.



Beautiful Compact mouse

A sculpted-round mouse. The palm grip design is comfortable to use for long hours and reduces the stress on your forearm and wrist

Image: Visual guide demonstrating the six steps for connecting the wireless keyboard and mouse to a USB-A device, including receiver removal, plugging in, battery insertion, and power activation.

OPERATING INSTRUCTIONS


Keyboard Functions

The AJAZZ A3060 keyboard features 84 keys with a retro round keycap design, providing a tactile and responsive typing experience. It includes dedicated media keys for enhanced control.

- Media Keys:** The function keys (F1-F12) have secondary media control functions. These can typically be accessed by pressing the 'Fn' key simultaneously with the desired F-key.
- Indicator Lights:** Located in the upper right corner of the keyboard. One light indicates uppercase/lowercase switching (Caps Lock), and the other indicates low battery or 2.4G connection status.



MEDIA KEYS FUNCTION



Esc Multimedia Lock Keys

F1 Previous Song

F2 Play

F3 Next Song

F4 Mute

F5 Volume plus

F6 Volume Down

F7 Home

F8 Search

F9 Email

F10 Favorites

F11 Save

F12 Setting



1 INDICATOR LIGHT IN THE UPPER RIGHT CORNER:

A: uppercase and lowercase switching indicator.

2 D low battery indicator/ 2.4G connection indicator.

Image: An illustration of the AJAZZ A3060 keyboard highlighting the media key functions (F1-F12) and the indicator lights for Caps Lock and battery/connection status.

Mouse Functions


The ergonomic cat-shaped mouse is designed for comfort and features adjustable DPI settings.

- DPI Adjustment:** The mouse features a DPI button, typically located near the scroll wheel. Press this button to cycle through three adjustable DPI levels: 800, 1600, and 3200. This allows you to customize cursor sensitivity.
- Power Switch:** An ON/OFF switch is located on the underside of the mouse to conserve battery life when not in use.



ERGONOMIC MOUSE

- 1 Ergonomic Design
- 2 Conforms to the palm curve
- 3 Comfortable to use
- 4 Not easy to fatigue



CAT SHAPE MOUSE

- 1 Exquisite and cute
- 2 Make you feel happy
- 3 Improve efficiency of work and play

Image: A visual representation of the AJAZZ A3060 mouse, highlighting its ergonomic design and the three adjustable DPI settings (800, 1600, 3200).

Power Saving Mode

The combo is equipped with an intelligent power-saving feature. After a period of inactivity, the devices will automatically enter sleep mode to conserve battery. To wake them up, simply click any key on the keyboard or move/click the mouse.

A low battery indicator will alert you when it's time to replace the batteries.

COMPATIBILITY

The AJAZZ A3060 Wireless Keyboard and Mouse Combo offers broad compatibility with various operating systems and devices, ensuring versatile use.

- **Operating Systems:** Compatible with Windows XP, Windows 7, Windows 8, Windows 10, and macOS.
- **Devices:** Suitable for use with PCs, laptops, Smart TVs, workstations, projectors, and tablets.



 **Suitable for Windows XP / Win7 / Win8 / Win10**




Image: An overview showing the AJAZZ A3060 keyboard and mouse compatible with Smart TVs, PCs, Laptops, Macs, Workstations, and Projectors, and suitable for Windows operating systems.

MAINTENANCE

To ensure the longevity and optimal performance of your AJAZZ A3060 combo, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device.
- **Battery Replacement:** Replace batteries promptly when the low battery indicator appears to avoid interruptions in use. Always use new, high-quality batteries of the specified type (AAA for keyboard, AA for mouse).
- **Storage:** When not in use for extended periods, turn off the mouse using its power switch and store the USB receiver in its designated slot to prevent loss.
- **Avoid Liquids:** Keep the devices away from liquids to prevent damage to internal components.

TROUBLESHOOTING

- **No Connection/Unresponsive:**

- Ensure the USB receiver is securely plugged into a working USB port.
- Check if the mouse power switch is in the 'ON' position.
- Replace the batteries in both the keyboard and mouse with fresh ones.
- Try plugging the USB receiver into a different USB port on your device.
- Move the keyboard and mouse closer to the USB receiver (within 10 meters).

- **Lagging/Delayed Response:**

- Ensure there are no other 2.4GHz wireless devices causing interference nearby.
- Check battery levels and replace if low.

- **Mouse Cursor Movement Issues:**

- Clean the optical sensor on the underside of the mouse.
- Ensure you are using the mouse on a suitable surface (not highly reflective or transparent).
- Adjust the DPI setting to your preference.

SPECIFICATIONS

Model	A3060
Connection Type	2.4GHz Wireless (USB Receiver)
Wireless Range	Up to 10 meters (33 feet)
Keyboard Layout	84 Keys
Keyboard Battery	2 x AAA Batteries (not included)
Mouse Battery	1 x AA Battery (not included)
Mouse DPI	800 / 1600 / 3200 (Adjustable)
Keyboard Dimensions	Approx. 13.6 in x 6 in x 1.1 in
Mouse Dimensions	Approx. 4.1 in x 2.7 in
Product Weight	Approx. 730 grams (package weight)
Country of Origin	China

PRODUCT SIZE DATA




Image: Detailed dimensions of the AJAZZ A3060 wireless keyboard and mouse, showing measurements in inches.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims.

Related Documents - A3060

	<p>AJAZZ i339Pro Gaming Mouse User Manual and Specifications</p> <p>Detailed user manual and technical specifications for the AJAZZ i339Pro gaming mouse, including features, warranty, and operational instructions.</p>
---	---

	<p>AJAZZ AJ52Pro Three-Mode Gaming Mouse User Manual</p> <p>Comprehensive user manual for the AJAZZ AJ52Pro three-mode gaming mouse, covering technical specifications, button functions, mode descriptions, light switching, product warranty, and FCC compliance. Download drivers and find support information.</p>
	<p>AJAZZ AJ139 PRO Dual Mode Gaming Mouse User Manual</p> <p>User manual for the AJAZZ AJ139 PRO dual mode gaming mouse, detailing technical specifications, button functions, indicator lights, low power modes, sleep modes, and connection instructions for wired and 2.4G wireless modes. Includes warranty information and FCC compliance statement.</p>
	<p>AJAZZ T520 Tri-Mode Gaming Mouse User Manual and Specifications</p> <p>Comprehensive user manual for the AJAZZ T520 gaming mouse, detailing its tri-mode connectivity (2.4G, Bluetooth, Wired), DPI settings, features, and product warranty information.</p>
	<p>AJAZZ T520 Gaming Mouse User Manual and Specifications</p> <p>Official user manual and technical specifications for the AJAZZ T520 gaming mouse, detailing features, setup, usage, button layout, troubleshooting, and system requirements.</p>
	<p>Ajazz AJ52 Gaming Mouse Product Manual and Catalog</p> <p>Detailed user manual and catalog for the Ajazz AJ52 gaming mouse, covering features, specifications, setup, driver configuration, usage guidelines, and maintenance.</p>