

CuFun YC-6060

CuFun Kids Height-Adjustable Table and Chairs Set (Model YC-6060) Instruction Manual

For Ages 2-8

1. INTRODUCTION

Thank you for choosing the CuFun Kids Height-Adjustable Table and Chairs Set. This manual provides essential information for the safe assembly, operation, and maintenance of your new product. Please read these instructions carefully before use and retain them for future reference.

This set is designed to provide a versatile and comfortable space for children aged 2 to 8 years for various activities such as learning, drawing, playing, and dining. Key features include height-adjustable components, a durable and easy-to-clean desktop, and an ergonomic design for child safety and comfort.

2. IMPORTANT SAFETY WARNINGS

- **Weight Limit:** Do not exceed the maximum weight capacity of 180 pounds (approximately 81 kg) for each chair. The table has a maximum weight capacity of 330 pounds (approximately 150 kg).
- **Choking Hazard:** Keep small objects, such as paint supplies or small toy parts, away from young children to prevent choking.
- **Assembly:** Always follow the assembly instructions precisely to ensure the stability and safe use of the table and chairs. Improper assembly can lead to instability and potential injury.
- **Supervision:** Adult supervision is recommended during use, especially for younger children.
- **Placement:** Place the table and chairs on a flat, stable surface. Ensure all leg adjusters are properly engaged to prevent wobbling.
- **Sharp Objects:** Avoid using sharp objects on the desktop to prevent scratches or damage.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged,

please contact customer support.

- 1 x Kids Tabletop
- 4 x Table Legs (with height adjustment mechanisms)
- 2 x Kids Chairs (with seat, backrest, and legs)
- Hardware Pack (screws, foot spinners/rotators)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Assembly is straightforward and can be completed in a few steps. An electric screwdriver set to a low-medium speed may assist in faster assembly.

4.1. Table Assembly

1. Unpack all table components and lay them out on a clean, soft surface to prevent scratches.
2. Attach the four table legs to the underside of the tabletop using the provided screws. Ensure they are securely fastened.
3. Insert the foot spinners/rotators into the bottom of each table leg. These can be adjusted later to level the table on uneven surfaces.



Image 4.1: Illustration of table components and features, including the sturdy structure and non-slip adjustable legs.

4.2. Chair Assembly

1. Unpack all chair components for both chairs.
2. Attach the chair legs to the chair seat.
3. Secure the backrest to the chair frame.
4. Install the two crossbars on each chair. **Note:** Ensure the arrows on the chair's crossbars are facing upwards for correct installation and enhanced sturdiness.
5. Verify all screws are tightened for stability.



Image 4.2: Detail of the ergonomically designed chair backrest.

5. OPERATING INSTRUCTIONS

5.1. Adjusting Table Height

The table offers 7 height levels, ranging from 18.9 inches to 23.6 inches. To adjust the table height:

1. Loosen the screws on the upper part of each table leg.
2. Carefully slide the inner leg section up or down to the desired height. Ensure all four legs are adjusted to the same level.
3. Tighten the screws firmly on all legs to secure the table at the new height.



Image 5.1: Close-up of the table leg height adjustment mechanism.

5.2. Adjusting Chair Height

The chairs feature 3 height levels for the seat, from 10.6 inches to 12.2 inches. To adjust the chair height:

1. Locate the adjustment points on the chair legs.
2. Press the release buttons or loosen the screws (depending on the specific mechanism) and slide the leg sections to the desired height.
3. Ensure both sides of the chair are adjusted to the same height and securely locked into place.

Height Adjustable






Image 5.2: Visual guide for height adjustment and weight limits for the table and chairs.

5.3. Using the Erasable Desktop

The tabletop is designed to be paintable and erasable. It is compatible with water-based paintbrushes and pencils. Avoid using oil-based pens or permanent markers, as these may stain the surface.

Graffiti Desktop



Image 5.3: Guide for using the erasable desktop with appropriate writing tools.

6. MAINTENANCE

6.1. Cleaning

To clean the table and chairs, simply wipe with a dry cloth. For spills or marks, use a damp cloth with mild soap and water, then dry thoroughly. The desktop is designed for easy cleaning of water-based paints and marks.

6.2. General Care

- Regularly check all screws and fasteners to ensure they remain tight.
- Avoid exposing the product to extreme temperatures or direct sunlight for prolonged periods to prevent material degradation.
- Do not use abrasive cleaners or harsh chemicals, as these can damage the surface finish.

7. TROUBLESHOOTING

7.1. Table or Chairs are Wobbly

- **Check Fasteners:** Ensure all screws and bolts are securely tightened on both the table and chairs.
- **Level Surface:** Verify that the table and chairs are placed on a flat, even surface.
- **Adjust Foot Spinners:** For the table, adjust the silicone rotators (foot spinners) at the bottom of the legs to compensate for uneven ground.
- **Chair Crossbars:** For chairs, confirm that the crossbars are correctly installed with arrows facing upwards, as this significantly enhances stability.

7.2. Difficulty Adjusting Height

- **Loosen Screws:** Ensure all securing screws on the adjustable leg sections are sufficiently loosened before attempting to slide the parts.
- **Clear Obstructions:** Check for any debris or obstructions within the leg mechanisms that might prevent smooth adjustment.

8. SPECIFICATIONS

Feature	Detail
Brand	CuFun
Model Number	YC-6060
Material	High Density Polyethylene (Plastic)
Table Dimensions (L x W x H)	23.6 x 23.6 x 18.9-23.6 inches (adjustable height)
Tabletop Size	23.6 x 23.6 inches
Table Height Adjustment Range	18.9 inches to 23.6 inches (7 levels)
Chair Seat Height Adjustment Range	10.6 inches to 12.2 inches (3 levels)
Maximum Table Weight Capacity	330 pounds (150 kg)
Maximum Chair Weight Capacity	180 pounds (81 kg) per chair
Recommended Age	2-8 years
Product Weight	25.7 pounds (11.6 kg)
Color	Burlywood
Care Instructions	Wipe with Dry Cloth
UPC	789616226560

Product Dimensions



Health



Graffiti



Lift



Strong Solid



Image 8.1: Visual representation of the product dimensions.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the terms and conditions provided by your retailer at the time of purchase. CuFun is committed to product quality and customer satisfaction.

If you encounter any issues or have questions regarding your CuFun Kids Height-Adjustable Table and Chairs Set, please contact the retailer where you purchased the product or visit the official CuFun brand store for support resources.

CuFun Official Store: [Visit the CuFun Store on Amazon](#)

