

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [JISULIFE](#) /

› JISULIFE 3 IN 1 Hand Fan with Power Bank, Flashlight & 2024 Powerful Handheld Fan Life4 with LED Display User Manual

JISULIFE F8, Life4

JISULIFE Handheld Fans User Manual

Models: F8, Life4

1. INTRODUCTION

Welcome to the user manual for your new JISULIFE Handheld Fans. This manual provides essential information for the safe and efficient operation of both the JISULIFE 3 IN 1 Pocket Handheld Fan (Model F8) and the JISULIFE 2024 Powerful Handheld Fan (Model Life4). Please read this manual thoroughly before using your devices and retain it for future reference.

2. PRODUCT OVERVIEW

Your purchase includes two versatile handheld fans designed for personal cooling and convenience.



This image displays both the compact, bear-shaped JISULIFE F8 fan and the sleek, black JISULIFE Life4 fan, highlighting their distinct designs.

2.1. JISULIFE 3 IN 1 Pocket Handheld Fan (Model F8)

The F8 fan is a multi-functional device that combines a personal fan, a power bank, and a flashlight into a compact, foldable design. It is ideal for on-the-go use, offering two speed settings and a long-lasting battery.




The JISULIFE F8 fan is shown in its compact, folded state and then unfolded with its fan blades spinning, demonstrating its portability and readiness for use.

2.2. JISULIFE 2024 Powerful Handheld Fan (Model Life4)

The Life4 fan is engineered for powerful airflow and extended cooling. It features an LED digital display for easy monitoring of battery life and speed settings, and offers five adjustable speeds for customized comfort.







This detailed view of the JISULIFE Life4 fan highlights its modern design and the clear LED digital display, which shows the current battery percentage or fan speed.

3. SETUP

3.1. Unboxing and Initial Inspection

Upon receiving your JISULIFE fans, carefully remove them from the packaging. Inspect both devices for any visible damage. Ensure all included components are present.

3.2. Charging the Devices

Before first use, fully charge both the F8 and Life4 fans. Use a standard USB charger (not included) and the provided charging cable.

- Connect the charging cable to the fan's charging port.
- Connect the other end of the cable to a USB power source (e.g., wall adapter, computer USB port).
- The F8 fan will indicate charging status via an LED indicator. The Life4 fan's LED display will show the charging percentage.
- Charging time may vary. Disconnect once fully charged to preserve battery life.

4. OPERATING INSTRUCTIONS

4.1. JISULIFE 3 IN 1 Pocket Handheld Fan (Model F8)


3 IN 1 Pocket Fan



Fan



Flashlight



Backup Power Bank

This image illustrates the versatility of the JISULIFE F8 fan, showing it being used as a personal fan, its integrated flashlight illuminating a surface, and its power bank feature charging a phone from a pocket.

Fan Operation:

- To turn on the fan, unfold it to the desired angle (180 degrees for handheld, 90 degrees for desk mode).
- Press the power button once for Speed 1.
- Press the power button a second time for Speed 2.
- Press the power button a third time to turn off the fan.

Unique Folding Design

90° -- Desk Style

180° -- Handheld Style



The image showcases the unique folding design of the JISULIFE F8 fan, allowing it to be positioned at a 90-degree angle for desk use or fully extended to 180 degrees for handheld operation.

Power Bank Function:

- Locate the USB-A output port on the fan.
- Connect your device's charging cable to this port.
- The fan will automatically begin charging your device.

Flashlight Function:

- Locate the flashlight on the end of the fan body.
- Press and hold the power button for approximately 2 seconds to turn the flashlight on or off.

4.2. JISULIFE 2024 Powerful Handheld Fan (Model Life4)

Easy Management and Maintenance With Smart Digital

Battery Power, Wind Speed Settings



A graphic representation of the JISULIFE Life4 fan's LED display, emphasizing its ability to show real-time battery power and current wind speed settings for easy management.

Fan Operation:

- Press the power button once to turn on the fan at Speed 1.
- Subsequent presses of the power button will cycle through Speed 2, Speed 3, Speed 4, and Speed 5.
- After Speed 5, pressing the button again will turn off the fan.

LED Display:

- The LED display shows the current fan speed (1-5) and the remaining battery percentage.
- During charging, the display will show the charging progress.

Enhance Your Cooling Experience with Upgraded Technology



The image contrasts the JISULIFE Life4 fan's internal advanced turbine and upgraded brushless DC motor, designed for more concentrated airflow, against a conventional fan's less efficient blade design.

5. MAINTENANCE

5.1. Cleaning

- Ensure the fan is turned off before cleaning.
- Use a soft, dry cloth to wipe the exterior of the fan.
- For the fan blades and grille, use a cotton swab or a soft brush to gently remove dust and debris. Do not use water or harsh chemicals.

5.2. Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- Charge the fan regularly, even if not in use, to maintain battery health.
- Store the fan in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Low battery.	Charge the fan fully.
Fan does not turn on.	Power button not pressed correctly.	Ensure a firm press on the power button. For F8 flashlight, press and hold.
Fan not charging.	Faulty cable or adapter.	Try a different USB cable and power adapter.
Fan not charging.	Charging port obstruction.	Check the charging port for debris and clean gently if necessary.
Weak airflow.	Low battery.	Charge the fan fully.
Weak airflow.	Fan blades or grille obstructed.	Clean the fan blades and grille as per maintenance instructions.
F8 flashlight not working.	Not activated correctly.	Press and hold the power button for 2 seconds to activate/deactivate.
F8 power bank not charging devices.	Low fan battery.	Ensure the F8 fan has sufficient charge.
F8 power bank not charging devices.	Incompatible cable or device.	Try a different charging cable or ensure your device is compatible with USB-A charging.

7. SPECIFICATIONS

7.1. JISULIFE 3 IN 1 Pocket Handheld Fan (Model F8)

Feature	Detail
Functions	Fan, Power Bank, Flashlight
Fan Speeds	2 Speeds
Working Hours	12-19 hours (depending on speed)
Design	Unique Pocket and Folding Design (90° Desk, 180° Handheld)
Power Source	Battery Powered (Rechargeable)
Material	Plastic

Use it Anywhere with Large Battery Capacity



A user holds the JISULIFE F8 fan, with an overlay indicating its impressive battery life: up to 19 hours on the first speed setting and 12 hours on the second speed setting.

7.2. JISULIFE 2024 Powerful Handheld Fan (Model Life4)

Feature	Detail
Display	LED Digital Display
Fan Speeds	5 Speeds
Battery Capacity	3600mAh
Cooling Time	Up to 13 hours
Motor	Upgraded Brushless DC Motor
Blade Material	Plastic (12-blades)
Power Source	Battery Powered (Rechargeable)

Keep You Cool Twice Longer Than Others



This visual comparison highlights the JISULIFE Life4 fan's superior 3600mAh battery, providing up to 13 hours of cooling, significantly longer than a typical 1800mAh battery offering 8 hours.

8. WARRANTY AND SUPPORT

JISULIFE products are manufactured to high-quality standards. For information regarding warranty coverage and customer support, please refer to the warranty card included with your product or visit the official JISULIFE website. If you encounter any issues not covered in this manual, please contact JISULIFE customer service for assistance.

For further assistance, please visit the [JISULIFE Store on Amazon](#).