Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

oneisall RFC-676#1-#8

Oneisall Dog Clipper Guide Combs Instruction Manual

Model: RFC-676#1-#8

1. Introduction

Welcome to the instruction manual for your Oneisall Dog Clipper Guide Combs. This set of 10 guide combs is designed to provide precise and consistent cutting lengths for your pet's grooming needs. Please read this manual carefully before use to ensure proper handling and to achieve optimal grooming results.

Safety Warning:

Always ensure the guide combs are securely attached to your clipper before use. Keep out of reach of children and pets when not in use. Inspect combs for any damage before each use; do not use damaged combs.

2. Product Overview

The Oneisall Dog Clipper Guide Comb set includes 10 different sizes, allowing for a wide range of hair lengths. These combs are specifically designed to fit Oneisall low-noise clippers, such as model B09QFRN3D5.

- **Included Sizes:** 1.5 mm, 3 mm, 4.5 mm, 6 mm, 10 mm, 13 mm, 16 mm, 19 mm, 22 mm, and 25 mm.
- Each comb is clearly marked with its length in both millimeters (mm) and inches (in) for easy identification.
- These combs allow you to achieve desired hair lengths when grooming your dog, working in conjunction with your clipper's fine-tuning settings.



Figure 2.1: Overview of the 10 guide comb sizes included in the set.

3. Setup and Installation

Before attaching a guide comb, ensure your Oneisall clipper is clean and turned off. Select the desired comb length based on the grooming style you wish to achieve.

1. **Identify Compatibility:** These guide combs are designed for Oneisall low-noise clippers. Verify your clipper model is compatible (e.g., B09QFRN3D5).
2. **Select Comb:** Choose the guide comb with the desired cutting length. The numbers on the comb correspond to the hair length in millimeters and inches.
3. **Attach Comb:** Align the guide comb with the clipper blade. Gently push the comb onto the blade until it clicks securely into place. Ensure it is firmly seated and does not wobble.
4. **Verify Attachment:** Lightly tug on the comb to confirm it is securely attached before turning on the clipper.



Figure 3.1: Illustration of how the guide combs attach to the Oneisall dog clipper.

4. Operating Instructions

Once the guide comb is securely attached, you can begin grooming. Always ensure your pet's fur is clean and tangle-free before clipping.

- **Preparation:** Brush your dog's coat thoroughly to remove any mats or tangles. This ensures smooth passage of

the clipper and prevents snagging.

- **Clipper Settings:** For best results, use the guide combs in conjunction with your clipper's fine-tuning settings. Some clippers have a five-speed adjustment that can further refine the cutting length.
- **Clipping Technique:** Hold the clipper firmly and move it smoothly against the direction of hair growth. Apply gentle, even pressure. Overlap strokes slightly to ensure an even cut.
- **Length Adjustment:** If you desire a longer coat, start with a longer guide comb. You can always switch to a shorter comb if you wish to reduce the length further.
- **Regular Cleaning During Use:** Periodically remove accumulated hair from the guide comb and clipper blade during grooming to maintain optimal performance.

5. Maintenance and Care

Proper maintenance of your guide combs will extend their lifespan and ensure consistent performance.

- **Cleaning:** After each use, remove the guide comb from the clipper. Use a small brush (often included with clippers) to remove any trapped hair from the comb's teeth. You can rinse the combs under running water if necessary, but ensure they are completely dry before storage.
- **Drying:** Allow the combs to air dry completely or wipe them with a clean, dry cloth. Do not store wet combs.
- **Storage:** Store the guide combs in a clean, dry place, preferably in their original packaging or a dedicated storage case, to prevent damage and keep them organized.
- **Inspection:** Regularly inspect the combs for any signs of wear, cracks, or broken teeth. Replace any damaged combs to prevent uneven cuts or potential injury to your pet.

6. Troubleshooting

If you encounter issues with your Oneisall Dog Clipper Guide Combs, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Comb does not fit the clipper.	Incompatible clipper model or incorrect attachment method.	Ensure your clipper is a compatible Oneisall model (e.g., B09QFRN3D5). Refer to Section 3 for proper attachment instructions. Apply firm, even pressure until it clicks into place.
Hair is snagging or cutting unevenly.	Comb is clogged with hair, damaged, or fur is matted.	Clean the comb and clipper blade thoroughly. Inspect the comb for any damage and replace if necessary. Ensure pet's fur is clean and tangle-free before grooming.
Comb feels loose or falls off during use.	Improper attachment or worn attachment points.	Re-attach the comb, ensuring it clicks securely. If the comb continues to be loose, it may be worn and require replacement.

7. Specifications

Feature	Detail
Product Name	Oneisall Dog Clipper Guide Combs
Model Number	RFC-676#1-#8

Feature	Detail
Brand	Oneisall
Material	Plastic
Number of Items	10 guide combs
Included Lengths	1.5 mm, 3 mm, 4.5 mm, 6 mm, 10 mm, 13 mm, 16 mm, 19 mm, 22 mm, 25 mm
Color	Black
Package Dimensions	14.91 x 11.3 x 5.51 cm
Package Weight	82 grams

8. Warranty and Support

This manual does not contain specific warranty information. For details regarding warranty coverage, product support, or to purchase replacement parts, please refer to the official Oneisall website or contact their customer service directly. You can often find support information on the manufacturer's official website:www.oneisall.com (Note: This is a placeholder URL, please refer to actual product packaging or manufacturer's official documentation for correct contact information).

© 2024 Oneisall. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D22MTXWH

More documents and user manuals: **https://manuals.plus/**