



Manuals.plus /

› **TIMEMORE** /

› TIMEMORE S3 Manual Coffee Grinder User Manual

TIMEMORE S3

TIMEMORE S3 Manual Coffee Grinder User Manual

Model: S3

INTRODUCTION

Thank you for choosing the TIMEMORE S3 Manual Coffee Grinder. This manual provides essential information for the proper setup, operation, and maintenance of your grinder. Please read it thoroughly to ensure optimal performance and longevity of your device. The TIMEMORE S3 is designed for precision grinding, offering consistent results for various coffee brewing methods.

PRODUCT FEATURES

- **Precision Grinding Control:** The S3 features a high-precision bean adjustment system, allowing for fine adjustments of 0.015mm per click. This enables precise grind sizes suitable for Italian espresso, pour-over, and French press.
- **Intuitive External Adjustment:** Easily adjust grind settings with the innovative lens-ring external adjustment design. A simple twist allows for quick changes to grind size without disassembly.
- **Premium Stainless Steel Burr:** Equipped with the original S2C 890 stainless steel burr, ensuring durability, consistency, and superior grinding performance.
- **Sleek All-Metal Construction:** Crafted with a seamless all-metal body and custom high-precision bearings for robust and long-lasting performance.
- **Stable & Silent Operation:** A non-slip silicone base ensures stability during use, minimizing noise for a quiet grinding experience.
- **Foldable Handle:** The handle is designed to fold, making the grinder compact for easy storage and transport.



CHESTNUT S3

Externally Adjustable
Manual Coffee Grinder



Image: The external adjustment lens ring allows for precise grind size changes.



Image: Close-up of the S2C 890 stainless steel burr, designed for uniform grinding.




Image: Diagram showing the all-metal integrated body and high-precision bearings for enhanced durability.



Image: The foldable handle design for compact storage and portability.

SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts are present: grinder body, handle, and lid.
2. **Initial Cleaning:** Before first use, disassemble the grinder (refer to Maintenance section for disassembly instructions) and clean all parts with a soft brush or dry cloth. Do not wash the burrs with water.
3. **Assembly:** Reassemble the grinder. Attach the handle to the top shaft.
4. **Grind Setting Adjustment:** The S3 features an external adjustment ring. To adjust, hold the grinder firmly and rotate the adjustment ring to your desired setting. Turning clockwise results in a finer grind, and counter-clockwise results in a coarser grind. Each click represents a 0.015mm change.

OPERATING INSTRUCTIONS

1. **Load Coffee Beans:** Remove the lid and pour your desired amount of whole coffee beans into the hopper. Do not overfill.
2. **Select Grind Size:** Adjust the external adjustment ring to your preferred grind setting based on your brewing method. Refer to the recommended settings below.
3. **Grind Coffee:** Place the lid back on and attach the handle. Hold the grinder firmly and turn the handle clockwise to begin grinding. Continue until all beans have been ground.
4. **Retrieve Grounds:** Unscrew the bottom catch cup to access your freshly ground coffee.

Recommended Grind Settings (Approximate Clicks from Zero Point)

- **Espresso:** 0-1.5 Clicks (Very Fine)
- **Moka Pot:** 0.5-2.0 Clicks (Fine)
- **Pour Over:** 5.0-8.0 Clicks (Medium)
- **French Press:** 8.0-9.0 Clicks (Coarse)



Original S2C 890 Burr

Image: Visual guide to recommended grind settings for Espresso, Moka, Pour Over, and French Press.



Image: The TIMEMORE S3 grinder being used to grind coffee, demonstrating its ergonomic design.

MAINTENANCE

1. **Regular Cleaning:** For optimal performance, clean your grinder regularly, especially if you switch between different types of coffee beans.

- 2. Disassembly:** Unscrew the bottom catch cup. Then, carefully unscrew the inner burr assembly. The outer burr is fixed.
- 3. Cleaning Burrs:** Use a soft brush (a small cleaning brush is often included) to remove any residual coffee grounds from the burrs and internal components. Do not use water on the burrs as this can lead to rust and affect grinding performance.
- 4. Cleaning Body and Catch Cup:** The exterior body and catch cup can be wiped with a damp cloth and then dried thoroughly. Ensure no water enters the burr mechanism.
- 5. Reassembly:** Carefully reassemble the inner burr, ensuring it is properly aligned, then screw the catch cup back on.
- 6. Storage:** Store the grinder in a dry place away from direct sunlight and moisture.

TROUBLESHOOTING

- **Difficulty Grinding:**

- Ensure the grind setting is not too fine for the beans being used. Very light roast beans can be harder to grind at fine settings.
- Check for any foreign objects in the burr chamber.
- Clean the burrs to remove any build-up of coffee oils or fine particles.

- **Inconsistent Grind:**

- Ensure the burr assembly is clean and free of debris.
- Verify that the inner burr is securely tightened and properly seated during reassembly.
- Avoid shaking the grinder excessively during operation, which can affect consistency.

- **Handle Not Turning Smoothly:**

- Check for obstructions in the bean hopper or burr area.
- Ensure the handle is correctly attached and tightened.
- Clean the shaft and bearings if there is resistance.

SPECIFICATIONS

Brand	TIMEMORE
Model	S3
Color	S3 Green
Material	Iron (Body), Stainless Steel (Burr)
Burr Type	S2C 890 Stainless Steel
Adjustment Precision	0.015mm per click
Included Components	Lid

WARRANTY INFORMATION

The TIMEMORE S3 Manual Coffee Grinder is covered by a manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary by region and retailer. Please retain

your proof of purchase for warranty claims. For detailed warranty information, refer to the documentation included with your product or visit the official TIMEMORE website.

SUPPORT

If you encounter any issues or have questions regarding your TIMEMORE S3 Manual Coffee Grinder that are not addressed in this manual, please contact TIMEMORE customer support. You can typically find contact information on the official TIMEMORE website or through your retailer. When contacting support, please have your product model (S3) and purchase details ready.