

ELECTROPRIME IP6D1244B

User Manual

ELECTROPRIME WEKOME VB07 MECHA SERIES BLADE WIRELESS BLUETOOTH EARPHONE

Model: IP6D1244B

INTRODUCTION

Thank you for choosing the ELECTROPRIME WEKOME VB07 Mecha Series Blade Wireless Bluetooth Earphone. This manual provides essential information for the proper use, setup, and maintenance of your new earphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

The WEKOME VB07 earphones feature Bluetooth V5.3 connectivity, a unique mecha design with cool illusion lighting effects, and a comfortable semi-in-ear fit. Enjoy low latency and high synchronization for an immersive audio experience.

SAFETY INFORMATION

- Do not expose the earphones or charging case to extreme temperatures, humidity, or liquids.
- Avoid dropping or subjecting the device to strong impacts.
- Do not disassemble or attempt to repair the device yourself. This will void the warranty.
- Use only the provided or certified charging cables and adapters.
- Prolonged listening at high volume levels may cause hearing damage. Adjust volume to a safe level.
- Keep out of reach of children and pets.

PACKAGE CONTENTS

Please check the package for the following items:

- WEKOME VB07 Mecha Series Blade Wireless Bluetooth Earphones (Left and Right)
- Charging Case
- USB Charging Cable

- User Manual (this document)
- Protective Case (as per product specifications)



Image: The retail packaging of the WEKOME VB07 Mecha Series Blade Wireless Bluetooth Earphones, showing the front and back of the box with product details and branding.

PRODUCT OVERVIEW

The WEKOME VB07 earphones are designed for a comfortable and immersive audio experience. The charging case features a unique mecha shape with cool illusion lighting effects and a slide compartment for easy access to the earbuds.



Image: A close-up view of the black WEKOME VB07 Mecha Series Blade Wireless Bluetooth Earphone charging case with the earbuds inserted. The case features a futuristic design with illuminated accents.



Image: Two versions of the WEKOME VB07 Mecha Series Blade Wireless Bluetooth Earphones, one in black and one in white, displayed side-by-side, showcasing their distinct mecha-inspired charging cases and earbuds.

SETUP

1. Charging the Device

Before first use, fully charge the earphones and the charging case.

1. Place both earphones into the charging case.
2. Connect the USB charging cable to the charging port on the case and plug the other end into a USB power source (e.g., computer, wall adapter).
3. The indicator lights on the case will show charging status.
4. Charging time for earphones is approximately 1 hour. Charging time for the case is approximately 2 hours.

2. Pairing with a Bluetooth Device

Follow these steps to pair your earphones with your smartphone or other Bluetooth-enabled device:

1. Ensure the earphones are fully charged.
2. Open the charging case. The earphones will automatically enter pairing mode (indicator lights will

flash).

3. On your device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices. You should see "WEKOME VB07" or similar in the list.
5. Select "WEKOME VB07" to connect. Once connected, the earphone indicator lights will stop flashing.
6. The earphones will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Open the charging case, and the earphones will automatically power on.
- **Power Off:** Place the earphones back into the charging case and close the lid. They will automatically power off and begin charging.

Music Playback Controls

The earphones feature touch controls for easy management of your audio:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Volume Up:** Triple tap on the right earbud.
- **Volume Down:** Triple tap on the left earbud.

Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

MAINTENANCE

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earphones and charging case. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use, store the earphones in their charging case to protect them and keep them charged. Store in a cool, dry place away from direct sunlight.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Solution
---------	----------

Problem	Solution
Earphones not pairing	<ul style="list-style-type: none"> • Ensure earphones are charged. • Turn off and on Bluetooth on your device. • Forget "WEKOME VB07" from your device's Bluetooth list and try pairing again. • Place earphones back in case, close lid, wait 5 seconds, then open again to re-enter pairing mode.
No sound from one earbud	<ul style="list-style-type: none"> • Ensure both earbuds are charged. • Place both earbuds back in the charging case, close the lid, and then take them out again. • Try resetting the earphones (refer to manufacturer's website if specific reset instructions are not in this manual).
Charging case not charging	<ul style="list-style-type: none"> • Check the USB cable and power adapter. • Ensure the charging port is clean and free of debris. • Try a different USB port or power source.
Poor audio quality	<ul style="list-style-type: none"> • Ensure the earphones are within the 10m transmission distance of your device. • Remove any obstacles between the earphones and your device. • Try disconnecting and reconnecting the Bluetooth connection.

SPECIFICATIONS

Model	IP6D1244B
Bluetooth Version	V5.3
Transmission Distance	10 meters
Driver Unit	13mm
Frequency Response	20Hz-20kHz
Charging Box Battery Capacity	500mAh
Headphone Battery Capacity	30mAh
Playing Time	4-5 hours
Standby Time (off state)	60 days
Earphone Charging Time	1 hour
Charging Case Charging Time	2 hours
Material	Plastic

Special Features	Lightweight, Mecha shape, Illusion lighting effect, Low latency, Semi-in-ear design
-------------------------	---

WARRANTY AND SUPPORT

This product is covered by a standard warranty as per the terms and conditions of ELECTROPRIME. Please refer to your purchase documentation or the official ELECTROPRIME website for detailed warranty information and support contacts.

For technical assistance, troubleshooting, or warranty claims, please contact ELECTROPRIME customer support through their official channels.

© 2024 ELECTROPRIME. All rights reserved.