

Beetel H27

Beetel H27 Portable Hotel Cordless Landline Phone User Manual

Model: H27

1. INTRODUCTION

Thank you for choosing the Beetel H27 Portable Hotel Cordless Landline Phone. This manual provides essential information for setting up, operating, and maintaining your new telephone. The H27 is designed for reliable communication with features tailored for convenience and clarity.



Figure 1: Beetel H27 Phone - Elegant Design

2. WHAT'S IN THE BOX

Please check the package contents carefully. If any items are missing or damaged, contact your retailer.

- Beetel H27 Landline Phone Unit
- Handset Cord
- Line Cord
- User Manual (this document)

3. SETUP

Follow these steps to set up your Beetel H27 phone:

1. **Connect the Line Cord:** Plug one end of the telephone line cord into the jack labeled 'LINE' on the back or side of the phone unit. Plug the other end into your wall telephone jack.
2. **Connect the Handset Cord:** Plug one end of the coiled handset cord into the handset and the other end into the jack labeled 'HANDSET' on the phone unit.
3. **Placement:** Place the phone on a flat, stable surface (desk mount) or mount it on a wall using the integrated magnetic effect for secure holding. Ensure it is near a telephone wall jack.



Figure 2: Wall Mountable Design with Magnetic Hold

4. OPERATING INSTRUCTIONS

4.1 Making a Call

1. Lift the handset.
2. Listen for a dial tone.
3. Dial the desired telephone number using the keypad.

4.2 Receiving a Call

1. When the phone rings and the Ringer LED illuminates, lift the handset to answer.
2. To end the call, place the handset back on the base.

4.3 Adjusting Volume

- **Receiver Volume:** The handset features a 3-step receiver volume adjustment for comfortable listening. Adjust as needed during a call.
- **Ringer Volume:** The phone offers a 2-step ringer volume control (Hi-Low) to suit your environment.




Figure 3: 3-Step Ringer Volume Control




Figure 4: 2-Step Adjustable Ringer Volume

4.4 Hold Function

During a call, press the **HOLD** button to place the call on hold. An LED indicator will illuminate to show the call is on hold. Press **HOLD** again to resume the conversation.

4.5 Speed Dial Memory

The phone supports 8 numbers for speed dial memory. Refer to the programming section (if available in a detailed manual) or contact support for instructions on how to program these numbers.

MAGNETIC EFFECT TO HOLD HANDSET IN WALL MOUNT



Figure 5: Handset with Speed Dial Capability

5. FEATURES OVERVIEW

- **3-Step Headset and 2-Step Ringer Volume Adjustment:** Customize audio levels for both incoming calls and your listening comfort.
- **Hold Function with LED Indication:** Easily place calls on hold with a clear visual indicator.
- **Support Tone Dialing:** Compatible with modern telephone systems for efficient dialing.
- **8 Numbers of Speed Dial Memory:** Store frequently called numbers for quick access.
- **Message Waiting Light (MWL):** An indicator light notifies you of new messages (requires compatible PBX system).
- **Hearing Aid Compatible (HAC) Handset:** Designed for users with hearing aids, reducing interference.
- **Programmable Flash Timing:** Adjustable flash timing (100mS to 1000mS) for compatibility with various PBX systems. Default is 300ms.

- **Ringer LED Indication:** A visual alert for incoming calls, useful in noisy environments or for hearing-impaired users.



Figure 6: Ringer LED Indicator

Your browser does not support the video tag.

Video 1: Overview of Beetel H27 Features. This video demonstrates key functionalities such as hold, tone dialing, speed dial, message waiting light, hearing aid compatibility, and programmable flash timing.

6. MAINTENANCE

To ensure the longevity and optimal performance of your Beetel H27 phone, follow these maintenance guidelines:

- **Cleaning:** Wipe the phone's surface with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Avoid Liquids:** Keep the phone away from water and other liquids.
- **Temperature:** Avoid exposing the phone to extreme temperatures or direct sunlight.
- **Storage:** If storing the phone for an extended period, disconnect it from the telephone line.

7. TROUBLESHOOTING

If you encounter issues with your Beetel H27 phone, try the following solutions:

- **No Dial Tone:**
 - Ensure the line cord is securely connected to both the phone and the wall jack.
 - Test the wall jack with another working phone to confirm line service.
- **No Ring:**
 - Check the ringer volume setting; ensure it is not set to the lowest level.
 - Verify the telephone line is active.

- **Poor Sound Quality:**

- Adjust the receiver volume.
- Check for interference from other electronic devices.
- Ensure the handset cord is securely connected.

- **Hold Function Not Working:**

- Ensure the phone is connected to a compatible telephone system.

If the problem persists after trying these steps, please contact customer support.

8. SPECIFICATIONS

Feature	Description
Brand	Beetel
Model Number	H27
Telephone Type	Corded Landline Phone
Power Source	Corded Electric
Material	Plastic
Dialer Type	Single Keypad (Tone Dialing)
Receiver Volume	3-Step Adjustable
Ringer Volume	2-Step Adjustable (Hi-Low)
Hold Function	Yes, with LED Indication
Speed Dial Memory	8 Numbers
Message Waiting Light (MWL)	Yes
Hearing Aid Compatible (HAC)	Yes
Programmable Flash Timing	100mS to 1000mS (Default 300ms)
Ringer LED Indication	Yes
Item Dimensions	5.5 x 20 x 5.5 Centimeters
Item Weight	300 Grams
Country of Origin	India

9. WARRANTY AND SUPPORT

Your Beetel H27 Portable Hotel Cordless Landline Phone comes with a **1 Year Manufacturer Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or further assistance, please contact Beetel Teletech Limited customer service.

Keep your purchase receipt as proof of purchase.

Manufacturer Contact Information: Beetel Teletech Limited

© 2026 Beetel Teletech Limited. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question