

[Manuals.plus](#) /

› [Enbrighten](#) /

› Enbrighten Warm White LED Landscape Lights (Model 56064-S1) Instruction Manual

Enbrighten 56064-S1

Enbrighten Warm White LED Landscape Lights (Model 56064-S1) Instruction Manual

INTRODUCTION

Thank you for choosing Enbrighten Warm White LED Landscape Lights. This manual provides important information regarding the installation, operation, and maintenance of your new landscape lighting system. Please read these instructions thoroughly before installation and retain them for future reference.

This system features 6 warm white LED puck lights on a 40-foot black cord, designed for outdoor use to enhance your garden, walkways, driveways, and other outdoor areas with accent lighting.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or injury to persons, follow these instructions carefully.

- Ensure the power supply is disconnected before installation or servicing.
- This product is intended for outdoor use and is weather-resistant. However, avoid submerging the power supply or connections in water.
- Do not operate the lighting system with damaged cords or if the housing is compromised.
- Use only the power supply provided with this product.
- Keep children and pets away from the installation area.
- Do not attempt to modify or repair the product yourself. Contact customer support for assistance.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 6 x Enbrighten Warm White LED Puck Lights
- 1 x 40ft Black Cord with integrated lights
- 1 x Power Supply

- Mounting Hardware (stakes for ground installation, screws for surface mounting)
- Instruction Manual

SETUP AND INSTALLATION

The Enbrighten LED Landscape Lights offer flexible installation options. Choose the method best suited for your outdoor space.

Option 1: Ground Stake Installation

1. **Plan Placement:** Determine the desired locations for each of the 6 puck lights along your walkway, garden, or driveway. Ensure the 40ft cord length is sufficient for your layout.
2. **Attach Stakes:** Securely attach a ground stake to the bottom of each puck light.
3. **Insert Lights:** Gently push each staked light into the ground at your chosen locations. Ensure they are stable and upright.
4. **Route Cable:** Lay the black cord along your desired path. The burial-grade cable allows for winding around corners and can be buried shallowly to maintain a clean appearance.
5. **Connect Power:** Plug the power supply into a suitable outdoor-rated 120V AC outlet.

Option 2: Surface Mounting (via Keyholes)

1. **Plan Placement:** Identify surfaces such as decks, eaves, or walls where you wish to mount the lights.
2. **Mark Holes:** Use the keyholes on the back of each puck light as a template to mark drilling locations on your chosen surface.
3. **Drill Pilot Holes:** Drill appropriate pilot holes for the included mounting screws.
4. **Mount Lights:** Secure each puck light to the surface using the provided screws.
5. **Route Cable:** Route the black cord neatly along the mounting surface. Use cable clips (not included) if necessary for a tidy installation.
6. **Connect Power:** Plug the power supply into a suitable outdoor-rated 120V AC outlet.



Image: Enbrighten Warm White LED Landscape Lights with 6 puck lights and a 40ft black cord, shown installed in an outdoor garden setting, illuminating a pathway.

OPERATING INSTRUCTIONS

Operating your Enbrighten LED Landscape Lights is straightforward:

- **Power On/Off:** Locate the ON/OFF button on the power supply. Press the button once to turn the lights ON. Press it again to turn the lights OFF.
- **Light Output:** The lights will emit a warm white (3000K) light, providing 600 lumens of brightness for accent lighting.

MAINTENANCE

To ensure the longevity and optimal performance of your Enbrighten LED Landscape Lights, follow these maintenance guidelines:

- **Cleaning:** Periodically wipe the light fixtures with a soft, damp cloth to remove dirt, dust, or debris. Do not use abrasive cleaners or solvents.
- **Inspection:** Regularly inspect the power cord and light fixtures for any signs of damage, such as cuts, fraying, or cracks. If damage is found, discontinue use and contact customer support.
- **LEDs:** The integrated LEDs are designed for a lifetime of use and do not require replacement.
- **Winterization:** While weather-resistant, in areas with extreme winter conditions, consider storing the lights indoors.

during the harshest months to prolong their lifespan.

TROUBLESHOOTING

If you encounter issues with your landscape lights, refer to the following common solutions:

Problem	Possible Cause	Solution
Lights do not turn on.	No power to the outlet. Power supply not connected. ON/OFF button not pressed. Damaged cord or power supply.	Check the outlet with another device. Ensure the power supply is securely plugged in. Press the ON/OFF button on the power supply. Inspect for damage; if damaged, discontinue use and contact support.
Lights are dim or flickering.	Inconsistent power supply. Loose connection.	Ensure the power outlet is stable. Check all connections for tightness.
Water inside light fixture.	Seal compromised.	Discontinue use immediately. Contact customer support.

If these steps do not resolve the issue, please contact Enbrighten customer support.

SPECIFICATIONS

Model Number:	56064-S1
Brand:	Enbrighten
Light Source:	Integrated LED
Number of Lights:	6
Light Color:	Warm White (3000K)
Brightness:	600 Lumens (total)
Cord Length:	40 feet
Power Source:	Corded Electric (120V AC)
Control Method:	Push Button (on power supply)
Material:	Metal (fixture), Plastic (shade)
Color:	Black
Indoor/Outdoor Usage:	Outdoor
Water Resistance Level:	Water Resistant
Mounting Type:	Floor Mount (stakes) / Surface Mount (keyholes)

WARRANTY AND SUPPORT

Enbrighten products are designed for quality and durability. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Enbrighten website.

If you require technical assistance, have questions about your product, or need to report a defect, please contact Enbrighten customer support:

- **Website:** www.enbrighten.com (Note: This is a placeholder URL, please refer to your product packaging for the correct support website.)
- **Phone:** Refer to your product packaging or the Enbrighten website for current contact numbers.

Please have your model number (56064-S1) and purchase date available when contacting support.

