

Frigelux RDP215NE

Frigelux RDP215NE Double Door Refrigerator User Manual

Model: RDP215NE

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your new Frigelux RDP215NE refrigerator. Keep this manual for future reference. Failure to follow these safety instructions may result in fire, electric shock, or injury.

- Ensure the appliance is properly grounded.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not damage the refrigerant circuit.
- This appliance is intended for household use only.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Unplug the appliance before cleaning or performing maintenance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.

2. SETUP AND INSTALLATION

2.1 Unpacking

Carefully remove all packaging materials, including foam and adhesive tape. Dispose of packaging responsibly. Ensure no parts are missing or damaged. It is recommended to keep the packaging for potential future transport.

2.2 Placement

Place the refrigerator on a firm, level surface away from direct sunlight, heat sources (such as stoves, heaters), and extreme cold. Allow sufficient space around the appliance for proper ventilation. The dimensions of the product are 53 cm (Depth) x 54 cm (Width) x 143 cm (Height).



Image: The FrigeluX RDP215NE refrigerator positioned in a room, illustrating typical placement during setup or moving.

2.3 Leveling

Adjust the leveling feet at the bottom of the refrigerator to ensure it is stable and level. This prevents vibrations and ensures proper door sealing.

2.4 Door Reversal

The FrigeluX RDP215NE features reversible doors, allowing you to change the opening direction to suit your kitchen layout. Refer to the detailed diagram in the full manual for specific instructions on how to reverse the doors.

2.5 Power Connection

Connect the appliance to a dedicated 240 Volt power outlet (Type E – 2 pins, suitable for France). After moving or installing the refrigerator, wait at least 2-4 hours before plugging it in. This allows the refrigerant to settle, preventing damage to the cooling system.

3. OPERATING INSTRUCTIONS

3.1 Temperature Control

The refrigerator is equipped with a mechanical thermostat for temperature adjustment. Turn the dial inside the refrigerator compartment to set the desired cooling level. Higher numbers typically indicate colder temperatures.

3.2 Storage Compartments

The FrigeluX RDP215NE offers a total net capacity of 204 Liters, with 167 Liters for the refrigerator and 37 Liters for the freezer.



Image: Interior view of the FrigeluX RDP215NE, showing the refrigerator and freezer compartments with shelves and door balconies.

Refrigerator Section (167 L)

- **Shelves:** Features 3 glass shelves for organized storage of various food items.
- **Door Balconies:** Includes 3 door balconies for bottles and smaller items.
- **Vegetable Crisper:** A dedicated drawer for keeping fruits and vegetables fresh.

Freezer Section (37 L)

- **Shelf:** Equipped with 1 glass shelf.
- **Ice Cube Tray:** A convenient tray for making ice.
- **Freezing Capacity:** Capable of freezing 2 kg of fresh food within 24 hours.

3.3 Interior LED Lighting

The refrigerator compartment is illuminated with energy-efficient LED lighting, providing clear visibility of your stored items.

4. MAINTENANCE

4.1 Defrosting

- **Refrigerator Compartment:** The refrigerator section features an automatic defrosting system, minimizing ice buildup and reducing the need for manual defrosting.
- **Freezer Compartment:** The freezer compartment requires manual defrosting when ice accumulation becomes excessive (approximately 5mm thick). To defrost, unplug the appliance, remove all food, and allow the ice to melt naturally. Clean and dry the interior thoroughly before restarting.

4.2 Cleaning

Always unplug the refrigerator before cleaning. Use a soft cloth with a mild detergent and warm water to clean the interior and exterior surfaces. Avoid abrasive cleaners or solvents. Regularly clean the door seals to ensure a tight closure.

5. TROUBLESHOOTING

Before contacting customer service, please check the following common issues:

Problem	Possible Cause	Solution
Refrigerator not cooling	Power outage; plug not inserted; temperature setting too high; door left open.	Check power supply; ensure plug is secure; adjust thermostat to a colder setting; ensure door is closed properly.
Unusual noises	Appliance not level; items touching the back wall; compressor noise (normal).	Level the appliance; rearrange items; normal operating sounds are expected.
Water on floor/inside	Drain hole blocked; door not sealed properly.	Clear the drain hole; check door seals for obstructions or damage.

6. SPECIFICATIONS

Detailed technical specifications for the FrigeluX RDP215NE refrigerator:




Image: Energy label for the Frigelux RDP215NE, showing energy class E, 172 kWh/annum consumption, 37L freezer, 167L refrigerator, and 41 dB noise level. For more details, visit [EPREL Database](#).

Feature	Value
Product Dimensions (D x W x H)	53P x 54W x 143H cm
Brand	Frigelux
Total Capacity	204 Liters
Configuration	Internal Freezer
Color	Black
Installation Type	Freestanding
Number of Doors	2
Defrost System	Automatic (Refrigerator)

Feature	Value
Voltage	240 Volts
Shelf Type	Glass
Product Format	Compact
Cooling Method	Thermoelectric
Number of Shelves	4 (total)
Adjustable Temperature Control	Yes
Electrical Plug	Type E – 2 pins (France)
Door Position	Left (Reversible)
Freezer Capacity	37 Liters
Item Weight	38 Kilograms
Annual Energy Consumption	172 kWh per year
Net Refrigerator Capacity	167 Liters
Refrigerant	Environmentally friendly refrigerant adapted to the European market
Door Finish	Solid
Model Number	RDP215NE
Manufacturer	Frigelux
Country of Origin	China

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This Frigelux RDP215NE refrigerator comes with a **2-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and malfunctions under normal household use.

7.2 Customer Support

For technical assistance, spare parts, or warranty service, please contact Frigelux customer support. You can typically find contact information on the manufacturer's official website or through your retailer. When contacting support, please have your model number (RDP215NE) and purchase date ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question