

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Panasonic](#) /

› [Panasonic ES-CM3A-W Travel Shaver User Manual](#)

Panasonic ES-CM3A

Panasonic ES-CM3A-W Travel Shaver User Manual

MODEL: ES-CM3A-W

1. Introduction

This manual provides essential instructions for the safe and effective use of your Panasonic ES-CM3A-W Travel Shaver. Please read this manual thoroughly before using the product and retain it for future reference. This compact electric shaver is designed for convenient grooming on the go, offering both wet and dry shaving capabilities with a USB-C charging system.

2. Important Safety Information

WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons:

- Always unplug this appliance from the electrical outlet immediately after using, except when charging.
- Unplug this appliance before cleaning.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not use while bathing or in a shower if not specifically designed for wet use. This model is IPX7 waterproof, allowing for wet use and rinsing, but ensure the charging port is dry before connecting the charger.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended household use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water.

3. Package Contents

Verify that all items are included in your package:

- Panasonic ES-CM3A-W Travel Shaver
- Travel Cap

- USB-C Charging Cable
- Cleaning Brush
- Blade Oil (small bottle)

4. Product Overview

The Panasonic ES-CM3A-W is a compact electric shaver designed for efficiency and portability. It features a 3-blade cutting system with hypoallergenic stainless steel blades for a smooth, irritation-free shave.




TOUCH UP ANYWHERE, ANYTIME

Lightweight, compact design is easy to take with you to the gym, work, on vacation



QUICK, EASY CHARGING

USB-C charging makes it easy to charge in the car, on the plane and more



EFFORTLESS MANEUVERABILITY

Ergonomic design quickly moves over body contours for smooth motions and even results



SHAVE DRY OR WET

Ideal for quick dry touch-ups, or a full shave in the shower



GENTLE FOR SENSITIVE SKIN

Hypoallergenic stainless steel blades minimize sensitivity



Image: The Panasonic ES-CM3A-W Travel Shaver, showcasing its compact design and highlighting features such as quick charging, effortless maneuverability, wet/dry shaving, and gentle blades for sensitive skin.

The shaver's intuitive design includes a simple swipe mechanism for power control and a removable outer foil for easy cleaning. Its ergonomic shape fits comfortably in your hand, providing total control over body contours.



HYPOALLERGENIC STAINLESS STEEL BLADES

Don't settle for one-time razors—choose smooth skin without the irritation, especially when dry shaving

Image: A close-up view of the shaver's cutting head, revealing the three hypoallergenic stainless steel blades designed for a close and comfortable shave.

5. Charging the Shaver

Your Panasonic ES-CM3A-W shaver is equipped with a convenient USB-C charging port.

1. Ensure the shaver is completely dry before charging.
2. Locate the USB-C port, typically on the bottom of the shaver.
3. Connect the provided USB-C charging cable to the shaver and plug the other end into a compatible USB power source (e.g., wall adapter, computer, car charger).
4. The charging indicator lights will illuminate to show the charging status.
5. A full charge typically takes approximately 1 hour and provides up to 40 minutes of cordless operation.



CHARGE AND GO WITH USB-C

Easy, universal charging plugs in anywhere, so you can take it wherever you go

Image: The shaver connected to a USB-C charging cable, illustrating the charging process.



Image: The shaver being charged via USB-C in a car, highlighting its versatility for on-the-go charging.

6. Initial Setup

Before your first use, ensure the shaver is fully charged. The shaver comes with a travel cap for protection.

- 1. Unpacking:** Carefully remove the shaver and all accessories from the packaging.
- 2. Initial Charge:** Charge the shaver fully as described in Section 5.
- 3. Removing the Travel Cap:** Gently slide the travel cap off the shaver head.



LIGHTWEIGHT AND TRAVEL-READY

Slip it into your bag to keep for quick touch-ups and emergencies

Image: The compact shaver being placed into a bag, emphasizing its portability and ease of storage for travel.

7. Operating Instructions

The Panasonic ES-CM3A-W shaver is designed for both wet and dry use, providing flexibility for your grooming routine.

7.1 Turning On/Off

The shaver features a unique swipe mechanism for activation:

- To turn **ON**: Slide the power switch to the right.
- To turn **OFF**: Slide the power switch to the left.

7.2 Shaving Technique

For optimal results and to minimize irritation:

- Hold the shaver at a 90-degree angle to your skin.
- Apply gentle pressure and move the shaver slowly against the direction of hair growth.
- Stretch your skin taut with your free hand to help the blades capture hairs more effectively.
- The shaver is suitable for use on various body parts including armpits, chest, face, and legs.



EASY TO MANEUVER

Compact shaver fits comfortably in your hand and gives you total shaving control around the contours of your bodyshave body

Image: A user demonstrating the shaver's easy maneuverability while shaving their leg.



Image: A collage illustrating the versatile use of the shaver on different body areas, including armpits, face, and legs.

7.3 Wet and Dry Use

- **Dry Shaving:** Ideal for quick touch-ups anytime, anywhere.
- **Wet Shaving:** For a more comfortable and thorough shave, use with shaving foam or gel in the shower or bath. The shaver is IPX7 waterproof.

8. Cleaning and Maintenance

Regular cleaning ensures optimal performance and hygiene for your shaver.

8.1 Daily Cleaning (Rinsing)

1. After each use, turn off the shaver.
2. Rinse the shaver head thoroughly under running water. The IPX7 waterproof design allows for easy rinsing.
3. Shake off excess water and allow the shaver to air dry completely before attaching the travel cap or storing.



WET-DRY SHAVING
IPX7 showerproof design

Image: The shaver head being rinsed under a faucet, demonstrating the ease of cleaning due to its waterproof design.



Image: Another view of the shaver being rinsed under water, emphasizing its suitability for shower use and easy cleaning.

8.2 Deep Cleaning (Foil and Blades)

1. Turn off the shaver and remove the outer foil frame.
2. Use the provided cleaning brush to remove any trapped hair from the inner blades and outer foil.
3. Apply a drop of blade oil to each inner blade and the outer foil to maintain smooth operation and prolong blade life.
4. Reattach the outer foil frame securely.

9. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully.
Shaver does not provide a close shave.	Blades are dull or clogged with hair. Incorrect shaving technique.	Clean the shaver thoroughly. Apply blade oil. Ensure you are shaving against hair growth with gentle pressure. Consider replacing blades if they are old.
Skin irritation after shaving.	Excessive pressure. Dry shaving on sensitive skin.	Use lighter pressure. Try wet shaving with foam/gel. Ensure blades are clean and sharp.
Charging indicator not lighting up.	Cable not connected properly. Faulty cable or power source.	Ensure USB-C cable is securely connected. Try a different USB-C cable or power source.

10. Specifications

- Model Name:** Swipe Right Compact Shaver
- Item Model Number:** ES-CM3A-W
- Brand:** Panasonic
- Power Source:** Battery Powered (1 Lithium Ion battery included)
- Special Features:** Dry Shave, Ergonomic Design, Portable, Shave Sensor, Waterproof (IPX7)
- Recommended Uses:** Armpit, Chest, Face, Leg
- Package Dimensions:** 6.54 x 4.69 x 2.24 inches
- Item Weight:** 9.45 ounces
- UPC:** 885170432666
- ASIN:** B0D234CZ9P
- Manufacturer:** Panasonic

11. Warranty and Support

For warranty information, product registration, or customer support, please refer to the warranty card included in your product packaging or visit the official Panasonic website. Keep your purchase receipt as proof of purchase for any warranty claims.