

BoxWave AccuPoint Active Stylus

BoxWave AccuPoint Active Stylus User Manual

Model: AccuPoint Active Stylus

Compatible with Honor Choice Watch

1. INTRODUCTION

The BoxWave AccuPoint Active Stylus is an electronic stylus designed for precise interaction with touchscreens, including the Honor Choice Watch. It features an ultra-fine tip and operates by emitting electronic pulses, eliminating the need for Bluetooth pairing. This manual provides instructions for its setup, operation, and maintenance.



Image 1.1: The AccuPoint Active Stylus shown alongside an Honor Choice Watch, illustrating its compatibility and sleek design.



Image 1.2: A visual representation of the AccuPoint Active Stylus, highlighting its design as a 2-in-1 stylus pen.

2. SETUP

2.1 Initial Charging

Before first use, fully charge the stylus. Connect the included MicroUSB cable to the charging port on the stylus and to any standard USB power source (e.g., computer, wall adapter). The indicator light will show the charging status.

2.2 Powering On/Off

To turn on the stylus, press the power button located on the barrel. The indicator light will illuminate. To turn off the stylus, press the power button again.



Image 2.1: Illustration of the stylus charging process, showing the MicroUSB port and the indicator lights for different charging states (blue for power on, red for charging, green for full charge).



Image 2.2: The stylus being charged by connecting its MicroUSB cable to a laptop, demonstrating convenient charging options.

3. OPERATING INSTRUCTIONS

The AccuPoint Active Stylus does not require Bluetooth pairing. Simply turn it on and begin using it with your touchscreen device.

3.1 Basic Operation

Use the ultra-fine tip to interact with your screen. The stylus emits electronic pulses that allow for precise tapping, swiping, and drawing, mimicking the feel of a traditional pen.

- **Tapping:** Lightly touch the screen with the stylus tip to select items or activate functions.
- **Swiping:** Drag the stylus tip across the screen to scroll or navigate.
- **Drawing/Writing:** Apply light pressure and move the stylus tip to draw or write on compatible applications.



Tap, Swipe, or Write Naturally With the AccuPoint Active Stylus

No pairing required! The AccuPoint Active Stylus emits quick electronic pulses to interact with your device's screen.

(Please note: the AccuPoint Active Stylus does not support palm rejection)

BoxWave AccuPoint Active Stylus

Image 3.1: A hand demonstrating natural writing and interaction with a tablet using the AccuPoint Active Stylus, emphasizing no pairing is required.




Image 3.2: A detailed view of the stylus tip interacting with a touchscreen, showing its precision for selecting applications.

4. MAINTENANCE

4.1 Charging

The built-in battery provides approximately 12 hours of continuous use on a full charge. Recharge the stylus when the indicator light signals low battery or when performance diminishes. Use the provided MicroUSB cable for charging.

4.2 Cleaning and Care

To maintain optimal performance, keep the stylus tip clean and free from debris. Use a soft, dry cloth to gently wipe the stylus body and tip. Avoid using harsh chemicals or abrasive materials.

5. TROUBLESHOOTING

- **Stylus not responding:**
 - Ensure the stylus is powered on (check indicator light).
 - Charge the stylus fully. A low battery can affect performance.
 - Ensure the device screen is clean and free of smudges.
- **Inaccurate input:**
 - Check if the stylus tip is damaged or worn.
 - Clean the stylus tip and the device screen.

6. SPECIFICATIONS




Image 6.1: A visual breakdown of the stylus's core features, including its active electronic signal, precise tip, FiberMesh tip, and rechargeable design.










Image 6.2: An annotated diagram detailing the physical features and specifications of the AccuPoint Active Stylus.

Feature	Detail
Model	AccuPoint Active Stylus
Tip Size	1.9mm / 2mm Ultra Fine Tip
Material	Aluminum, Metal, Plastic (Solid brushed aluminum barrel)
Battery Type	Built-in Product Specific battery (included)
Battery Life (Active Use)	Approximately 12 hours
Charging Port	MicroUSB
Item Weight	1.3 ounces
Color	Metallic Silver

7. IMPORTANT NOTES

- The AccuPoint Active Stylus **does not support Palm Rejection**. Ensure your hand does not touch the screen while using the stylus if palm rejection is desired.
- The AccuPoint Active Stylus **does not support Pressure Sensitivity**. Input will be consistent regardless of pressure applied.
- The Honor Choice Watch device is not included with the stylus.

 <p>DOUXE S3 Active Stylus Pen</p> <p>Instruction Manual</p>	<p>DOUXE S3 Active Stylus Pen Instruction Manual</p> <p>Comprehensive instruction manual for the DOUXE S3 Active Stylus Pen, detailing features, technical specifications, operating instructions, safety warnings, and warranty information for touchscreen device users.</p>
	<p>Penyeah Stylus Pen User Manual - DIY Combinations and Usage Guide</p> <p>Comprehensive user manual for the Penyeah P1 stylus pen, detailing DIY combinations of tips, usage instructions, and replacement procedures. Learn how to maximize your stylus experience for various devices and applications.</p>
 <p>sbs</p> <p>Ultra Fine Stylus Pen Designed for iPad 2018, 2019, 2020, 2021</p>	<p>SBS Ultra Fine Stylus Pen for iPad: Precision, Tilt Function, and Style</p> <p>Discover the SBS Ultra Fine Stylus Pen (Tilt Pencil) for iPad 2018-2021. Featuring tilt function, palm rejection, durable aluminum design, and a replaceable POM nib for precise, lag-free drawing and writing.</p>
 <p>POWEROLOGY</p> <p>NÉOTEC Active Stylus Pen SKU: PGBSTPN</p>	<p>Powerology NÉOTEC Active Stylus Pen - User Manual and Specifications</p> <p>Comprehensive guide to the Powerology NÉOTEC Active Stylus Pen (SKU: PGBSTPN), covering operation, features, specifications, compatible iPad models, and warranty information.</p>
 <p>ASUS ASUS PEN SA300</p>	<p>ASUS Pen SA300 Quick Start Guide</p> <p>This guide provides instructions on how to use and maintain the ASUS Pen SA300 Active Stylus, including package contents, inserting and replacing the battery, and replacing the pen tip and holder.</p>
 <p>ASUS</p>	<p>ASUS Pen 2.0 (SA203H) Active Stylus: Quick Start Guide</p> <p>Get started with your ASUS Pen 2.0 (SA203H) Active Stylus. This guide covers package contents, LED indicators, hardware interface, charging, and Bluetooth pairing instructions.</p>

