

Aquasonic ASFLOSBLU

AquaSonic Water Flosser ASFLOSBLU - User Manual

Brand: Aquasonic | Model: ASFLOSBLU

1. PRODUCT OVERVIEW

The AquaSonic Water Flosser is a cordless, rechargeable oral irrigator designed for effective teeth cleaning and gum health. It utilizes targeted water jets to remove food particles and plaque, offering a convenient and efficient alternative to traditional flossing.

- **Powerful Cleaning:** Rechargeable lithium-ion battery delivers targeted water jets for effective food particle and plaque removal.
- **Versatile Modes:** Features 3 flossing modes (Normal, Soft, Pulse) to suit various oral care needs.
- **Comprehensive Tips:** Includes 5 interchangeable jet tips for specialized care, such as standard, periodontal, orthodontic, and tongue scraper tips.
- **Gentle Gum Stimulation:** Helps stimulate gums to promote circulation and overall gum health.
- **Portable Design:** Lightweight, fully waterproof, and travel-ready with a long-lasting battery and dual voltage support (110V & 220V).
- **Ideal for Specific Needs:** 360-degree rotating tips make it suitable for individuals with braces, dental work, or hard-to-reach areas.



Image 1.1: The AquaSonic Water Flosser in Sapphire Blue with its included accessories, including various jet tips and a travel bag.

2. SAFETY INFORMATION

- Always read and follow the instructions provided with the product.
- Keep the device away from children.
- Do not use with certain medical conditions; consult a healthcare professional if unsure.
- Ensure the charge port is covered during use to prevent water damage.

3. PACKAGE CONTENTS

Your AquaSonic Water Flosser package includes:

- 1 x AquaSonic Water Flosser Unit (Sapphire Blue)
- 2 x Standard Jet Tips
- 1 x Periodontal Tip
- 1 x Orthodontic Tip

- 1 x Tongue Scraper Tip
- 1 x Charging Cable
- 1 x Soft-Touch Travel Bag

Exceptional Value

Soft-Touch Travel Bag

**2 Standard Tips
1 Periodontal Tip
1 Orthodontic Tip
1 Tongue Scraper Tip**



Image 3.1: The AquaSonic Water Flosser package contents, including the main unit, five specialized jet tips, and a travel bag.

4 Types of Tips

Standard Tip

creates an ultra-fine jet stream for cleaning between teeth and along the gumline

Orthodontic Tip

features soft bristles for dislodging plaque and debris from braces and dental work

Periodontal Tip

features a soft, rubberized tip for gently cleaning deep pockets below the gumline

Tongue Scraper Tip

is ideally shaped to clean the tongue



Image 3.2: A detailed view of the four types of tips included: Standard, Orthodontic, Periodontal, and Tongue Scraper.

4. SETUP

1. **Charge the Device:** Before first use, fully charge the AquaSonic Water Flosser using the provided charging cable. The device features a long-lasting lithium-ion battery.
2. **Attach a Jet Tip:** Select the desired jet tip (Standard, Periodontal, Orthodontic, or Tongue Scraper) and firmly insert it into the top of the flosser unit until it clicks into place.
3. **Fill the Water Reservoir:** Open the fill port on the side of the device. Fill the water reservoir with lukewarm water. For an enhanced experience, you may add a small amount of mouthwash. Close the fill port securely.

Advanced Design

Ultra-Fine Water Stream with
FreshJet Technology

360° Rotating Nozzle

Easy-to-Fill
Water Tank

3 Flossing
Modes

Rechargeable
Built-in Battery



Image 4.1: The advanced design of the AquaSonic Water Flosser, highlighting the 360° rotating nozzle, easy-to-fill water tank, and rechargeable battery.

5. OPERATING INSTRUCTIONS

1. **Select a Mode:** Press the 'Mode' button to cycle through the three pressure settings: 'Normal' for standard cleaning, 'Soft' for sensitive teeth and first-time users, and 'Pulse' for gum massage. The indicator light will show the selected mode.
2. **Position the Tip:** Lean over a sink and place the jet tip in your mouth, aiming it at your gumline at a 90-degree angle. Close your lips slightly to prevent splashing, but allow water to flow from your mouth into the sink.
3. **Turn On:** Press the 'On/Off' button to start the water flow.
4. **Floss:** Guide the water jet along your gumline, pausing briefly between teeth. Ensure you clean both the front and back surfaces of your teeth. The 360-degree rotating tip allows for thorough cleaning in all areas.
5. **Auto Shut-Off:** The device features a 2-minute auto shut-off for optimal cleaning time.

6. **Turn Off:** Press the 'On/Off' button again to stop the water flow.

3 Custom Modes

Normal

standard cleaning

Soft

gentle mode for sensitive teeth & gums

Pulse

massages gums



Image 5.1: Close-up of the AquaSonic Water Flosser's control panel, showing the On/Off button, Mode button, and indicator lights for Normal, Soft, and Pulse modes.

Flossing Made Easy



AquaSonic

Portable
Waterproof
Lightweight
Easy to Use

Image 5.2: A user demonstrating the ease of use and portability of the AquaSonic Water Flosser for daily oral hygiene.

Quickly and Easily **Cleans** **Between** Teeth and Gums



Image 5.3: An illustration showing the ultra-fine water stream effectively cleaning between teeth and along the gumline.

[Official Product Video: How To Use The AquaSonic Water Flosser](#)

Video 5.4: This official video from AquaSonic provides a detailed demonstration on how to properly use the AquaSonic Water Flosser for effective oral cleaning.

6. MAINTENANCE

- **Empty and Clean Reservoir:** After each use, empty any remaining water from the reservoir. Detach the reservoir and rinse it thoroughly with water.
- **Clean the Unit:** Wipe the exterior of the flosser unit with a soft, damp cloth. Do not immerse the main unit in water.
- **Dry Thoroughly:** Allow all parts to air dry completely before reassembling or storing the device.
- **Tip Replacement:** Replace jet tips every 3 months, or sooner if they show signs of wear.

7. TROUBLESHOOTING

If you encounter any issues with your AquaSonic Water Flosser, please refer to the following common solutions:

- **No Water Flow:** Ensure the reservoir is filled and the jet tip is securely attached. Check if the device is charged.
- **Weak Water Pressure:** Verify the selected mode is appropriate (e.g., not 'Soft' if stronger pressure is desired). Ensure the reservoir is adequately filled.
- **Device Not Turning On:** Confirm the device is fully charged. If the issue persists, contact customer support.
- **Leaking:** Ensure all components, especially the water reservoir and fill port, are securely closed and properly aligned.

For further assistance, please contact AquaSonic customer support.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	2.6 x 8.07 x 3.98 inches
Item Weight	15.2 ounces
Model Number	ASFLOSBLU
Batteries	1 Lithium Ion battery (included)
Power Source	Battery Powered
Special Features	Cordless, Portable, Rechargeable, Waterproof
Product Benefits	Removes Plaque, Gum Health
Unit Count	1.00 Count

9. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the official Aquasonic website or contact their customer service directly. Keep your purchase receipt for warranty claims.

10. LEGAL DISCLAIMER

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is intended for personal oral hygiene and is not a substitute for professional dental care.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question