

Wiflyer Z8103AX-G

Wiflyer AX3000 WiFi 6 Wireless Router Z8103AX-G User Manual

Model: Z8103AX-G

1. INTRODUCTION

This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your Wiflyer AX3000 WiFi 6 Wireless Router (Model Z8103AX-G). Please read this manual thoroughly before using the device to ensure proper functionality and optimal performance.

The Wiflyer AX3000 is a high-performance dual-band WiFi 6 router designed to deliver fast, stable, and secure wireless connectivity for your home or office. It features AX3000 speeds, multiple Gigabit ports, and advanced security protocols.



Image: A family using various devices, illustrating the router's capability to support multiple connected users simultaneously.

2. PACKAGE CONTENTS

Verify that your package contains the following items:

- Wiflyer AX3000 WiFi 6 Wireless Router (Z8103AX-G)
- Power Adapter
- Ethernet Cable
- Quick Installation Guide (this document)

3. PRODUCT OVERVIEW

3.1 Router Layout



Image: The Wiflyer AX3000 WiFi 6 Wireless Router, showcasing its design with multiple high-gain antennas.

3.2 Ports and Indicators



Fast Ethernet Ports

4 fast ethernet ports give you maximum wired speeds for PCs, smart TVs, giving you the best networking experience.



SMART TV



COMPUTER
SMART PHONES



VIDEO
GAMES



IP
CAMERA



PRINTERS

Image: Detailed view of the router's rear panel, highlighting the various ports and their functions.

- **DC Power Supply:** Connects to the included power adapter.
- **Power Connector:** For the power adapter.
- **USB Port:** For connecting USB storage devices or other compatible peripherals.
- **WAN Port (1x 1000Mbps):** Connects to your modem or internet service provider's (ISP) equipment.
- **LAN Ports (3x 1000Mbps):** Connects to wired devices such as computers, smart TVs, or gaming consoles.
- **MESH Button:** Used for setting up mesh networking with compatible Wiflyer devices.
- **LED Indicators:** Provide status information for power, internet connectivity, and Wi-Fi activity.

4. SETUP INSTRUCTIONS

4.1 Hardware Connection

1. **Position the Router:** Place the router in a central location in your home or office, away from obstructions and sources of interference (e.g., microwaves, cordless phones). Ensure the antennas are oriented vertically for optimal signal.
2. **Connect to Power:** Connect the power adapter to the router's DC Power Supply port and then plug it into a power outlet. Wait for the power LED indicator to turn solid.
3. **Connect to Modem:** Connect one end of the provided Ethernet cable to your modem's LAN port and the other end to the router's WAN port. Wait for the WAN LED indicator to show activity (usually blinking).
4. **Connect Wired Devices (Optional):** For wired connections, use Ethernet cables to connect your computers, gaming consoles, or other devices to the router's LAN ports.

4.2 Initial Configuration (Web Interface)

1. **Connect to Router:** Connect your computer or mobile device to the router's Wi-Fi network (SSID and password are usually printed on a label on the bottom of the router) or via an Ethernet cable to a LAN port.
2. **Access Web Interface:** Open a web browser and enter the default IP address (e.g., 192.168.1.1 or router.local) into the address bar. The exact address can be found on the router's label.
3. **Log In:** Enter the default username and password (usually admin for both, or as specified on the router's label).
4. **Run Setup Wizard:** Follow the on-screen instructions of the setup wizard to configure your internet connection type (e.g., DHCP, PPPoE), set a new Wi-Fi network name (SSID) and password, and change the router's login password for security.
5. **Save Settings:** Apply and save your settings. The router may restart.

5. OPERATING INSTRUCTIONS

5.1 Connecting to Wi-Fi

After initial setup, you can connect your wireless devices to the router's Wi-Fi network using the SSID and password you configured. The router supports dual-band operation (2.4GHz and 5GHz) for optimal performance across various devices.



High Performance Wi-Fi 6 Router



Image: Individuals working and gaming, demonstrating the router's capability to handle high-bandwidth activities.

5.2 Advanced Features

- **Guest Wi-Fi:** Create a separate Wi-Fi network for guests to provide internet access while keeping your main network secure. This can be configured via the web interface.
- **Parental Controls:** Manage internet access for specific devices, set time limits, or block certain websites. Access these settings in the router's web interface.

Secure Wi-Fi for Your Family




Image: Visual representation of security features and parental control options available through the router's interface.

- **Quality of Service (QoS):** Prioritize network traffic for specific applications (e.g., gaming, video streaming) to ensure smooth performance.
- **Mesh Networking:** The router supports mesh technology for extended coverage. Use the MESH button or web interface to set up a mesh network with compatible Wiflyer devices.

One-Click Mesh

Wiflyer's distinctive mesh bridging approach empowers effortless configuration that requires no App or Web setup




Image: An illustration of a mesh network setup across different rooms and floors of a house, indicating seamless Wi-Fi coverage.

- **VPN Support:** The router includes VPN client and server capabilities (PPTP, OpenVPN) for secure remote access and encrypted connections.

5.3 Security Features

The Wiflyer AX3000 router incorporates several security features to protect your network:

- **WPA/WPA2/WPA3 Encryption:** Supports the latest Wi-Fi encryption standards to secure your wireless network.
- **MAC White/Blacklist:** Control which devices can connect to your network based on their MAC addresses.
- **Firewall:** Provides network protection against unauthorized access.
- **Ad Blocking:** Integrated ad-blocking functionality to enhance browsing experience and security.

Ad Blocking functions and high end encryption protect your network safety
You could also monitor network guest and manage their access authority



Image: A screenshot of the router's administrative interface, highlighting options for network management and ad blocking.

6. MAINTENANCE

- **Firmware Updates:** Regularly check the Wiflyer support website for firmware updates. Updating your router's firmware can improve performance, add new features, and enhance security.
- **Router Placement:** Ensure the router is placed in an open area, free from physical obstructions and electronic devices that may cause interference.
- **Cleaning:** Keep the router clean and free of dust. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners.
- **Restarting:** If you experience network issues, try restarting the router by unplugging the power adapter for 10 seconds and then plugging it back in.

7. TROUBLESHOOTING

- **No Internet Access:**
 - Check if your modem is working correctly.

- Ensure the Ethernet cable is securely connected to the router's WAN port and your modem.
- Restart both your modem and router.
- Verify your internet connection settings in the router's web interface.

• **Weak Wi-Fi Signal:**

- Relocate the router to a more central position.
- Ensure antennas are properly oriented.
- Minimize interference from other electronic devices.
- Consider using a mesh system for larger homes.

• **Cannot Access Router's Web Interface:**

- Ensure your device is connected to the router's network (wired or wireless).
- Verify you are using the correct IP address (e.g., 192.168.1.1) and login credentials.
- Try clearing your browser's cache or using a different browser.
- Restart the router.

• **Slow Wi-Fi Speed:**

- Check for firmware updates.
- Ensure your devices support Wi-Fi 6 for optimal speeds.
- Reduce the number of active devices or bandwidth-intensive applications.
- Adjust QoS settings if necessary.

8. SPECIFICATIONS

Feature	Description
Model	Z8103AX-G
Brand	Wiflyer
Wi-Fi Standard	802.11ax (Wi-Fi 6), 802.11ac, 802.11a
Wi-Fi Speed	AX3000 (Up to 3000Mbps)
Frequency Band	Dual-Band (2.4GHz & 5GHz)
Ethernet Ports	1x 1000Mbps WAN, 3x 1000Mbps LAN
Antennas	10x 5dBi High Gain Antennas
Dimensions	8.35 x 2 x 8.35 inches
Item Weight	1.89 pounds
Special Features	MU-MIMO, OFDMA, Beamforming, Mesh Support, VPN, Parental Control, Ad Blocking
Compatible Devices	Personal Computer, Smartphone, Tablet

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Wiflyer products are covered by a limited warranty from the date of purchase. Please refer to the warranty card included with your product or visit the official Wiflyer website for detailed warranty terms and conditions.

9.2 Technical Support

For technical assistance, troubleshooting, or product inquiries, please visit the Wiflyer support website or contact their customer service. Contact information can typically be found on the Wiflyer official website or in the product packaging.

Online Resources:

- Wiflyer Official Website: [Visit the Wiflyer Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question