

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ytonet](#) /

› [Ytonet Coin Collection Book Holder Model 6657 Instruction Manual](#)

Ytonet 6657

Ytonet Coin Collection Book Holder Model 6657 Instruction Manual

Your guide to using and maintaining your Ytonet Coin Collection Book Holder.

1. PRODUCT OVERVIEW

The Ytonet Coin Collection Book Holder Model 6657 is designed for collectors to organize and protect their valuable coins and currency. This album features a durable, fireproof, and waterproof exterior, a secure combination lock, and a versatile interior with various pocket sizes to accommodate different collectibles.

It includes 13 coin pages and 12 currency sleeves, providing storage for up to 320 coins and 36 notes. The 3-ring binder mechanism allows for easy customization and expansion.



Image 1.1: The Ytonet Coin Collection Book Holder open, showcasing its capacity for coins and currency.

320 PCS COIN & 36 PCS CURRENCY COLLECTION ALBUM

It will keep your collections
neat and orderly




coins



Currency



postage stamp



badge



Image 1.2: The collection book's versatility for various collectibles including coins, currency, stamps, and badges.

2. INITIAL SETUP

2.1 Setting the Combination Lock

Your Ytonet Coin Collection Book Holder comes with a resettable 3-digit combination lock to secure your collection. Follow these steps to set your personal combination:

1. The default combination is usually **0-0-0**. Ensure the lock is set to this combination and open the zippers.
2. Locate the small reset button or lever on the side or bottom of the lock. Use a pen or a pointed object to press and hold this button.
3. While holding the reset button, set your desired 3-digit combination by turning the dials.
4. Release the reset button. Your new combination is now set.
5. Scramble the dials to lock the zippers. Test your new combination to ensure it opens the lock correctly.

Important: Remember your combination. There is no master key or override if you forget it.

COMBINATION LOCK DESIGN

Enhance privacy, protect information.



Image 2.1: Detail of the combination lock mechanism.

3. OPERATING INSTRUCTIONS

3.1 Inserting Coins

The album includes coin pages with two different pocket sizes: **1.77 x 1.77 inches** and **1.45 x 1.45 inches**. These are suitable for coins ranging from 20mm to 45mm, such as pennies, quarters, and Silver Eagles.

- Select a coin page with the appropriate pocket size for your coin.
- Gently slide the coin into an empty pocket.
- Ensure the coin is fully seated within the pocket.
- Utilize the integrated flap at the top of each coin pocket. Fold the flap down over the coin to secure it and prevent it from slipping out, even if the album is inverted.

SMART FLAP DESIGN

Prevent Coins from Falling Out



Image 3.1: The smart flap design securing coins within their pockets.

3.2 Inserting Currency

The album also features currency sleeves for paper money. Each sleeve is designed to hold standard-sized banknotes.

- Open a currency sleeve.
- Carefully slide your banknote into the sleeve.
- Ensure the note lies flat and is fully protected within the sleeve.


3.3 Adding or Removing Pages

The 3-ring stainless steel binder allows for flexible organization of your collection.

- To open the rings, locate the small levers or tabs on either end of the binder mechanism. Press them inward or outward (depending on the design) to release the rings.
- Carefully add new coin or currency pages, or remove existing ones.
- Once pages are arranged as desired, press the rings firmly until they snap shut, ensuring all pages are securely held.

DELICATE CRAFTSMANSHIP











THREE-RING BINDER

Easier to add or move more inner pages



WATERPROOF

Waterproof performance provides better protection



HD TRANSPARENT SHEETS

Thickened transparent interior sheets allows you to see the details of the coin or currency clearly

Image 3.2: The 3-ring binder mechanism for page management.



Image 3.3: Example of the collection book in use.

4. CARE AND MAINTENANCE

4.1 Fireproof and Waterproof Features

The Ytonet Coin Collection Book Holder is constructed from silicone-coated fiberglass, providing both fireproof and waterproof protection. It is designed to withstand temperatures up to **2200°F (1200°C)**, offering a layer of safety for your valuable collections in the event of a fire. The waterproof material helps protect against water damage.

While highly protective, it is important to note that the zipper seam may have a lower resistance to extreme conditions. Always store the album in a secure and accessible location.

FIREPROOF COIN HOLDER



The fireproof coin collection album is made of durable silicone coated fiberglass and can withstand high temperature up to 2200°F, except the zipper seam.



Image 4.1: Visual representation of the fireproof and waterproof features.

4.2 General Care

- To clean the exterior, wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- Keep the album away from direct sunlight for prolonged periods to prevent material degradation.
- Ensure coins and currency are clean and dry before placing them in the pockets to prevent moisture damage or corrosion.
- The transparent pages are acid-free to protect your collectibles from damage over time.

4.3 Luminous Strip Design

The album features a luminous strip on its exterior, designed to help you quickly locate the book in low-light conditions or in the dark.

LUMINOUS STRIP DESIGN

Help quickly find coin book in the dark



Image 4.2: The luminous strip aids in finding the album in the dark.

5. TROUBLESHOOTING

5.1 Combination Lock Issues

- **Lock not opening:** Double-check that you are entering the correct 3-digit combination. Ensure each dial is precisely aligned with the indicator mark. If you have forgotten your combination, there is no factory reset option; the lock cannot be opened without the correct code.
- **Zippers difficult to close:** Ensure no pages or items are obstructing the zipper path. The zippers should move smoothly. Avoid forcing the zippers, as this can cause damage.

5.2 Coin Slippage

- If coins are slipping out of pockets, ensure the coin is fully inserted and the protective flap is securely folded down over the coin.
- Verify that the coin size is appropriate for the pocket. Coins that are too small may not be held securely by the flap.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	6657
Dimensions	11.22 x 9.5 x 2 inches (29.01 x 24.69 x 4.6 cm)
Material	Silicone-coated fiberglass
Coin Capacity	320 coins (13 pages)
Currency Capacity	36 notes (12 sleeves)
Coin Pocket Sizes	1.77 x 1.77 inches & 1.45 x 1.45 inches
Suitable Coin Diameter	20mm - 45mm
Fire Resistance	Up to 2200°F (1200°C)
Special Features	Fireproof, Waterproof, Lockable, Expandable (3-ring binder), Luminous Strip



Image 6.1: Dimensions and pocket sizes of the collection book.

7. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Ytonet Coin Collection Book Holder Model 6657, please contact the manufacturer directly through their official channels. Specific warranty details may vary and are typically provided with your purchase documentation or on the manufacturer's website.