

[Manuals.plus](#) /

› [Superer](#) /

› Superer 26V Massage Gun Charger User Manual

Superer RSF-DY115B-2601000US

Superer 26V Massage Gun Charger User Manual

Model: RSF-DY115B-2601000US

INTRODUCTION

This user manual provides essential information for the safe and effective use of your Superer 26V Massage Gun Charger. Please read this manual thoroughly before use and retain it for future reference.

The Superer 26V Massage Gun Charger is designed to provide reliable power for compatible Hyperice Hypervolt massage guns.

PRODUCT OVERVIEW



The image displays the Superer 26V Massage Gun Charger. It is a black AC adapter with a standard US plug on one end and a long black cable terminating in a yellow-tipped round connector. The cable is neatly coiled and secured with a tie.

Key Features:

- Output: 26V 1A 26W
- Input: 100-240V (Universal Voltage)
- Safety Certifications: Meets nationally recognized standards for electronic safety.
- Protection Features: Overheating, Overvoltage, Electrostatic, Short Circuit, Overcurrent, Overcharge Protection.

COMPATIBILITY

This charger is specifically designed for certain Hyperice Hypervolt massage gun models. Please verify your device's voltage and amperage requirements before use.

Compatibility

VOLTS	AMPS	COMPATIBILITY
24V-26V	1A	✓
18V	1A	✗
16.8V	1A	✗



This image illustrates the voltage and amperage compatibility. It shows that the charger is compatible with devices requiring 24V-26V at 1A. It is not compatible with 18V 1A or 16.8V 1A devices.

Compatible Devices

✓
COMPATIBLE



Hypervolt



Hypervolt Plus



Hypervolt 2



Hypervolt 2 Pro



Hypervolt Go



Hypersphere

✗
INCOMPATIBLE

This image displays specific compatible and incompatible Hypervolt models. Compatible models include Hypervolt and Hypervolt Plus. Incompatible models include Hypervolt 2, Hypervolt 2 Pro, Hypervolt Go, and Hypersphere. Ensure your device matches the compatible models shown.

Important Note: Do not use this charger if your massage gun requires more than 1A.

SETUP AND CONNECTION

- Unpack:** Carefully remove the charger from its packaging.
- Inspect:** Before first use, inspect the charger and cable for any signs of damage. Do not use if damaged.
- Connect to Device:** Insert the round connector of the charger cable firmly into the charging port of your compatible Hyperice Hypervolt massage gun.
- Connect to Power Outlet:** Plug the AC adapter into a standard 100-240V wall outlet.
- Charging Indicator:** Observe your massage gun's charging indicator (if available) to confirm it is receiving power.

OPERATING INSTRUCTIONS

The Superer 26V Massage Gun Charger operates automatically once connected to a power source and a compatible device. It is designed to provide consistent and stable power delivery.



This image shows a Hypervolt massage gun connected to the Superer charger, which is plugged into a wall outlet. This setup demonstrates proper connection for charging.

- Ensure the charger is placed in a well-ventilated area during use.
- Do not cover the charger while it is in operation.
- Disconnect the charger from the power outlet when not in use or when the device is fully charged.

MAINTENANCE AND CARE

- **Cleaning:** Use a dry, soft cloth to clean the charger. Do not use liquid cleaners or sprays.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and moisture when not in use.
- **Cable Care:** Avoid bending or crimping the cable excessively. Do not pull the cable to disconnect from the outlet; always grasp the plug.
- **Inspection:** Periodically inspect the charger and cable for any signs of wear or damage.

SAFETY PRECAUTIONS



This image highlights the various safety protections built into the charger: Overheating Protection, Overvoltage Protection, Electrostatic Protection, Short Circuit Protection, Overcurrent Protection, and Overcharge Protection. These features ensure safe operation.

- Do not expose the charger to water or extreme temperatures.
- Do not attempt to disassemble or modify the charger.
- Keep out of reach of children and pets.
- Use only with compatible devices as specified in the compatibility section.
- If the charger becomes unusually hot, emits smoke, or produces strange odors, immediately unplug it from the wall outlet and discontinue use.


TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging	Charger not properly connected to outlet or device. Device is incompatible. Outlet is not functioning.	Ensure all connections are secure. Verify device compatibility (voltage/amperage). Test the outlet with another device.
Charger feels hot	Normal operation (slight warmth). Overload or faulty unit.	A slight warmth is normal. If excessively hot, unplug immediately and discontinue use. Ensure proper ventilation.
Loose connection	Worn connector or port.	Ensure the connector is fully inserted. If it remains loose, the charger or device port may be damaged. Contact support.

SPECIFICATIONS

- **Model Number:** RSF-DY115B-2601000US
- **Input:** 100-240V ~ 50/60Hz
- **Output:** 26V 1A (26W)
- **Connector Type:** Round Connector

- **Color:** Black
- **Package Dimensions:** 4.35 x 2.53 x 1.7 inches
- **Item Weight:** 4 ounces
- **Included Components:** 1 x Power Adapter



This image provides the physical dimensions of the charger unit, showing measurements of approximately 2.25 inches in length, 1.3 inches in height, and 1.49 inches in width. This helps in understanding the compact size of the adapter.

WARRANTY AND SUPPORT

Superer provides comprehensive after-sales support for this product.

- **30-Day Return/Replacement:** This product is eligible for replacement or returns within 30 days of purchase.
- **12-Month Guarantee:** The manufacturer provides an additional 12 Months Guarantee for quality-related issues.



This image visually represents the customer support policy, highlighting "Replace Service Within 12 Months" and "Refund Within 30 Days of Purchase," along with a commitment to "Quick feedback to any problems."

For any questions, concerns, or warranty claims, please contact Superer customer support through the retailer where the product was purchased or visit the official Superer store on Amazon: [Superer Store](#).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D258Q874>

More documents and user manuals: <https://manuals.plus/>