

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FOREVER](#) /

› [SETTY 10000 mAh Power Bank User Manual](#)

## FOREVER SETTY 10000 mAh Power Bank

# SETTY 10000 mAh Power Bank User Manual

Model: SETTY 10000 mAh Power Bank

Brand: FOREVER

### INTRODUCTION

Thank you for choosing the SETTY 10000 mAh Power Bank. This portable power bank is designed to provide reliable and convenient charging for your mobile devices on the go. With its high capacity and integrated cables, it ensures your devices stay powered throughout your travels and daily activities. Please read this manual carefully before using the product to ensure proper operation and longevity.

### PRODUCT OVERVIEW

#### Key Features:

- **Reliable Performance:** 10000 mAh capacity, capable of charging a smartphone 2-3 times.
- **Versatile Charging:** Equipped with one USB-A output port and two input ports (Micro-USB and USB-C) for charging the power bank itself.
- **Integrated Cables:** Features 3 built-in cables: USB-A (input), USB-C (output), and Lightning (output) for convenient device charging without extra cables.
- **LED Display:** Clear LED display shows the current battery level of the power bank.
- **Additional Functions:** Includes a built-in flashlight for added utility.

#### Product Visuals:



**Figure 1:** Front view of the SETTY Power Bank, showcasing the integrated USB-C, Lightning, and USB-A cables, along with the digital LCD battery indicator.



**Figure 2:** Visual representation of key features: built-in LED torch, three integrated charging cables, and the clear LCD battery display.



**Figure 3:** Detailed view of the integrated charging cables (USB-A, USB-C, Lightning) and the external input/output ports (USB-A output, Micro-USB input, USB-C input) located on the side of the power bank.

## SETUP

### Initial Charging:

1. Before first use, fully charge the power bank.
2. Connect the power bank to a USB power adapter (not included) using either the integrated USB-A input cable, a Micro-USB cable, or a USB-C cable.
3. The LED display will show the charging progress, indicating 100% when fully charged.

It is recommended to fully charge the power bank before its initial use to optimize battery performance.

## OPERATING INSTRUCTIONS

### Charging Your Devices:

1. Identify the correct cable for your device: integrated USB-C, integrated Lightning, or use your device's own USB cable with the USB-A output port.
2. Connect the appropriate cable from the power bank to your device's charging port.
3. The power bank will automatically begin charging your device. The LED display will show the remaining power bank battery level.
4. Disconnect your device once it is fully charged or when you no longer need to charge.

### Recharging the Power Bank:

1. When the LED display shows a low battery percentage, it's time to recharge the power bank.
2. Use the integrated USB-A input cable or connect a Micro-USB or USB-C cable to the respective input ports on the power bank.
3. Connect the other end of the cable to a USB wall adapter, computer USB port, or other compatible power source.
4. The LED display will show the charging status. Disconnect when it reaches 100%.

### Using the Flashlight:

- Locate the power button on the side of the power bank.
- Press and hold the power button for a few seconds to turn the flashlight on or off.

## MAINTENANCE

- Keep the power bank dry. Do not expose it to moisture or liquids.
- Avoid extreme temperatures. Do not store in very hot or cold environments.
- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the power bank with approximately 50% charge if not used for extended periods to preserve battery life. Recharge every 3-6 months.
- Handle with care. Do not drop or subject the power bank to strong impacts.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging device.	Low power bank battery; incorrect cable/port; device not compatible.	Recharge power bank; ensure correct cable and port are used; check device compatibility.
Power bank not recharging.	Faulty charging cable/adapter; power bank port damaged.	Try a different charging cable and adapter; contact support if ports appear damaged.
LED display not working.	Power bank is off; internal malfunction.	Press the power button to activate; if still unresponsive, contact support.
Flashlight not turning on.	Incorrect button press; low battery.	Press and hold the power button for a few seconds; recharge the power bank.

## SPECIFICATIONS

**Model:** SETTY 10000 mAh Power Bank

**Brand:** FOREVER

**Battery Capacity:** 10000 mAh (Lithium-Ion)

**Input Ports:** Micro-USB, USB-C, Integrated USB-A cable

**Output Ports:** USB-A, Integrated USB-C cable, Integrated Lightning cable

**Voltage:** 5 Volts

**Product Dimensions:** 15 x 2.5 x 10 cm

**Weight:** 400 Grams

**ASIN:** B0D25SC2GV

**Country of Origin:** China

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. The seller for this product is [TelForceOne](#).

Please retain your proof of purchase for any warranty claims.