



[Manuals.plus](#) /

› [HOOBRO](#) /

› HOOBRO C Shaped End Table Set BF40SFP201 User Manual

HOOBRO BF40SFP201

HOOBRO C Shaped End Table Set BF40SFP201 User Manual

Model: BF40SFP201

INTRODUCTION

Thank you for choosing the HOOBRO C Shaped End Table Set. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new furniture. This set includes two versatile C-shaped end tables, designed to enhance convenience and organization in various living spaces.



Image: The HOOBRO C Shaped End Table Set, showcasing both tables with their storage bags.

SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Position the product away from water and fire sources for storage and use.
- For safety reasons, children are not allowed to climb on or play on the product.
- Ensure all screws and fasteners are securely tightened before use.
- Do not exceed the maximum weight capacity of 30 lbs (13.6 kg) on the tabletop.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity (per table)
A	Tabletop (Rustic Brown)	1
B	Vertical Frame (Black Metal)	2
C	Base Frame (Black Metal)	1
D	Storage Bag (Black Fabric)	1
E	Adjustable Feet	4
F	Screws (M6x15mm)	8
G	Allen Key	1

Note: Quantities listed are per individual table. This set includes two tables, so double the quantities for the complete set.

SETUP AND ASSEMBLY

Assembly is designed to be straightforward. Please follow these steps carefully.

- Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
- Attach Adjustable Feet:** Screw the adjustable feet (E) into the pre-drilled holes on the bottom of the base frame (C).
- Assemble Frame:** Connect the two vertical frame pieces (B) to the base frame (C) using screws (F) and the Allen key (G). Do not fully tighten screws yet.
- Attach Tabletop:** Place the tabletop (A) onto the top of the vertical frame pieces (B). Align the holes and secure with screws (F). Now, fully tighten all screws on the frame and tabletop.
- Install Storage Bag:** Attach the fabric storage bag (D) to the designated hooks or fasteners on the side of the vertical frame. Ensure it is securely fastened.
- Final Adjustments:** Place the assembled table in its desired location. Adjust the feet (E) as needed to ensure the table is stable and level on uneven surfaces.



Image: Detailed dimensions of the C Shaped End Table, illustrating its compact design and storage bag capacity.



Image: Key features of the table, including its C-shaped base, storage bag, and robust frame.

OPERATING INSTRUCTIONS

The HOOBRO C Shaped End Table is designed for versatile use and convenience.

- **Slide Under Sofa/Bed:** Utilize the unique C-shaped design to slide the table's base under your sofa, armchair, or bed. This allows the tabletop to extend over your lap, providing easy access to items while you relax.
- **Utilize Storage Bag:** The 3-tier storage bag is ideal for organizing remote controls, magazines, books, tablets, snacks, and other small items, keeping your living space tidy.
- **Versatile Placement:** These tables are suitable for various rooms, including living rooms, bedrooms, hallways, or foyers, serving as end tables, nightstands, or accent tables.

Your browser does not support the video tag.

Video: Demonstration of the HOOBRO C Shaped Side Table with Storage Bag in various use scenarios.



Image: The C-shaped table positioned over a sofa, providing a convenient surface for a laptop.



Image: The tables serving as functional bedside companions in a bedroom setting.

MAINTENANCE

Proper care will extend the life and appearance of your HOOBRO C Shaped End Table.

- **Cleaning:** Wipe the tabletop and metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Storage Bag Care:** The fabric storage bag can be spot cleaned with a mild detergent and water. Allow it to air dry completely.
- **Regular Checks:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Direct Sunlight/Heat:** Prolonged exposure to direct sunlight or extreme heat can cause fading or warping of the engineered wood.




Image: Details of the table's construction, including rounded corners for safety and adjustable feet for stability.

TROUBLESHOOTING

If you encounter any issues with your C Shaped End Table, refer to the following common problems and solutions.

- **Table is wobbly:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the leveling feet on the bottom of the base frame to compensate for uneven flooring.
- **Missing parts:**
 - Double-check the packaging and all packing materials.
 - Contact HOOBRO customer support with your model number and a description of the missing part.
- **Tabletop appears scratched or damaged:**

- If damage occurred during shipping, contact the retailer or HOOBRO customer support immediately.
- For minor scratches, furniture repair kits or markers may be used, following product instructions.

SPECIFICATIONS

Feature	Detail
Brand	HOOBRO
Model Number	BF40SFP201
Product Dimensions (D x W x H)	15.7" x 11.8" x 28.3" (40cm x 30cm x 72cm)
Item Weight	11.7 Pounds (5.3 kg) per table
Maximum Weight Recommendation	30 Pounds (13.6 kg)
Color	Rustic Brown + Black
Table Design	End Table (C-Shaped)
Frame Material Type	Engineered Wood (Tabletop), Metal (Frame)
Number of Shelves	3 (within storage bag)
Indoor/Outdoor Usage	Indoor
Tools Recommended For Assembly	Screw Driver (Allen Key included)

WARRANTY AND SUPPORT

HOOBRO is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, most HOOBRO products come with a manufacturer's warranty against defects in materials and workmanship.

For warranty claims, missing parts, assembly assistance, or any other inquiries, please contact HOOBRO customer support through the retailer where you purchased the product or visit the official HOOBRO brand store:

[Visit the HOOBRO Store on Amazon](#)

Please have your model number (BF40SFP201) and purchase information ready when contacting support.