



Manuals.plus /

› Wonderchef /

› Wonderchef Nutri-blend Activ Mixer Grinder Blender 500W User Manual

## Wonderchef 63154951

# Wonderchef Nutri-blend Activ Mixer Grinder Blender 500W User Manual

Model: 63154951

## 1. INTRODUCTION

---

Thank you for choosing the Wonderchef Nutri-blend Activ Mixer Grinder Blender. This appliance is designed to assist you in preparing a variety of healthy beverages and food items efficiently. With its powerful 500W motor and versatile jars, it is suitable for blending, grinding, and mixing. Please read this manual carefully before first use to ensure safe and optimal operation.



Image: The Wonderchef Nutri-blend Activ unit with its blending jar, blade, sipper lid, and examples of blended drinks.



Image: A user demonstrating an active lifestyle, highlighting the product's suitability for health-conscious individuals.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the appliance.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the jar while blending to prevent severe personal injury and/or damage to the blender.
- Ensure the blade assembly is securely attached to the jar before placing it on the motor base.
- Never blend hot liquids as pressure buildup can cause the jar to burst.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Close supervision is necessary when any appliance is used by or near children.

## 3. WHAT'S IN THE BOX

---

Your Wonderchef Nutri-blend Activ package includes the following components:

- Motor Base - 1N
- Blending Jar 500 ml - 1N
- Blending Blade - 1N
- Sipper Jar 500 ml - 1N
- Sipper Lid - 1N

# What's in the Box



Image: An illustration detailing each component included in the product packaging, such as the motor base, blending jar, blade, sipper jar, and sipper lid.

## 4. PRODUCT FEATURES

The Wonderchef Nutri-blend Activ is engineered with features designed for performance and convenience:

- **Powerful Motor:** Equipped with a 500W, 22000 RPM, 100% full copper motor for efficient blending and grinding.
- **Durable Jars:** Includes two unbreakable polycarbonate jars (500 ml blending jar and 500 ml sipper jar).
- **Stainless Steel Blades:** Features surgical-grade stainless steel blades for effective processing of ingredients.
- **Compact Design:** Space-saving design with dimensions of 11.5D x 11.5W x 17.5H Centimeters.
- **Portable Sipper Jar:** The sipper jar with a sipper lid allows for convenient on-the-go consumption.
- **Hand-Free Operation:** Designed for ease of use.



# Built for Lasting Performance



Image: A cutaway view of the Nutri-blend Activ, showcasing its 500W copper motor, unbreakable jars, and stainless steel blades, along with its compact dimensions.



**Unveil the Blend  
Maestro in You!**

**Nutri-blend Activ's** 500W, 22000 RPM, 100% copper motor, enables you to swiftly create delectable smoothies, refreshing juices, and nutrient-packed shakes.

**Blender Inside,  
Sipper Outside**

**Nutri-blend Activ** comes with a sleek sipper jar which easily fits in your gym or office bag.

Image: This image highlights the convenience of the sipper jar, which allows users to blend and then carry their drink directly, fitting easily into gym or office bags.

## 5. SETUP

---

Follow these steps for initial setup:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the blending jar, sipper jar, and blade assembly with mild soap and water. Rinse thoroughly and dry.
3. **Assemble Blade:** Ensure the blade assembly is securely screwed onto the bottom of the desired jar.
4. **Place on Base:** Place the assembled jar (with ingredients inside) onto the motor base. Align the tabs on the jar with the slots on the base.
5. **Secure:** Twist the jar clockwise until it locks into place. The appliance will not operate unless the jar is properly secured.
6. **Connect Power:** Plug the power cord into a suitable electrical outlet.

## 6. OPERATING INSTRUCTIONS

---

The Wonderchef Nutri-blend Activ is designed for simple operation. Follow these guidelines for blending and grinding:

1. **Prepare Ingredients:** Cut fruits, vegetables, or other ingredients into small pieces (approximately 1-2 inches) to ensure smooth blending. Do not overfill the jar beyond the maximum fill line.
2. **Add Liquid:** For best results, always add some liquid (water, milk, juice, etc.) when blending solid ingredients.
3. **Assemble:** Securely attach the blade assembly to the jar containing your ingredients.
4. **Place and Twist:** Invert the jar and place it onto the motor base. Twist the jar clockwise to engage the motor. The motor will start automatically.
5. **Blend:** Blend until desired consistency is achieved. For tough ingredients or thick mixtures, use short pulses to prevent overheating. Do not operate continuously for more than 60 seconds.
6. **Stop:** To stop blending, twist the jar counter-clockwise to disengage the motor, then lift the jar off the base.

7. **Serve:** Unscrew the blade assembly and, if using the sipper jar, attach the sipper lid for on-the-go convenience.



**Watch the Magic Unfold**

With the **clear**, sturdy jars, get your blend spot-on every time; simply **Place**, **Twist**, and **Play** to discover a range of flavours.

**“Blend Like a Pro!”**

**Champion of All!**

With its **Surgical-Grade** sharp **6-Wing** multipurpose blade, **Nutri-blend Activ** is designed to grind, mix, and blend effortlessly.

Image: This visual demonstrates the simple three-step process of using the blender: Place the jar, Twist to activate, and Play (blend) to create various recipes. It also highlights the surgical-grade 6-wing blade.

## Applications

The Nutri-blend Activ is versatile for various culinary tasks:

- **Smoothies & Shakes:** Effortlessly blend fruits, vegetables, and protein powders for nutritious drinks.
- **Juices:** Create fresh fruit and vegetable juices.
- **Grinding:** Grind dry spices, coffee beans, and nuts.
- **Purées & Dips:** Prepare smooth purées for sauces or creamy dips.

# One Nutri-blend, Endless Possibilities



Image: A visual representation of the diverse range of preparations possible with the Nutri-blend Activ, from beverages like smoothies and slushies to food items like purées, dips, and ground spices.

# Grinds the Toughest Ingredients with Ease



Image: This image demonstrates the appliance's ability to grind tough ingredients such as dry spices and coffee beans, showcasing its grinding functionality.

## 7. MAINTENANCE AND CLEANING

Proper cleaning and maintenance will extend the life of your appliance:

1. **Unplug:** Always unplug the appliance before cleaning.
2. **Clean Jars and Blades:** Unscrew the blade assembly from the jar. Wash the jars and blade assembly with warm, soapy water. Use a brush to clean around the blades carefully. The jars are also dishwasher safe.
3. **Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
4. **Dry:** Ensure all parts are thoroughly dry before reassembling or storing.

# Easy to Clean

Clean with soap  
and water

Dishwasher Safe



Image: This image illustrates the ease of cleaning the Nutri-blend Activ, showing both manual washing of the blade and the jars being placed in a dishwasher for convenience.

## 8. TROUBLESHOOTING

If you encounter issues with your Wonderchef Nutri-blend Activ, refer to the following common problems and solutions:

- **Appliance does not start:**

- Ensure the power cord is securely plugged into a working outlet.
- Verify that the jar is correctly assembled with the blade and securely locked onto the motor base. The appliance has a safety mechanism that prevents operation if not properly assembled.

- **Ingredients are not blending smoothly:**

- Add more liquid to the mixture.
- Reduce the amount of ingredients in the jar.
- Cut ingredients into smaller pieces.

- Use short pulses to dislodge ingredients from the blades.

- **Motor smells burnt or overheats:**

- This can occur with heavy loads or prolonged use. Stop the appliance immediately and unplug it.
- Allow the motor to cool down for at least 15-20 minutes before resuming use.
- Do not operate continuously for more than 60 seconds.

- **Leakage from the jar:**

- Ensure the blade assembly is tightly screwed onto the jar.
- Check if the gasket (sealing ring) is properly seated within the blade assembly.
- Do not overfill the jar beyond the maximum fill line.

If the problem persists after following these steps, please contact customer support.

## 9. SPECIFICATIONS

Feature	Specification
Brand	Wonderchef
Model Number	63154951
Colour	Black
Power Source	Corded Electric
Wattage	500 Watts
Motor Speed	22000 RPM
Number of Speeds	3
Capacity	500 Milliliters (each jar)
Product Dimensions	11.5D x 11.5W x 17.5H Centimeters
Item Weight	1 kg 300 g
Blade Material	Stainless Steel
Container Material	Polycarbonate
Special Features	Compact, Dishwasher Safe Jars, Hand Free Operation, Powerful Motor
Country of Origin	India

## 10. WARRANTY AND SUPPORT

Your Wonderchef Nutri-blend Activ comes with a **2-year warranty**, ensuring peace of mind regarding product quality and performance.

### Customer Support

For any queries, service requests, or support, please contact Wonderchef customer service:

- **Toll-Free Number:** 1800 266 0788
- **WhatsApp:** 70705 95959
- **Email:** care@wonderchef.in
- **Service Hours:** Monday-Saturday, 9 AM to 6 PM

Wonderchef offers Pan-India Doorstep Service with quick resolutions within 48 hours, covering over 20,000+ pincodes.

# Pan-India Doorstep Service



**Wonderchef On-site Warranty**

-  **Quick Resolution**
-  **1860 266 0788**
-  **7070 59 59 59**
-  **care@wonderchef.in**
-  **Across 20,000+ Pincodes**
- Monday-Saturday 9am to 6pm**
-  **Authorised Service Agent**





Image: A map illustrating the extensive Pan-India doorstep service network provided by Wonderchef, along with contact information for support.

## Register Your Purchase for Priority Service

Register your product to receive priority service and support. You can register online by scanning the QR code or visiting the provided link:

## REGISTER YOUR PURCHASE FOR PRIORITY SERVICE



SCAN ME

- Pan-India Doorstep Service
- Quick Resolutions within 48 Hours
- On-demand Virtual Product Demo
- For quick after-sales service, WhatsApp "Hi" on 70705 95959



Image: A visual prompt to register the product for priority service, featuring a QR code and key benefits like 48-hour resolution and virtual product demos.

**Online Registration:** [Register Here](#)