

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [OLEVS](#) /

› [OLEVS Women's Quartz Analog Watch \(Model XLY-S-L9931GH-HH\) Instruction Manual](#)

**OLEVS XLY-S-L9931GH-HH**

# OLEVS Women's Quartz Analog Watch Instruction Manual

Model: XLY-S-L9931GH-HH

## INTRODUCTION

---

Thank you for choosing the OLEVS Women's Quartz Analog Watch. This manual provides essential information for the proper setup, operation, and maintenance of your new timepiece. Please read it carefully to ensure optimal performance and longevity of your watch.



Figure 1: OLEVS Women's Quartz Analog Watch (Model XLY-S-L9931GH-HH)

## PRODUCT OVERVIEW AND FEATURES

---

The OLEVS Women's Quartz Analog Watch combines classic design with practical features, crafted for durability and elegance.

- **Movement:** Imported original quartz movement for stable and precise timekeeping.
- **Dial:** Small black round dial with luxury diamond indices and classic Roman numerals. Features a date display window.
- **Band:** Durable stainless steel metal band with a textured bracelet design. Includes an adjustable tool for resizing.
- **Water Resistance:** 30 meters (3 ATM) waterproof rating, suitable for hand washing, rain, and splashes. Not recommended for swimming or diving.
- **Luminous Function:** Luminous hands and hour markers absorb light for 10 minutes, providing 6-8 hours of glow in dark conditions.
- **Crystal:** High hardness coated glass mirror.




Figure 2: Key Features of the OLEVS Watch

## SETUP INSTRUCTIONS

---

### 1. Setting the Time and Date

1. Gently pull out the crown (the small knob on the side of the watch) to the first click position.
2. Turn the crown clockwise or counter-clockwise to adjust the date.
3. Pull the crown out to the second click position.
4. Turn the crown to set the hour and minute hands to the correct time.
5. Once the time and date are set, push the crown back into its original position to start the watch movement.

### 2. Adjusting the Band Length

Your OLEVS watch comes with a tool to adjust the stainless steel band. This allows you to customize the fit to your wrist.

1. Identify the pins on the side of the watch band links that you wish to remove.
2. Place the band in the provided adjustment tool, aligning the tool's pin with the band pin.
3. Carefully turn the screw on the tool to push the pin out of the link.

4. Remove the desired number of links. Ensure an even number of links are removed from each side of the clasp for a balanced fit.
5. Reassemble the band by inserting the pins back into the links and gently tapping them into place.

For visual guidance on band adjustment, please refer to the official product video below.

*Video 1: Demonstrates the OLEVS watch features, including water resistance, luminous display, and how to operate the clasp. It also shows the watch being worn.*

## OPERATING INSTRUCTIONS

---

Once the time and date are set, your OLEVS watch operates automatically. The quartz movement ensures accurate timekeeping. The luminous hands and markers will glow in low-light conditions after exposure to light.



*Figure 3: OLEVS Watch on Wrist*

## MAINTENANCE

---

### 1. Water Resistance

The watch is rated for 30 meters (3 ATM) water resistance. This means it is protected against splashes, rain, and brief immersion in water, such as during hand washing. It is **not** suitable for showering, bathing, swimming, or diving, as prolonged water exposure or high-pressure water jets can compromise the seals.

## 2. Cleaning

To maintain the appearance of your watch, wipe the case and band with a soft, dry cloth regularly. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

## 3. Battery Replacement

The watch is powered by a quartz battery. When the watch stops running, it indicates that the battery needs to be replaced. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance is maintained.

## TROUBLESHOOTING

---

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Incorrect time:** Adjust the time using the crown as described in the Setup section.
- **Condensation under crystal:** This may indicate a loss of water resistance. Avoid further water exposure and consult a watch technician.

## SPECIFICATIONS

---

<b>Model Number</b>	XLY-S-L9931GH-HH
<b>Brand</b>	OLEVS
<b>Movement Type</b>	Quartz
<b>Display Type</b>	Analog
<b>Case Material</b>	Stainless Steel
<b>Band Material</b>	Stainless Steel
<b>Dial Color</b>	Black
<b>Case Diameter</b>	27 Millimeters
<b>Case Thickness</b>	9 Millimeters
<b>Band Width</b>	13 Millimeters
<b>Water Resistance Depth</b>	30 Meters (3 ATM)
<b>Crystal Type</b>	Hardlex

## WARRANTY AND SUPPORT

---

This OLEVS watch comes with a seller warranty. For any issues or support inquiries, please contact the seller directly through your purchase platform. Ensure to provide your model number (XLY-S-L9931GH-HH) and purchase details for efficient assistance.

