Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TCL 55P61B

TCL 55P61B Smart TV User Manual

Model: **55P61B** | Brand: **TCL**

1. Introduction

Thank you for choosing the TCL 55P61B Smart TV. This 55-inch 4K Ultra HD television features Google TV, Dolby Audio, and voice control capabilities, providing an immersive viewing experience. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new television. Please read this manual thoroughly before operating the TV and keep it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the TV to rain or moisture.
- Do not block ventilation openings. Ensure adequate space around the TV for proper airflow.
- Do not place the TV on an unstable cart, stand, tripod, bracket, or table.
- Protect the power cord from being walked on or pinched.
- Unplug the TV during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

3. Package Contents

Please check to ensure all items are included in your package:

- TCL 55P61B Smart TV
- Remote Control (requires 1 AA battery, not always included)
- Power Cord
- TV Stand (2 pieces) and Screws
- Quick Start Guide / User Manual (this document)

4. Setup

4.1 Unpacking and Placement

Carefully remove the TV from its packaging. It is recommended to have two people for this process due to the size of the 55-inch screen. Place the TV on a stable, flat surface or prepare for wall mounting.

4.2 Attaching the TV Stand

If you are not wall-mounting, attach the two stand pieces to the bottom of the TV using the provided screws. Ensure the stand is securely fastened before placing the TV upright.

4.3 Connecting Power

Connect the power cord to the TV's power input and then to a wall outlet.

4.4 Connecting External Devices

Connect your external devices such as set-top boxes, gaming consoles, or Blu-ray players to the HDMI ports. For antenna or cable connection, use the appropriate coaxial input. For internet access, connect an Ethernet cable or ensure Wi-Fi is enabled during initial setup.




Figure 4.4.1: The TCL 55P61B Smart TV, showcasing its sleek design and vibrant display. This image illustrates the overall appearance of the television, which is a 55-inch 4K Ultra HD model.

4.5 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup wizard. This includes selecting your language, connecting to a Wi-Fi network, signing in with your Google Account (for Google TV features), and scanning for TV channels (DVB-T2, DVB-C, DVB-S2).

5. Operating Your TV

5.1 Remote Control

The remote control allows you to navigate the TV's menus and control functions. Insert 1 AA battery into the remote control, observing the correct polarity.

5.2 Power On/Off

Press the Power button on the remote control or on the TV itself to turn the TV on or off.

5.3 Input Selection

Use the "Input" or "Source" button on your remote to switch between connected devices (HDMI 1, HDMI 2, TV, etc.).

5.4 Channel Tuning

After the initial setup, you can access digital channels (DVB-T2, DVB-C, DVB-S2) by selecting the "TV" input and using the channel up/down buttons.

5.5 Smart TV Features (Google TV)

Your TCL 55P61B runs on Google TV, providing access to a vast library of apps, streaming services, and content.

- **Home Screen:** Access personalized recommendations, installed apps, and content categories.
- **Apps:** Download and install your favorite streaming apps from the Google Play Store.
- **Chromecast Built-in:** Cast content directly from your smartphone or tablet to the TV.

5.6 Voice Control ("Hey Google")

The TV supports voice commands through Google Assistant. Simply say "Hey Google" or press the dedicated voice assistant button on your remote to search for content, control smart home devices, get answers, and more.

5.7 Picture and Sound Settings

Access the TV's settings menu to adjust picture and sound preferences.

- **Picture:** Optimize your viewing experience with settings for brightness, contrast, color, and advanced options like HDR (High Dynamic Range) and Micro Dimming. The TV features a PPI (Picture Performance Index) of 2400 for smooth motion.
- **Sound:** Adjust volume, sound mode, and other audio settings. The TV supports Dolby Audio for rich, clear sound.

6. Maintenance

Proper maintenance ensures the longevity of your TV.

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for TVs. Do not spray cleaner directly onto the screen.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet.
- **Ventilation:** Keep the ventilation openings clear of dust and obstructions.

7. Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No Power	Check if the power cord is securely plugged into the TV and the wall outlet. Try a different outlet.
No Picture, But Sound is Present	Ensure the correct input source is selected. Check cable connections to external devices.
No Sound, But Picture is Present	Check the volume level and mute setting. Ensure audio cables are correctly connected.

Problem	Possible Solution
Remote Control Not Working	Replace the AA battery in the remote. Ensure there are no obstructions between the remote and the TV.
Cannot Connect to Wi-Fi	Check your Wi-Fi password. Restart your router and the TV. Ensure the TV is within range of your Wi-Fi network.

8. Specifications

Key technical specifications for the TCL 55P61B Smart TV:

Feature	Detail
Model Number	55P61B
Brand	TCL
Screen Size	55 inches (139.7 cm)
Resolution	3840 x 2160 pixels (4K Ultra HD)
Display Technology	LED (Direct-LED)
Operating System	Google TV (Android)
Connectivity	Wi-Fi, Ethernet
Digital Tuner	DVB-C, DVB-S2, DVB-T2
Audio Technology	Dolby Audio
Motion Interpolation	PPI (Picture Performance Index) 2400
Response Time	15 ms
Aspect Ratio	16:9
Energy Efficiency Class	E




Figure 8.1: The energy efficiency label for the TCL 55P61B TV, indicating its energy class E and power consumption.

9. Warranty and Support

Specific warranty details and software update guarantees are not available in this manual. For comprehensive warranty information, technical support, and details regarding spare parts availability, please refer to the official TCL website or contact TCL customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

For the latest software updates and troubleshooting guides, visit the TCL support page for your model.

© 2024 TCL Corporation. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D26DFFNR

More documents and user manuals: **https://manuals.plus/**