

[manuals.plus](#) /› [ELECTROPRIME](#) /› [ELECTROPRIME SUITU ST-6638 Wireless Car Vacuum Cleaner and Blower User Manual](#)

ELECTROPRIME ST-6638

ELECTROPRIME SUITU ST-6638 Wireless Car Vacuum Cleaner and Blower User Manual

1. PRODUCT OVERVIEW

The ELECTROPRIME SUITU ST-6638 is a versatile wireless device designed for vehicle cleaning, integrating both vacuum suction and air blowing functionalities. Its compact and lightweight design makes it easy to store and handle. Key features include a powerful motor, built-in lighting for dark areas, and an environmentally friendly, washable filter.

Key Features:

- **Integrated Suction and Blowing:** Offers dual functionality for comprehensive cleaning.
- **Wireless Design:** Provides freedom of movement without cord limitations.
- **Built-in Lighting:** Illuminates dark spaces for improved visibility during cleaning.
- **Washable Filter:** Reusable filter element reduces maintenance costs and environmental impact.
- **Compact and Portable:** Small footprint for easy storage in a vehicle or home.

Included Accessories:

The standard package includes essential accessories to enhance cleaning versatility. Optional accessories may vary based on the specific product version purchased.

- Straw attachment
- Brush attachment
- User Manual
- Type-C Charging Cable (may be optional with some versions)
- Floor Brush (optional)
- Mouthpiece (optional)
- Small Brush (optional)
- Charging Base (optional)



Figure 1: The ELECTROPRIME SUITU ST-6638 wireless vacuum cleaner shown with its charging base and various cleaning attachments, including a long crevice tool, a brush nozzle, and a wider floor brush.

2. SETUP

- 1. Charge the Battery:** Before first use, ensure the device's battery is fully charged. Connect the Type-C charging cable to the device and a suitable USB power source. The charging indicator will show red during charging and turn green when fully charged.
- 2. Select and Attach Nozzle:** Choose the appropriate suction or blowing nozzle for your cleaning task. Align the nozzle with the device's intake/outlet and firmly attach it. For example, use the straw attachment for narrow gaps or the brush attachment for upholstery.

3. OPERATING INSTRUCTIONS

- 1. Power On:** Locate the power switch on the device and slide or press it to the "ON" position to start operation.
- 2. Cleaning:** Direct the attached nozzle towards the area to be cleaned. For vacuuming, ensure the nozzle makes good contact with the surface to maximize suction. For blowing, aim the nozzle to dislodge dust and debris.
- 3. Wet and Dry Use:** This vacuum cleaner supports both wet and dry cleaning. When absorbing liquids, exercise caution and avoid overfilling the dustbin.
- 4. Power Off:** After cleaning, slide or press the power switch to the "OFF" position.



Figure 2: The wireless vacuum cleaner being used to clean the interior of a car, demonstrating its portability and effectiveness in tight spaces.

Charging the Device:

- Connect the Type-C charging cable to the charging port on the device or the charging base.
- Plug the other end of the USB cable into a compatible power adapter (not included) or a USB port.
- The charging indicator light will be **red** during charging.
- The indicator light will turn **green** when the battery is fully charged.
- A full charge typically takes approximately **3-4 hours**.
- The device can operate continuously for about **30 minutes** on a full charge.

Strong Suction

Hurricane suction
Instantaneous absorption



Figure 3: Visual representation of the strong suction capability of the vacuum cleaner, showing debris being drawn into the nozzle.

4. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your ELECTROPRIME SUITU ST-6638.

Filter Cleaning:

- The device features an environmentally friendly, washable filter element.
- To clean, remove the dustbin and carefully extract the filter.
- Rinse the filter under running water until clean.
- Allow the filter to air dry completely before reinserting it into the device. Do not use the device with a wet filter.

Dustbin Emptying and Wet Use:

- After each use, especially after vacuuming wet debris, empty the dustbin.
- When absorbing water, it is crucial to open the front cover and drain the collected liquid promptly to prevent damage to the device and maintain hygiene.

5. TROUBLESHOOTING

If you encounter issues with your device, refer to the following common troubleshooting steps:

- **Device Not Turning On:**

- Ensure the battery is sufficiently charged. Connect the device to the charger and check if the indicator light turns red.
- Verify the power switch is fully in the "ON" position.

- **Low Suction Power:**

- Check if the dustbin is full and empty it if necessary.
- Inspect the filter for blockages or excessive dirt. Clean and dry the filter as described in the Maintenance section.
- Ensure all attachments are securely fitted and there are no air leaks.
- If used for wet cleaning, ensure the front cover has been opened to drain water.

- **Short Operating Time:**

- Ensure the device is fully charged before use (indicator light green).
- Battery performance may decrease over time with prolonged use.

6. SPECIFICATIONS

Parameter	Value
Material	ABS
Net Weight	0.33 KGS
Product Size	180 x 158 x 66 MM
Rated Voltage	DC 7.4V
Vacuum Degree (Wireless)	Approximately 4000 Pa
Rated Speed	42000 rpm
Lithium Battery Capacity	2 x 1800 mAh
Charging Method	8.4V USB Booster Line
Rated Power	45W
Noise Level	≤ 84 dB
Operating Temperature	-20°C to +50°C
Filter Material	PE+PP+Polyester Hot-Rolled Cloth
USB Cable Length	Approximately 1m

7. WARRANTY AND SUPPORT


This product is covered by a warranty policy. For detailed information regarding warranty terms, coverage, and claims, please refer to the official ELECTROPRIME warranty documentation provided with your purchase or visit the manufacturer's website.

For technical support, troubleshooting assistance beyond this manual, or inquiries about replacement parts, please contact ELECTROPRIME customer service. Contact details can typically be found on the product packaging, the official brand website, or through your retailer.

Manufacturer: ELECTROPRIME

Model Number: ST-6638 (Item Part Number: TBD0603643303)

Related Documents - ST-6638

	<p>TORQUE PRO WIRELESS VACUUM User Manual - Specifications, Operation, and Safety</p> <p>Comprehensive user manual for the TORQUE PRO WIRELESS VACUUM (SKU: TPRO-1, Model: ST-6645Pro). Includes detailed instructions on installation, operation, cleaning, and important safety guidelines for this handheld vacuum cleaner.</p>
	<p>SUITU ST-116 Multifunction Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the SUITU ST-116 Multifunction Vacuum Cleaner. Includes product overview, parts list, charging instructions, usage guide, maintenance tips, troubleshooting FAQ, technical specifications, warranty information, and conformity certificate.</p>
	<p>suitu ST-126 Brushless Vacuum Cleaner User Manual</p> <p>This user manual provides essential information for operating and maintaining the suitu ST-126 Brushless Vacuum Cleaner, including technical specifications, assembly, usage instructions, and safety precautions.</p>
	<p>SUITU ST-5007 On-Board Air Compressor: User Manual & Guide</p> <p>Discover the SUITU ST-5007 On-Board Air Compressor. This manual provides essential information on usage, features, and safety for your portable tire inflator.</p>
	<p>SUITU ST-6645 Multifunction Wireless Vacuum Cleaner User Manual</p> <p>Official user manual for the SUITU ST-6645 Multifunction Wireless Vacuum Cleaner. Provides instructions for operation, maintenance, and safety for this portable home and car vacuum.</p>



[Husqvarna ST 424, ST 427, ST 430 Series Snow Thrower Operator's Manual](#)

Comprehensive operator's manual for Husqvarna ST 424, ST 427, ST 430, ST 424T, ST 427T, and ST 430T snow throwers. Covers safety, assembly, operation, maintenance, and troubleshooting.