

[Manuals.plus](#) /

› [ZioeYiue](#) /

› Camping Fan Rechargeable, 20000mAh Large Battery Powered Fan, 4Speed Rechargeable Fan Portable with Remote, Battery Operated Fans with LED Light and Hanging Hook, Cordless Fans for Tent Picnic Outdoor

ZioeYiue Camping Fan

ZioeYiue Camping Fan Rechargeable User Manual

Model: Camping Fan

INTRODUCTION

The ZioeYiue Camping Fan Rechargeable is a versatile and portable device designed to provide cooling, lighting, and power bank functionalities for various outdoor and indoor activities. With its large capacity battery and multiple features, it ensures comfort and convenience wherever you go.

SAFETY INSTRUCTIONS

- **Do not** disassemble or attempt to repair the device yourself.
- Keep away from water and high humidity environments.
- **Do not** insert fingers or foreign objects into the fan blades.
- Use only the provided charging cable or a certified equivalent.
- Store in a cool, dry place when not in use.
- Keep out of reach of children.

PACKAGE CONTENTS

Please check the package for the following items:

- Rechargeable Camping Fan x 1
- Charging Cable x 1
- Remote x 1

PRODUCT OVERVIEW



The ZioeYiue Camping Fan, showcasing its main unit, remote control, and power bank functionality for charging a smartphone.

20000mAh RECHARGEABLE FAN

Large Capacity Battery



Fan Work
12-58h



Light Work
39-138h



Fan & Oscillation
10-31h



Input & Output
5V-3A



Detailed view of the fan's 20000mAh battery capacity, indicating fan work time (12-58h), light work time (39-138h), and fan & oscillation time (10-31h).

Key Features:

- **20000mAh Large Capacity Battery:** Provides 12-58 hours of continuous fan operation and 39-138 hours of light.
- **Power Bank Function:** Equipped with Type-C/USB interface to charge other devices.
- **Strong Airflow & Low Noise:** Utilizes brushless motor technology for powerful airflow (<30dB noise).
- **4 Adjustable Wind Speeds:** Customize airflow to your preference.
- **Adjustable Angle:** Features 45°/90° auto oscillation and 270° free rotation for wide coverage.
- **360° Hanging Hook:** Easily hang the fan in tents, hammocks, or RVs.
- **Remote Control:** Full control over fan, light, timer, and oscillation settings.
- **3 LED Light Brightness Levels:** Provides portable illumination for night activities.
- **Timer Function:** Set operation for 1, 2, 4, or 8 hours.
- **Sleep Mode:** Turns off indicator lights while fan operates for undisturbed sleep.

SETUP

Initial Charging:

Before first use, fully charge the fan using the provided Type-C charging cable. Connect the cable to the fan's Type-C input port and a compatible USB power adapter (not included). The battery indicator lights will show charging progress.

20000mAh
Rechargeable Battery

 Fan Work
12-58h

 Light Work
39-138h

 Fan & Oscillation
10-31h

 Input & Output
5V-3A

Emergency Power Source

The fan's 20000mAh battery also functions as an emergency power source, capable of charging other devices like smartphones via its USB output port.

OPERATING INSTRUCTIONS

Fan Operation:

- **Power On/Off:** Press the fan power button on the base or the 'OFF' button on the remote.
- **Adjust Fan Speed:** Press the fan speed button on the base or the fan speed buttons (+/-) on the remote to cycle through 4 speed settings.
- **Oscillation:** Press the oscillation button on the base or the remote to activate 45°/90° auto oscillation. Press again to stop.
- **Manual Rotation:** Manually adjust the fan head 270° for precise airflow direction.

STRONG AIRFLOW & ADJUSTABLE ANGLE

4 Speed Settings



360°
Hanging Hook



270°
Free Rotation



45°/90°
Auto Oscillation

Visual guide to the fan's strong airflow with 4 speed settings, adjustable 45°/90° auto oscillation, 270° free rotation, and a convenient 360° hanging hook.



The fan in a tent setting, emphasizing its remote control (120°/16ft range), low noise (<30dB), timing function (1-8h), and sleep mode without light.

LED Light Operation:

- **Turn On/Off:** Press the light button on the base or the light icon button on the remote.
- **Adjust Brightness:** Press the light button repeatedly to cycle through 3 brightness levels.
- **Sleep Mode:** When the fan is on, press the sleep mode button on the remote to turn off the blue indicator lights on the base.

MULTIFUNCTIONAL CAMPING GEAR



The fan's multifunctional capabilities, including 3 levels of outdoor lighting (LV.1, LV.2, LV.3) and its role as a power source with USB and Type-C input/output ports.

Timer Function:

- Press the timer button on the base or the remote to set the fan to operate for 1, 2, 4, or 8 hours. The corresponding indicator light will illuminate.

Power Bank Function:

- Connect your device to the fan's USB output port using your device's charging cable. The fan's 20000mAh battery can be used to charge smartphones and other small electronics.

Official Product Video



This video demonstrates the ZioeYiue Camping Fan's features, including its strong airflow, adjustable angles, remote control, and lighting

functions, showcasing its versatility for outdoor activities like camping and picnics.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the fan's surface. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store the fan in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the fan at least once every three months if not used regularly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan fully.
Fan is not oscillating.	Oscillation function is off.	Press the oscillation button on the base or remote.
Remote control not working.	Remote battery is low or line of sight is blocked.	Ensure clear line of sight to the fan's IR sensor. Replace remote battery if necessary.
Light is dim or not working.	Battery is low or light setting is too low.	Charge the fan. Adjust light brightness using the light button.

SPECIFICATIONS

Feature	Detail
Brand	ZioeYiue
Model Name	Camping Fan Rechargeable
Battery Capacity	20000mAh Lithium Polymer
Fan Speeds	4 Levels
Noise Level	<30dB
Oscillation	45°/90° Auto Oscillation
Rotation	270° Free Rotation
LED Light Brightness	3 Levels
Timer Settings	1H, 2H, 4H, 8H
Power Source	Battery Powered (USB Type C)
Product Dimensions	8.77"D x 4.48"W x 11.18"H
Item Weight	3.23 pounds

WARRANTY AND SUPPORT

ZioeYiue offers a **365-Day New Item Exchange Policy** for any quality problems with your camping fan. For any questions or support, please contact us through Amazon. We commit to responding and resolving your issue within 24 hours.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question