

[Manuals.plus](#) /

› [PayLessHere](#) /

› PayLessHere Dining Chairs Set of 4 Instruction Manual

PayLessHere Dining Chairs Set of 4

PayLessHere Dining Chairs Set of 4 Instruction Manual

Model: Dining Chairs Set of 4

1. PRODUCT OVERVIEW

The PayLessHere Dining Chairs Set of 4 offers a blend of modern design and comfort, suitable for various dining room decors. Each chair features a fabric upholstered seat and back, designed for durability and ease of maintenance. The sturdy frame is constructed from solid wood, ensuring stability and longevity.



Image 1.1: PayLessHere Dining Chairs Set of 4. This image displays the complete set of four beige dining chairs, highlighting their elegant design and upholstered finish.

Key Features:

- **Upholstered Comfort:** Fabric cushion and back provide a comfortable seating experience.
- **Durable Construction:** Sturdy frame made with quality wood for stability.
- **Floor Protection:** Equipped with plastic feet on legs to prevent floor scratching.
- **Modern Design:** Contemporary aesthetic that complements various interior styles.

2. ASSEMBLY INSTRUCTIONS

Assembly of the PayLessHere Dining Chairs is designed to be straightforward. Each chair typically requires approximately 10-15 minutes for completion. All necessary tools and hardware are included with the product.

Required Components (per chair):

- Chair Backrest
- Seat Cushion
- Four (4) Chair Legs
- Hardware Pack (screws, washers, Allen wrench)

Assembly Steps:

1. Carefully unpack all components and verify against the parts list.
2. Attach the chair legs to the seat cushion using the provided screws and Allen wrench. Ensure all connections are secure but do not overtighten initially.
3. Attach the backrest to the seat cushion, aligning the pre-drilled holes. Secure with the remaining screws.
4. Once all components are loosely assembled, place the chair upright on a flat surface. Apply gentle pressure to ensure all parts are aligned, then fully tighten all screws.
5. Verify the stability of the chair before use.

—Floor Protection—



Strong Wooden leg



Quality Wood

Image 2.1: Chair Leg and Wood Quality. This image illustrates the strong wooden legs and the quality of the wood used in the chair's construction, essential for assembly and durability.

3. OPERATING AND USAGE GUIDELINES

These dining chairs are designed for indoor use in dining room settings. Adhering to the following guidelines will ensure safe and optimal performance.

Proper Use:

- **Intended Use:** These chairs are specifically recommended for dining purposes.
- **Weight Capacity:** Each chair has a maximum weight recommendation of 250 pounds. Do not exceed this limit to prevent damage or injury.
- **Floor Protection:** The chair legs are fitted with plastic feet to protect your flooring from scratches. Avoid dragging chairs across rough surfaces.
- **Sitting Posture:** For ergonomic comfort, maintain a proper sitting posture.

HEALTHY LIFE BEGINS WITH THE RIGHT SITTING POSITION



This dining chair is a design personality, a medieval modern sensory dining chair.



Image 3.1: Ergonomic Design. This image highlights the ergonomic considerations in the chair's design, promoting a healthy sitting posture.

4. MAINTENANCE AND CARE

Regular maintenance will help preserve the appearance and extend the lifespan of your dining chairs.


Cleaning Instructions:

- **General Cleaning:** Wipe clean with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the fabric or finish.
- **Fabric Care:** The fabric upholstery is designed to be wear-proof and dirty-proof. For spills, blot immediately with a clean, dry cloth.
- **Wood Finish:** The wooden legs feature a powder-coated finish. Wipe with a dry or slightly damp cloth.
- **Water Resistance:** The chair's materials offer some water resistance; however, prolonged exposure to liquids should be avoided.

—Product Detail—



Anti-Slip foot mats



Water Proof



Skin-friendly and Comfortable



Image 4.1: Product Details for Maintenance. This image details features like anti-slip foot mats, waterproof fabric, and skin-friendly material, all contributing to ease of maintenance and durability.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your dining chairs.

Common Issues and Solutions:

- **Wobbling Chair:**
 - Ensure all screws are securely tightened.
 - Place the chair on a flat, level surface. If wobbling persists, slightly loosen all screws, sit on the chair to settle the frame, then retighten.
- **Scratches on Floor:**

- Verify that the plastic feet on the chair legs are intact and properly positioned. Replace if damaged.
- **Stains on Fabric:**
 - For fresh spills, blot immediately with a clean, dry cloth. Avoid rubbing.
 - For stubborn stains, consult a professional upholstery cleaner or use a fabric-specific spot cleaner, testing on an inconspicuous area first.

6. SPECIFICATIONS

Detailed specifications for the PayLessHere Dining Chairs Set of 4.




Image 6.1: Product Dimensions. This diagram provides a visual representation of the chair's measurements in inches, including height, width, and depth.

Attribute	Detail
-----------	--------

Attribute	Detail
Brand	PayLessHere
Model Number	Dining Chairs Set of 4
Product Dimensions (Overall)	22"D x 17"W x 34"H
Seat Depth	16.5 inches
Seat Back Interior Height	16.9 Inches
Color	Beige
Material (Fill)	Foam
Furniture Finish (Legs)	Wood (Powder Coated)
Item Weight (Set of 4)	50 pounds
Maximum Weight Recommendation (per chair)	250 Pounds
UPC	195030107512
ASIN	B0D295VKYY
Indoor/Outdoor Usage	Indoor

7. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the purchase documentation or contact the retailer directly. Specific warranty terms may vary based on the point of purchase and regional regulations. Keep your proof of purchase for any warranty claims or support inquiries.

© 2024 PayLessHere. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question