

[Manuals.plus](#) /

› [Mizuno](#) /

› Mizuno MORELIA NEO IV Japan Soccer Cleats User Manual

Mizuno P1GA233009

Mizuno MORELIA NEO IV Japan Soccer Cleats User Manual

Model: P1GA233009

INTRODUCTION

Thank you for choosing the Mizuno MORELIA NEO IV Japan Soccer Cleats. This manual provides essential information for the proper setup, usage, maintenance, and care of your new cleats to ensure optimal performance and longevity. The MORELIA NEO IV Japan model is engineered for a barefoot-like feel, offering superior comfort and control on various playing surfaces.



Image: Side view of the Mizuno MORELIA NEO IV Japan Soccer Cleats, showcasing the white upper with black and red accents.

SETUP

Before your first use, follow these steps to prepare your cleats:

1. **Initial Fit:** Try on the cleats with your preferred soccer socks. Ensure a snug but comfortable fit. The kangaroo leather upper is designed to mold to your foot over time, enhancing the barefoot feel.
2. **Lacing:** Lace the cleats securely, ensuring even tension across the foot. Experiment with different lacing techniques to find what provides the best lockdown and comfort for your foot shape.

3. **Insole Check:** The Morelia Neo insole is removable. Ensure it is properly seated inside the cleat before use.
4. **Break-in Period:** While these cleats are designed for immediate comfort, a short break-in period during light training sessions is recommended to allow the materials to fully adapt to your foot.



Image: Top-down view of the Mizuno MORELIA NEO IV Japan Soccer Cleats, showing the lacing system and the "MORELIA NEO" branding on the insole.

OPERATING / USAGE

The Mizuno MORELIA NEO IV Japan cleats are versatile and designed for optimal performance on specific playing surfaces.

- **Suitable Ground Types:** These cleats are suitable for natural grass, firm ground (soil), and artificial grass grounds. The outsole is engineered to provide reliable traction on these surfaces.
- **Playing Conditions:** For best results and longevity, avoid using these cleats on extremely hard or abrasive surfaces not specified, as this can accelerate wear on the outsole and upper.
- **Performance:** The lightweight design and kangaroo leather upper contribute to enhanced ball touch and control, allowing for agile movements and precise passing/shooting.



Image: View of the soleplate of the Mizuno MORELIA NEO IV Japan Soccer Cleats, highlighting the stud configuration designed for multi-ground use.

MAINTENANCE

Proper maintenance will extend the life and performance of your Mizuno MORELIA NEO IV Japan cleats.

- **Cleaning After Use:**

- Immediately after each use, remove excess dirt and mud from the upper and soleplate using a soft brush or damp cloth.
- For the kangaroo leather upper, use a specialized leather cleaner or a mild soap solution with a soft cloth. Avoid harsh chemicals.
- Wipe down the studs and soleplate thoroughly.
- **Drying:**
 - Do not dry cleats in direct sunlight or with artificial heat sources (e.g., radiators, hair dryers), as this can damage the leather and synthetic materials.
 - Stuff the cleats with newspaper or paper towels to absorb moisture and help retain their shape. Allow them to air dry at room temperature.
- **Storage:**
 - Store cleats in a cool, dry place away from extreme temperatures.
 - Use the included shoe bag for protection during transport and storage.
- **Insole Care:** Remove insoles periodically to air them out and prevent odor buildup. If necessary, hand wash insoles with mild soap and water, then air dry completely before reinserting.



Image: Angled side view of the Mizuno MORELIA NEO IV Japan Soccer Cleats, showing the texture of the kangaroo leather upper.

TROUBLESHOOTING

If you encounter any issues with your cleats, consider the following common solutions:

Problem	Possible Cause	Solution
Discomfort or Blisters	Improper fit, insufficient break-in, wrong sock type.	Ensure correct size and width (2E). Allow for break-in. Use appropriate athletic socks. Re-lace for better fit.
Excessive Wear on Studs	Usage on unsuitable hard surfaces, abrasive artificial turf.	Ensure cleats are used on recommended surfaces (natural grass, soil, artificial grass). Avoid concrete or asphalt.
Odor Buildup	Lack of proper drying and ventilation.	Remove insoles after each use and air dry. Stuff cleats with newspaper. Use shoe deodorizers if needed.

Problem	Possible Cause	Solution
Leather Cracking/Stiffening	Improper cleaning or drying, lack of conditioning.	Clean gently and air dry. Apply a leather conditioner specifically designed for kangaroo leather periodically.



Image: Rear view of the Mizuno MORELIA NEO IV Japan Soccer Cleats, showing the heel counter and "MORELIA NEO" branding.

SPECIFICATIONS

Key specifications for the Mizuno MORELIA NEO IV Japan Soccer Cleats:

- **Model:** P1GA233009

- **Color:** White x Black (Super white pearl x black)
- **Upper Material:** Washable Kangaroo Leather, Artificial Leather (Microfiber), Synthetic Fiber
- **Sole Material:** Synthetic Sole
- **Insole:** Morelia Neo Insole (removable)
- **Width:** 2E equivalent
- **Weight:** Approximately 195g (per shoe, 27.0cm size)
- **Closure Type:** Lace-Up
- **Suitable Grounds:** Natural Grass, Soil, Artificial Grass
- **Accessories:** Includes shoe bag (Made in China)
- **Country of Origin:** Japan
- **Manufacturer:** MIZUNO
- **First Available:** April 21, 2024

WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or additional product support, please refer to the retailer's purchase policy or contact Mizuno customer service directly. Keep your proof of purchase for any warranty claims. Visit the official Mizuno website for the latest product information and support resources www.mizunousa.com

© 2025 Mizuno. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

