Haofy Haofynhdvs9ipz7

Haofy Lightweight Squeeze Roller Mop Instruction Manual

Model: Haofynhdvs9ipz7 | Brand: Haofy

1. Introduction

Thank you for choosing the Haofy Lightweight Squeeze Roller Mop. This manual provides essential information for the safe and efficient use of your new cleaning tool. Designed for versatility and ease of use, this mop is suitable for various indoor environments, including homes, offices, and stores.
Key features of your Haofy Squeeze Roller Mop include:

- **Versatile Usage:** Suitable for all types of indoor floors.
- **Super Absorbent:** Made of soft gum cotton material for high absorbency and effective cleaning.
- **Effortless Mopping:** Innovative roller design allows for smooth gliding across surfaces.
- **Easy to Use:** Unique squeezing mechanism minimizes hand contact with water, keeping hands dry during use.
- **Lightweight & Convenient:** Designed to save energy and make cleaning faster and easier.

2. Package Contents

Your package should contain the following items:

- 1 x Roller Mop (Handle and Head Assembly)
- 2 x Sponge Heads (Replacement)

3. Setup and Assembly

Follow these steps to assemble your Haofy Squeeze Roller Mop:

1. **Attach the Mop Head:** Align the sponge head with the mop base. Ensure the plastic handle on the mop base is flat against the body. The sponge head has an 'IN' arrow indicating the direction to slide it into the mop base.
2. **Secure the Sponge Head:** Push the sponge head firmly into the mop base until it clicks into place. The squeeze mechanism should be able to grip the sponge securely.
3. **Assemble the Handle:** Your mop handle comes in multiple sections. Screw the handle sections together clockwise until they are tightly connected.

4. **Connect Handle to Mop Base:** Screw the assembled handle onto the mop base. Ensure it is securely fastened.



Image: The Haofy Squeeze Roller Mop fully assembled and ready for use on a floor.

Video: Demonstrates the assembly process of the sponge mop, including attaching the sponge head and handle sections.

4. Operating Instructions

Using your Haofy Squeeze Roller Mop is straightforward:

1. **Wet the Sponge:** Before first use or if the sponge is dry and hard, soak the sponge head in water until it becomes soft and pliable.
2. **Wring Out Excess Water:** To wring the mop, pull the handle lever upwards. This activates the roller mechanism, squeezing out excess water from the sponge. Repeat until the desired dampness is achieved.
3. **Mop the Floor:** Glide the mop across the floor surface. The absorbent sponge material will pick up dirt, dust, and spills.

4. **Clean and Re-wet:** As the mop gets dirty, wring it out over a bucket of clean water or a sink to release the dirt. Re-wet the sponge as needed.




Image: The squeeze mechanism compressing the sponge to remove water.

Video: Demonstrates the effective use of a PVA sponge mop for cleaning various floor types and its wringing mechanism.

5. Maintenance

Proper maintenance ensures the longevity and effectiveness of your mop:

5.1 Cleaning the Sponge Head

- After each use, rinse the sponge head thoroughly under running water while operating the squeeze mechanism to remove all dirt and cleaning solution.
- Allow the sponge to air dry completely before storing to prevent mildew and odors.

5.2 Replacing the Sponge Head

When the sponge head shows signs of wear or reduced absorbency, it's time for a replacement. Your package includes

two spare sponge heads.

1. **Remove Old Sponge:** Ensure the mop handle is in the downward position. Locate the release mechanism (often a lever or button) on the mop head. Activate it to release the old sponge head. It should slide out easily.
2. **Install New Sponge:** Align the new sponge head with the mop base, ensuring the 'IN' arrow on the sponge points towards the mop. Slide the new sponge head into the mop base until it locks into place.
3. **Test Mechanism:** Operate the squeeze mechanism a few times to ensure the new sponge head is securely installed and functions correctly.



Image: A close-up view of the soft, absorbent sponge material of the mop head.

Video: Shows the simple process of installing a new sponge head onto the mop.

6. Specifications

Feature	Detail

Item Type	Roller Mop
Material	Sponge, Plastic, Stainless Steel
Adjustable Length	Approx. 95-129 cm / 37.4-50.79 inches
Sponge Length	Approx. 38 cm / 14.96 inches
Item Weight	Approx. 1.02 kg / 2.25 lbs
Color	White
Surface Recommendation	Floor
Model Number	Haofynhdvs9ipz7

7. Troubleshooting

If you encounter any issues with your mop, please refer to the following common solutions:

- **Sponge is Hard/Stiff:** If the sponge head is dry, it will be hard. Soak it in warm water for 5-10 minutes until it becomes soft and flexible before use.
- **Mop Not Wringing Properly:** Ensure the sponge head is correctly installed and locked into place. Check that the squeeze mechanism lever moves freely and is not obstructed.
- **Handle is Loose:** Tighten all handle sections by twisting them clockwise. Ensure the handle is securely screwed into the mop base.
- **Poor Cleaning Performance:** The sponge head may be worn out or excessively dirty. Replace the sponge head with a new one. Ensure the sponge is adequately damp for effective cleaning.

8. Warranty and Support

For any questions, concerns, or warranty claims regarding your Haofy Lightweight Squeeze Roller Mop, please contact Haofy customer support through the retailer where you purchased the product. Please retain your proof of purchase for warranty service.