Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- MLOVE /
- MLOVE A200 Portable Retro Bluetooth Speaker Instruction Manual

MLOVE A200

MLOVE A200 Portable Retro Bluetooth Speaker Instruction Manual

Brand: MLOVE | Model: A200

INTRODUCTION

The MLOVE A200 Portable Retro Bluetooth Speaker combines vintage aesthetics with modern audio technology. Designed for versatile use, it features multiple connectivity options and adjustable sound controls to enhance your listening experience at home or during gatherings. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your speaker.

WHAT'S IN THE BOX

- · Retro Bluetooth Speaker
- Aux Cord
- USB to USB C / USB Cable
- User Manual

SETUP

Charging the Speaker

Before first use, fully charge the MLOVE A200 speaker. Connect the provided USB to USB C / USB cable to the USB-C port on the back of the speaker and a compatible USB power adapter (not included). A full charge takes approximately 4 hours and provides up to 10 hours of continuous playtime.



Image: MLOVE A200 speaker with its charging port visible.

Powering On

To power on the speaker, press and hold the "Power" button located on the top panel for 2 seconds until you hear a prompt sound and the Bluetooth indicator flashes rapidly.



Image: Close-up of the speaker's top control panel showing the power button and volume/tone knobs.

Bluetooth Pairing

Once powered on, the speaker will automatically enter Bluetooth pairing mode, indicated by a rapidly flashing Bluetooth indicator light. On your device (smartphone, tablet, etc.), search for "Mlove A200" in the Bluetooth settings and select it to connect. A confirmation sound will indicate successful pairing.

Your browser does not support the video tag.

Video: Official MLOVE A200 Retro Bluetooth Speaker demonstration, showing the speaker's features and connectivity.

TWS (True Wireless Stereo) Pairing

For an immersive surround sound experience, you can pair two MLOVE A200 speakers together. Ensure both speakers are powered on and not connected to any other Bluetooth device. Press the "TWS" button on both speakers. They will automatically connect to each other. Once paired, connect your device to one of the speakers via Bluetooth, and audio will play through both speakers in stereo.




Image: Two MLOVE A200 speakers positioned to demonstrate True Wireless Stereo (TWS) functionality.

OPERATING MODES

The MLOVE A200 speaker supports multiple audio input methods:

- Bluetooth Mode: Connect wirelessly to your smartphone, tablet, or other Bluetooth-enabled devices.
- Aux Input: Use the included 3.5mm aux cord to connect to devices without Bluetooth capabilities.
- Micro SD Card Slot: Insert a Micro SD card (up to 32GB) loaded with your favorite music files.
- USB Port: Connect a USB flash drive (up to 32GB) containing audio files.



Image: Rear view of the MLOVE A200 speaker highlighting the Micro SD, USB, USB-C, and 3.5mm Aux input ports.

Sound Adjustment

Utilize the dedicated knobs on the top panel to fine-tune your audio:

- Bass Knob: Adjust the low-frequency output for deeper or lighter bass.
- Treble Knob: Control the high-frequency output for sharper or softer treble.
- Volume Knob: Adjust the overall volume level.

MAINTENANCE

To ensure the longevity and optimal performance of your MLOVE A200 speaker, follow these maintenance guidelines:

- Cleaning: Use a soft, dry cloth to wipe the exterior of the speaker. Avoid using abrasive cleaners or solvents.
- Storage: Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Protection:** While the speaker has high-standing legs to protect against spills, avoid direct contact with water or other liquids.
- **Battery Care:** For extended storage, charge the battery to about 50% every few months to maintain battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery or no charge.	Charge the speaker fully using the provided USB-C cable.
Cannot pair via Bluetooth.	Speaker is not in pairing mode or already connected to another device.	Ensure the speaker's Bluetooth indicator is flashing rapidly. Disconnect from other devices if necessary. Restart both speaker and device.
No sound from speaker.	Volume too low, incorrect input mode, or device not playing.	Increase speaker and device volume. Press the "M" button to cycle through input modes. Ensure your device is playing audio.
Poor sound quality.	Low battery, device too far from speaker, or interference.	Charge the speaker. Move the device closer to the speaker. Avoid obstacles or other electronic devices causing interference.
TWS pairing fails.	Speakers are too far apart or already connected to other devices.	Ensure both speakers are close to each other and not connected to any other device. Restart both speakers and try TWS pairing again.

SPECIFICATIONS

Feature	Detail
Model Name	A200
Speaker Type	Subwoofer
Connectivity Technology	Bluetooth, USB C, Aux Input, Micro SD Card Slot, USB Port
Wireless Communication Technology	Bluetooth, AUX, USB, Micro SD Card Slot
Bluetooth Range	15 Meters (approx. 49 feet)

Feature	Detail
Speaker Maximum Output Power	80 Watts
Battery Life	8 Hours (up to 10 hours as per feature bullets)
Charging Time	4 Hours
Battery Capacity	5000 Milliamp Hours
Product Dimensions	5.91"D x 10.43"W x 6.77"H
Item Weight	6.77 Pounds
Material	Wood, Plastic, Metal
Water Resistance Level	Water Resistant
Included Components	Retro Bluetooth Speaker, User Manual, Aux Cord, USB to USB C / USB Cable

WARRANTY & SUPPORT

MLOVE is committed to providing quality products and customer satisfaction. Your MLOVE A200 speaker comes with the following:

- 30 Days Return: Hassle-free returns within 30 days of purchase.
- 90 Days Replacement: Free replacement for any manufacturing defects within 90 days.
- 360 Days Warranty: Comprehensive warranty coverage for 360 days from the date of purchase.

For any inquiries or support, MLOVE offers 24x7 customer support, including weekends. Please refer to the contact information provided in your user manual or visit the official MLOVE store on Amazon.



Image: MLOVE support and warranty details, including 24x7 support, 30-day return, 90-day replacement, and 360-day warranty.

Related Documents - A200

A200 Uses Monard or Anniell personal UStreething invasion in committee controls Streething in co	70mai A200 Dash Cam User Manual Comprehensive user manual for the 70mai A200 dash cam, detailing product overview, package contents, installation guide, technical specifications, memory card instructions, safety precautions, cautions, warranty conditions, and EU declarations.
70mal Dash Carn A200 Series User Manual Tomal Dash Carn A200 Series User Manual Tomal Dash Carn A200 Series User Manual	70mai Dash Cam A200 Series: User Manual, Installation Guide, and Specifications Comprehensive user manual for the 70mai Dash Cam A200 Series, covering product overview, package contents, installation steps, technical specifications, memory card instructions, precautions, and regulatory compliance information.
Eigensperoperop Time Dath Care ASSI Floridaes repyrop paras	Посібник користувача 70mai Dash Cam A200: Функції, Встановлення та Заходи Безпеки Вичерпний посібник користувача для 70mai Dash Cam A200. Дізнайтеся про функції пристрою, кроки встановлення, комплектацію, технічні характеристики, використання карти пам'яті та важливі заходи безпеки.
70mail Dash Cam A200 Series User Manual	70mai Dash Cam A200 Series User Manual User manual for the 70mai Dash Cam A200 Series, providing product overview, installation guides, specifications, and precautions.
D64LTextrologies	Dell EMC PowerScale OneFS Best Practices Guide Discover essential best practices for deploying, configuring, and managing Dell EMC PowerScale clusters with OneFS. This guide covers data layout, node hardware, data tiering, network configurations, and protocol recommendations for optimal performance and efficiency.
	Mlove Rangers D5 Karaoke Speaker User Manual User manual for the Mlove Rangers D5 Karaoke Speaker, detailing its features, functions, specifications, and troubleshooting.

Documents - MLOVE - A200

[pdf] User Manual




A200 Bluetooth Колонка Підключення до вашого пристрою Увімкніть на своєму пристрої та виберіть Mlove A200 Після підключення пролунає звуковий сигнал і світлодіод буде 1017530 portativnaja akustika mlove a200 elegant retro brown i allo ua media manual |||

A200 Bluetooth 01 02 , , . . , . , , , . . , . . , . . . , . . . , . USB . 1 Bluetooth USB- USB- 1 USB- 1 3.5 / 1 ...

lang:fr score:35 filesize: 377.88 K page_count: 2 document date: 2023-12-24

[pdf] User Manual Warranty



lang:en score:18 filesize: 2.27 M page_count: 52 document date: 2024-04-20

Pleasestoreandusethisproductatroomtemperature. Donotusethisproduc...

