

**JTEMAN L39-1**

# **JTEMAN 360 Rotating Cell Phone Stand with Wireless Bluetooth Speaker with Light**

## **INSTRUCTION MANUAL**

Model: L39-1

### **Product Overview**

The JTEMAN 360 Rotating Cell Phone Stand with Wireless Bluetooth Speaker with Light is a versatile device designed to enhance your mobile experience. It integrates a rotatable phone stand, a Bluetooth speaker, and an atmosphere light into a single unit. This manual provides detailed instructions for its setup, operation, and maintenance.



Figure 1: JTEMAN 360 Rotating Cell Phone Stand with Wireless Bluetooth Speaker with Light.

#### Included Components:

- Bluetooth Speaker (with integrated phone stand and light)
- Type-C Cable
- Instruction Manual

## Setup Guide

### 1. Unboxing and Initial Inspection:

Carefully remove all components from the packaging. Inspect the device and accessories for any signs of damage. Ensure all listed components are present.

Your browser does not support the video tag.

Video 1: Unboxing and initial setup of the JTEMAN phone stand and Bluetooth speaker.

### 2. Preparing the Phone Stand:

Before first use, locate and remove the silicone protective patch from the device's base. This patch protects the surface during shipping.



Figure 2: Product details and components. Note the anti-slip design and key functions.

### 3. Charging the Device:

Connect the provided Type-C cable to the charging port on the device and the other end to a compatible USB power adapter (not included). The power indicator light will show red during charging and turn green when fully charged.

- **Red Light:** Battery is charging.
- **Green Light:** Battery is fully charged.




Figure 3: Battery capacity and estimated usage times.

#### 4. Bluetooth Pairing:

1. Long press the Power ON/OFF button (3) for 3 seconds to turn on the speaker. The speaker will enter pairing mode, indicated by a flashing blue light.
2. On your smartphone or tablet, navigate to Bluetooth settings.
3. Select "L39-1" from the list of available devices.
4. Once connected, the blue light will become solid.




Figure 4: Bluetooth connection with a laptop, demonstrating wireless audio playback.

## Operating Instructions

### Control Panel Overview:



Figure 5: Detailed view of the control panel and its functions.

1. **VOL- (1):** Press to decrease volume.

2. **VOL+ (2):** Press to increase volume.

3. **Answer/Hang up/Play/Pause/Next (4):**

- Short press to play/pause music.
- Short press to answer/hang up calls.
- Long press to skip to the next track.

4. **Power ON/OFF (3):**

- Long press for 3 seconds to turn on/off the speaker.
- Double press to switch between Bluetooth and AUX modes.
- Short press to adjust the brightness of the atmosphere lights (4 levels).

5. **Atmosphere Light (5):**

- Long press for 3 seconds to turn on/off the light.
- Short press to switch lighting mode (11 modes available, 3 modes sync with music).

6. **Microphone (6):** For hands-free calling.

7. **Charging Port (7):** Type-C input for charging.

8. **Power Indicator Light (8):** Shows charging status and Bluetooth connection status.

### Phone Stand Adjustment:

The phone stand features 360° rotation and adjustable height and angle to suit various viewing needs. The anti-slip silicone pads ensure device stability.

# Super Compatibility with Phone Tablet

Support for iPhone Android Samsung and most 4-13" devices



Figure 6: The phone stand supports a wide range of devices, including smartphones and tablets (4-13 inches).

The stand is foldable for easy portability.



Figure 7: The foldable design allows for easy storage and transport.

## Maintenance

## **Cleaning:**

Wipe the device with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the surface or internal components. Avoid exposing the device to excessive moisture.

## **Storage:**

When not in use for extended periods, store the device in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the device is fully charged before storing to prolong battery life.

## **Battery Care:**

To maximize battery lifespan, avoid fully discharging the battery frequently. Charge the device regularly, even if not in constant use. Do not expose the battery to high temperatures.

## **Troubleshooting**

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device using the provided Type-C cable.
Cannot connect via Bluetooth.	Bluetooth not enabled on device; speaker not in pairing mode; too far from speaker.	Ensure Bluetooth is enabled on your phone/tablet. Long press Power ON/OFF button to enter pairing mode (flashing blue light). Move device closer to the speaker.
No sound from speaker.	Volume too low; device not connected; AUX mode active.	Increase volume on both the speaker and your connected device. Verify Bluetooth connection. Double press Power ON/OFF button to switch to Bluetooth mode if in AUX mode.
Atmosphere lights not working.	Lights turned off; low battery.	Long press the Atmosphere Light button (5) to turn on. Charge the device.

## **Specifications**

Feature	Detail
Model Name	L39-1
Mounting Type	Tabletop Mount
Speaker Type	Surround Sound
Special Feature	LED Light
Recommended Uses	For Smartphones or Tablets
Compatible Devices	Smartphone, Tablet (4-13 inches)

Feature	Detail
Controller Type	Button, Touch
Surround Sound Channel	2.0
Product Dimensions	5.3"D x 3.5"W x 2.3"H
Is Waterproof	FALSE
Power Source	Battery Powered
Battery Type	1 Lithium Ion (included)
Audio Driver Type	Dynamic Driver
Wireless Connectivity	Bluetooth 5.3
Speaker Maximum Output Power	5 Watts
Frequency Response	1 KHz
Item Weight	15.5 ounces

## Warranty Information

This JTEMAN product comes with a **One-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the official JTEMAN website or contact customer support.

## Customer Support

If you encounter any issues or have questions not covered in this manual, please contact JTEMAN customer support. Provide your product model number (L39-1) and a detailed description of the issue to assist our support team.

For the most up-to-date contact information, please visit the official JTEMAN website: [JTEMAN Store on Amazon](#)

	<p><a href="#"><b>L9 Phone Stand with Bluetooth Speaker Instruction Manual</b></a></p> <p>Instruction manual for the L9 Phone Stand with Bluetooth Speaker, detailing product parameters, key functions, usage instructions, and features. Includes FCC compliance information.</p>
	<p><a href="#"><b>Jteman ML100 User Manual: Night Light Bluetooth Speaker with Alarm Clock</b></a></p> <p>Comprehensive user manual for the Jteman ML100 Night Light Bluetooth Speaker with Alarm Clock. Learn about its features, button functions, Bluetooth and SD card modes, light settings, time and alarm clock setup, charging, and safety instructions.</p>