

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [MOFII](#) /
- > [MOFII Wireless Keyboard and Mouse Combo User Manual](#)

MOFII Wireless Keyboard and Mouse Combo

MOFII Wireless Keyboard and Mouse Combo User Manual

Model: Wireless Keyboard and Mouse Combo

Brand: MOFII

INTRODUCTION

This manual provides essential instructions for setting up, operating, and maintaining your MOFII Wireless Keyboard and Mouse Combo. Please read this guide thoroughly to ensure optimal performance and longevity of your device.



The MOFII Wireless Keyboard and Mouse Combo, showcasing its full-size design and colorful keys.

SETUP

1. Battery Installation

- The keyboard and mouse each require one AA battery (not included).
- Open the battery compartment on the underside of both the keyboard and the mouse.
- Insert the AA batteries, ensuring correct polarity (+/-).
- Close the battery compartments securely.

2. USB Receiver Connection

- Locate the USB receiver, typically stored within the mouse's battery compartment.
- Plug the USB receiver into an available USB port on your computer (PC, desktop, or laptop).
- The system will automatically detect and install the necessary drivers. No additional software is required.



The compact USB receiver provides 2.4G wireless connectivity for both the keyboard and mouse.

3. Compatibility

This keyboard and mouse combo is compatible with Windows operating systems (Windows 7/8/10) and various computer types including PCs, desktops, and notebooks.

Your browser does not support the video tag.

Video demonstrating the simple plug-and-play setup by inserting the USB receiver into a computer.

OPERATING INSTRUCTIONS

1. Power On/Off

- Ensure the power switch on the underside of both the keyboard and mouse is in the 'ON' position.
- To conserve battery life, switch the devices to 'OFF' when not in use for extended periods.

2. Auto-Sleep Feature

Both the keyboard and mouse are equipped with an auto-sleep function. After 8-10 minutes of inactivity, they will enter a low-power sleep mode to extend battery life. To wake them up, simply press any key on the keyboard or click the mouse button.



The auto-sleep feature helps conserve battery power during periods of inactivity.

3. Multimedia Hotkeys

The keyboard features dedicated multimedia hotkeys for quick access to various functions. These keys are typically located along the top row (F1-F12) and can be activated by pressing the 'Fn' key simultaneously with the desired function key.




Illustration of the multimedia hotkeys for enhanced productivity.

4. Ergonomic Design

The keyboard is designed with a folding holder and anti-slide pads to provide an optimal typing angle, reducing wrist strain. The contoured mouse offers comfortable use for extended periods.

Ergonomic Design

Release wrist pressure and work effectively



The keyboard's adjustable feet allow for a comfortable typing angle.

Your browser does not support the video tag.

Video demonstrating the typing sound and feel of the keyboard, highlighting its quiet operation.

MAINTENANCE

1. Cleaning

The keyboard features removable keycaps, making cleaning easy. Gently pull off the keycaps to clean dust and debris from underneath. Use a soft, dry cloth for general cleaning of both the keyboard and mouse surfaces.



Removable keycaps facilitate easy cleaning and maintenance.

2. Battery Replacement

When the devices stop responding or show signs of low power, replace the AA batteries in both the keyboard and mouse. Refer to the 'Battery Installation' section for detailed steps.

Your browser does not support the video tag.

Video showing the battery compartment of the mouse and how to replace batteries.

TROUBLESHOOTING

- **Device not responding:** Ensure batteries are correctly installed and charged. Check that the USB receiver is securely plugged into a working USB port. If devices are in auto-sleep mode, press any key or click the mouse to wake them.
- **Intermittent connection:** Ensure the devices are within the 10-meter (33 feet) operating range of the USB receiver. Avoid placing the receiver near strong electromagnetic interference sources.
- **Keys or mouse buttons not working:** Check for any physical obstructions or debris under the keys. For the keyboard, try removing and re-inserting the keycaps.

SPECIFICATIONS

Feature	Detail
---------	--------

Connectivity Technology	2.4G Wireless (USB Receiver)
Operating Range	Up to 10 meters (33 feet)
Power Source	1 x AA Battery (Keyboard), 1 x AA Battery (Mouse)
Compatibility	Windows, PC, Desktop, Notebook
Special Features	Round Keycaps, Ergonomic Design, Auto-Sleep Function, Full-Size Layout
Keyboard Dimensions	17.71 x 5.31 x 1.57 inches (approximate)
Mouse Dimensions	4.13 x 2.56 x 1.37 inches (approximate)
Item Weight	1.98 pounds (combo)

WARRANTY AND SUPPORT

Your MOFII Wireless Keyboard and Mouse Combo comes with a 30-day money-back guarantee and a 12-month warranty from the date of purchase. For any support inquiries, troubleshooting assistance, or warranty claims, please contact MOFII customer service through the retailer where the product was purchased.