

[Manuals.plus](#) /

› [Brilvibera](#) /

› Brilvibera 18-inch Black 2-Light Outdoor Wall Light Fixture Instruction Manual

Brilvibera No Sensor

Brilvibera 18-inch Black 2-Light Outdoor Wall Light Fixture

MODEL: NO SENSOR

1. Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Brilvibera 18-inch Black 2-Light Outdoor Wall Light Fixture. Please read this manual thoroughly before installation and retain it for future reference.



Image 1.1: Brilvibera 18-inch Black 2-Light Outdoor Wall Light Fixture. This image shows the overall design of the black outdoor wall light fixture with two light sources and clear glass panels.

The Brilvibera outdoor wall light fixture is designed for exterior use, featuring a durable aluminum construction and clear glass panels. It is ETL certified, ensuring quality and safe operation. This model is a standard 'No Sensor' type, providing consistent illumination when powered on.



✓ **Ours**

✓ Large Size

✓ Anti-rust

✓ Clear Glass

✓ Waterproof

✗ **Others**

✗ Small Size

✗ Easy to Rust

✗ Fragile Glass

✗ Not Waterproof

Image 1.2: Feature comparison highlighting the Brilvibera light's large size, anti-rust properties, clear glass, and waterproof design compared to other products.

2. Safety Information

- **Electrical Safety:** Always turn off the main power at the circuit breaker or fuse box before beginning installation, maintenance, or bulb replacement. Failure to do so may result in electric shock, serious injury, or death.
- **Professional Installation:** If you are unsure about electrical wiring or installation procedures, consult a qualified electrician.
- **Grounding:** Ensure the fixture is properly grounded to avoid potential electrical hazards.
- **Bulb Requirements:** Use only E12 base bulbs with a maximum wattage of 40W per socket. Do not exceed the recommended wattage.
- **Handling:** Handle glass components with care to prevent breakage. Wear protective gloves if necessary.
- **Outdoor Use:** This fixture is designed for outdoor use and is rated IP65 waterproof. Ensure all connections are sealed to maintain water resistance.

3. Package Contents

Verify that all components are present and undamaged before proceeding with installation.

- Outdoor Wall Light Fixture (1 unit)
- Mounting Hardware (screws, wire nuts, mounting plate)
- Shade (pre-assembled with fixture)



Image 3.1: Detailed view of the fixture components, including the top handle, round bracket, E12 bulb base, and aluminum frame construction.

4. Specifications

Feature	Specification
Brand	Brilvibera

Model	No Sensor
Color	Black
Material	Aluminum, Glass
Light Fixture Form	Sconce
Indoor/Outdoor Usage	Outdoor
Power Source	Corded Electric (Hardwired)
Voltage	120V
Bulb Base	E12
Max Wattage per Bulb	40W
Number of Light Sources	2
Water Resistance Level	Waterproof (IP65)
Certification	ETL Listed



Large Size



Glass:	Clear Glass	Base Type:	E12 Base
Voltage:	120V	Wattage:	40W MAX
Certification	ETL	Power:	Hardwired

Image 4.1: Dimensional drawing showing the fixture's height (18 inches / 45.5 cm), width (8 inches / 20.1 cm), and depth (6.7 inches / 17 cm). Also lists electrical specifications: E12 base, 120V, 40W MAX, Hardwired, ETL certified.



Compatible with All E12 Bulbs

(BULBS NOT INCLUDED)



Image 4.2: Illustration of various E12 base bulb types compatible with the fixture, including LED, CFL, incandescent, and halogen bulbs (bulbs not included).

5. Installation Instructions

Before you begin: Ensure power is OFF at the circuit breaker. Gather necessary tools (screwdriver, wire strippers, electrical tape, safety glasses).

1. **Prepare the Wiring:** Turn off power at the main circuit breaker. Remove the old fixture if applicable.
2. **Attach Mounting Plate:** Secure the mounting plate (round bracket) to the junction box using the provided screws. Ensure it is firmly attached.
3. **Connect Wires:** Connect the fixture's wires to your house wiring. Match the wires: black to black (live), white to white (neutral), and green/bare copper to green/bare copper (ground). Use wire nuts to secure connections and wrap with electrical tape for added safety.
4. **Mount the Fixture:** Carefully align the fixture with the mounting plate and secure it with the provided screws. Ensure no wires are pinched.
5. **Install Bulbs:** To install bulbs, gently remove the top cover of the fixture. Screw in two E12 base bulbs (max 40W

each) into the sockets. Replace the top cover securely.

6. **Restore Power:** Turn the power back on at the circuit breaker. Test the light fixture.



Image 5.1: Visual guide showing how to remove the top of the fixture to install E12 bulbs, emphasizing reinforced installation.

6. Operation

This Brilvibera outdoor wall light fixture (No Sensor model) operates as a standard hardwired light. Once installed and wired correctly, it will turn on and off via your existing wall switch or external timer connected to the circuit. There are no integrated sensors or special operating modes for this specific model.

7. Maintenance

- **Cleaning:** To clean the fixture, ensure power is off. Wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.
- **Bulb Replacement:** Turn off power at the circuit breaker. Carefully remove the top cover of the fixture. Unscrew the old bulb and screw in a new E12 base bulb (max 40W). Replace the top cover securely.

- **Inspection:** Periodically inspect the fixture for any signs of wear, damage, or loose connections. Address any issues promptly.



Image 7.1: Icons illustrating the fixture's weather resistance, including waterproof, sunproof, snowproof, and windproof capabilities.

8. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture Loose wire connections Faulty bulb	Check circuit breaker and wall switch Verify all wire connections are secure (power off first) Replace bulb
Light flickers	Loose bulb Incorrect bulb type Loose wiring	Tighten bulb Ensure compatible E12 bulb is used Check wire connections (power off first)
Glass is broken or cracked	Impact damage	Contact customer support for replacement parts

9. Product Videos

Watch these official product videos for additional information and visual guidance.

Your browser does not support the video tag.

Video 9.1: An overview of the Brilvibera 2-light outdoor wall fixture, showcasing its design and features.

Your browser does not support the video tag.

Video 9.2: A demonstration of the large outdoor wall light, highlighting its size and aesthetic appeal.

10. Warranty and Support

Brilvibera products are manufactured to high-quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. Please refer to the product packaging or contact Brilvibera customer support for specific warranty details and duration.

For technical assistance, replacement parts, or any questions regarding your Brilvibera outdoor wall light fixture, please contact Brilvibera customer service through the retailer's platform or the official Brilvibera website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D2D916LD>

More documents and user manuals: <https://manuals.plus/>