

[Manuals.plus](#) /

> [UFESA](#) /

> UFESA Z7 Digital Animal 81405894 Vacuum Cleaner Vertical, Grey, 500 W 29.6V Z7 Digital Animal User Manual

## UFESA 81405894

# UFESA Z7 Digital Animal Vacuum Cleaner User Manual

Model: 81405894

## PRODUCT OVERVIEW

---

The UFESA Z7 Digital Animal is a powerful and versatile cordless stick vacuum cleaner designed for efficient cleaning across various surfaces. It features a digital brushless motor, multicyclonic technology, and a long-lasting Li-ion battery, providing up to 80 minutes of runtime. The integrated digital display offers real-time information, and its multiple suction modes adapt to different cleaning needs. This model is specifically designed with pet owners in mind, offering specialized accessories for effective pet hair removal.



Figure 1: UFESA Z7 Digital Animal Vacuum Cleaner with main body, extension tube, floor brush, and various attachments. It illustrates the versatility and range of cleaning options available with the product.

## SETUP AND ASSEMBLY

---

### 1. Package Contents

Before assembly, ensure all components are present in the package:

- Main Motor Unit (with dust tank)
- Extension Tube
- Motorized Floor Brush with LED lights
- Flexible Hose
- Crevice Tool
- Upholstery Brush
- Pet Brush
- Wall-mounted Charging Support

- Power Adapter
- User Manual

**Accesorios incluidos**  
Acessórios incluídos  
Included accessories  
Accessoires inclus



*Figure 2: The various accessories that come with the UFESA Z7 Digital Animal vacuum cleaner, including a flexible hose, a narrow crevice tool for tight spaces, an upholstery brush, and a specialized pet brush, enhancing its cleaning versatility.*

## 2. Assembly Instructions

1. Insert the extension tube into the main motor unit until it clicks securely into place.
2. Attach the motorized floor brush to the other end of the extension tube, ensuring it clicks into position.
3. For handheld use or specific cleaning tasks, attach any desired accessory (flexible hose, crevice tool, upholstery brush, or pet brush) directly to the main motor unit or the flexible hose.

## 3. Initial Charging

Before first use, fully charge the vacuum cleaner's battery. The battery is removable for convenient charging.

- Mount the wall-mounted charging support in a convenient location using the provided hardware.
- Connect the power adapter to the charging support and plug it into a power outlet.

- Place the vacuum cleaner onto the charging support. The digital display will indicate charging status.
- A full charge takes approximately 4 hours. The display will show 100% when fully charged.



Figure 3: The convenient wall-mounted charging support for the UFESA Z7 Digital Animal vacuum cleaner, allowing for easy storage and charging when not in use.

## OPERATING INSTRUCTIONS

---

### 1. Power On/Off

Press the power button located on the main motor unit to turn the vacuum cleaner on or off.

### 2. Suction Modes

The UFESA Z7 Digital Animal offers four suction modes to optimize cleaning for different surfaces and dirt levels. Use the mode selection button on the digital display to cycle through them:

- **Eco Mode:** For light cleaning and maximum battery runtime (up to 80 minutes).
- **Medium Mode:** Balanced power for everyday cleaning.

- **Turbo Mode:** Maximum suction power for stubborn dirt and deep cleaning.
- **Auto Mode:** The vacuum automatically adjusts suction power based on the detected dirt level, optimizing performance and battery life.



*Figure 4: A detailed view of the vacuum cleaner's digital touch screen, which provides real-time information such as remaining battery charge and the currently selected cleaning mode.*



**Autonomía hasta 80min**  
Autonomia até 80min  
Autonomy up to 80min  
Autonomie jusqu'à 80min



*Figure 5: The UFESA Z7 Digital Animal vacuum cleaner being used in a living room, emphasizing its cordless design and extended autonomy of up to 80 minutes.*

### 3. Digital Display Information

The digital display provides crucial information at a glance:

- **Battery Charge:** Shows the remaining battery percentage.
- **Working Mode:** Indicates the currently selected suction mode (Eco, Medium, Turbo, Auto).
- **Full Dust Container Display:** Alerts when the dust tank needs emptying.
- **Brush Lock Indicator:** Notifies if the motorized brush is obstructed.
- **Battery Charge Reminder:** Prompts to charge the battery when low.

### 4. Multicyclonic Technology

The vacuum cleaner utilizes advanced multicyclonic technology to separate dust and debris from the airflow, preventing filter clogging and maintaining consistent suction power throughout your cleaning session.

**Tecnología multiciclónica**  
Tecnologia multiciclónica  
Multicyclonic technology  
Technologie multicyclonique



*Figure 6: This image visually explains the multicyclonic technology integrated into the UFESA Z7 Digital Animal, which optimizes particle separation to maintain consistent suction power.*

## MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the lifespan of your UFESA Z7 Digital Animal vacuum cleaner.

### 1. Emptying the Dust Tank

Empty the 0.6-liter dust tank regularly, especially when the 'Full Dust Container' indicator appears on the digital display.

1. Ensure the vacuum cleaner is turned off.
2. Locate the dust tank release button on the main motor unit.
3. Press the button to detach the dust tank.
4. Hold the dust tank over a waste bin and open the bottom flap to release the contents.
5. Close the flap and reattach the dust tank to the main motor unit until it clicks.

## 2. Cleaning the Filters

The vacuum cleaner features washable filters. Clean them regularly to maintain suction power.

1. Remove the dust tank as described above.
2. Carefully remove the filter components from inside the dust tank.
3. Tap the filters gently over a bin to remove loose dust.
4. Rinse the filters under cold running water until the water runs clear. Do not use detergent.
5. Allow the filters to air dry completely for at least 24 hours before reassembling. Do not use a dryer or direct heat.
6. Once completely dry, reinsert the filters into the dust tank and reattach the tank to the vacuum.

## 3. Cleaning the Motorized Floor Brush

Periodically check the motorized floor brush for tangled hair or debris.

1. Ensure the vacuum cleaner is off and disconnected from the charger.
2. Detach the motorized floor brush from the extension tube.
3. Locate the brush roll release mechanism (usually a latch or screw) and remove the brush roll.
4. Use scissors or a brush to remove any tangled hair, threads, or debris from the brush roll and its housing.
5. Reinsert the brush roll and secure it in place.

## TROUBLESHOOTING

If you encounter any issues with your UFESA Z7 Digital Animal vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the battery fully (approx. 4 hours).
Low suction power.	Dust tank is full.	Empty the dust tank.
Low suction power.	Filters are clogged.	Clean or replace the filters. Ensure they are completely dry before reinserting.
Low suction power.	Obstruction in the nozzle, tube, or brush.	Check and clear any blockages.
Motorized brush not spinning.	Brush roll is tangled or obstructed.	Clean the brush roll and remove any tangled hair or debris. Check the brush lock indicator on the display.
Battery not charging.	Power adapter or charging support not properly connected.	Ensure all connections are secure and the power outlet is working.

## SPECIFICATIONS

Detailed technical specifications for the UFESA Z7 Digital Animal Vacuum Cleaner (Model: 81405894):

Feature	Specification
---------	---------------

Feature	Specification
Brand	UFESA
Model Number	81405894
Color	Grey
Power / Wattage	500 W
Voltage	29.6 V
Battery Type	2000 mAh Li-ion (Removable)
Runtime	Up to 80 minutes (in Eco mode)
Charging Time	Approx. 4 hours
Suction Pressure	≥26 KPa
Dust Tank Capacity	0.6 Liters
Noise Level	≤78 dBA
Number of Speeds	4 (Eco, Medium, Turbo, Auto)
Filter Type	Bagless with Washable Filter
Special Features	Cordless, Bagless, Washable Filter, Digital Display, Motorized Brush with Light, Auto Clean Function
Item Weight	4.19 Kilograms
Surface Recommendation	All floors



Figure 7: This diagram provides a visual overview of the UFESA Z7 Digital Animal's core specifications and features.

## WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official UFESA website. Keep your purchase receipt as proof of purchase for warranty claims. Extended warranty options may be available through third-party providers, such as the 1-Year or 2-Year Extended Warranty by Salama Care, as detailed at the point of purchase.

© 2024 UFESA. All rights reserved.

For the latest information and updates, please visit [www.ufesa.es](http://www.ufesa.es)