

[Manuals.plus](#) /

› [LIUP](#) /

› LIUP LP1 Wireless Luminous Earbuds User Manual

LIUP LP1

LIUP LP1 Wireless Luminous Earbuds User Manual

Model: LP1

INTRODUCTION

Thank you for choosing the LIUP LP1 Wireless Luminous Earbuds. This manual provides detailed instructions for the proper use, maintenance, and troubleshooting of your new earbuds. Please read this manual thoroughly before use to ensure optimal performance and longevity of the product.



PACKAGE CONTENTS

Please verify that all items are present in your package:

- Luminous Earbuds (Left and Right)
- Wireless Charging Case
- USB Charging Cable
- UV Flashlight
- User Manual (this document)

SETUP

1. Initial Charging

Before first use, fully charge the charging case and earbuds.


1. Place both earbuds into the charging case.
2. Connect the USB charging cable to the charging port on the case and to a compatible USB power source.
3. The indicator light on the charging case will show charging status. Allow approximately 2 hours for a full charge.

2. Bluetooth Pairing

The earbuds utilize Bluetooth 5.4 for a stable connection.

1. Ensure the earbuds are charged and placed inside the charging case.
2. Open the charging case lid. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "LIUP LP1" from the list of found devices to connect.
5. Once connected, a voice prompt will confirm successful pairing.

V5.4 ONE STEP QUICK PAIRING



**Solid
Connection**



**Solid
Signal**



**Gaming
Mode**

Image: Bluetooth pairing process shown on a smartphone screen, with the LIUP LP1 earbuds connected.

3. Activating the Luminous Feature

The earbuds and case contain luminous flowing sand that glows in the dark after absorbing light energy.

- To activate the glow, expose the earbuds and case to a light source, such as sunlight or the included UV flashlight, for at least 3 minutes.
- The intensity and duration of the glow depend on the light absorption.



Image: The LIUP LP1 charging case glowing in the dark, demonstrating its luminous feature.

OPERATING INSTRUCTIONS

1. Power On/Off

- **Power On:** Open the charging case lid, or take the earbuds out of the case. They will power on automatically.
- **Power Off:** Place the earbuds back into the charging case and close the lid. They will power off automatically.

2. Touch Controls

The LIUP LP1 earbuds feature touch-sensitive controls on the side of each earbud stem. Refer to the diagram below for specific functions:

TOUCH CONTROL

Music incoming calls can be controlled at any time



Answer/Play

Single Tap



Next Track

Double press right ear



Hang up/Reject

Long Press



Previous Track

Double press left ear



Game Mode

Long press right ear for 2s



Volume Up

Triple press right ear



Voice Assistant

Long press left ear for 2s



Volume Down

Triple press left ear

Image: Detailed diagram of the touch control functions for the LIUP LP1 earbuds.

- **Answer/Play:** Single tap (either earbud)
- **Hang up/Reject Call:** Long press (either earbud)
- **Next Track:** Double press right earbud

- **Previous Track:** Double press left earbud
- **Volume Up:** Triple press right earbud
- **Volume Down:** Triple press left earbud
- **Game Mode:** Long press right earbud for 2 seconds
- **Voice Assistant:** Long press left earbud for 2 seconds

3. Mono and Twin Stereo Mode

- **Twin Stereo Mode:** Use both earbuds for a full stereo audio experience.
- **Mono Mode:** Either earbud can be used independently. Simply take one earbud out of the case, and it will connect to your device. The other earbud can remain in the case or be used by another person.

4. Gaming Mode

Activate Gaming Mode for reduced audio latency, enhancing your gaming experience.

- To activate: Long press the right earbud for 2 seconds.
- To deactivate: Repeat the long press on the right earbud for 2 seconds.



Image: The LIUP LP1 earbuds in a gaming setup, highlighting the low-latency gaming mode.

MAINTENANCE

1. Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Ensure charging contacts on both earbuds and case are clean and free of debris to maintain proper charging.

2. Charging

- Charge the earbuds and case using the provided USB cable and a standard 5V USB power adapter.
- Avoid using damaged cables or chargers.
- A 10-minute quick charge provides approximately 2 hours of playtime when the case is low on power.

ALL DAY LISTENING

Immerse yourself in the music world all day long
and the charging case extends playtime up to 35 hours.



6 hrs
Single Charge



35 hrs
Charging Case



< 2 hrs
Fast Charging

3. Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

4. Water Resistance

The earbuds are water resistant. This means they can withstand splashes, sweat, and light rain. They are not designed for submersion in water or for use during swimming or showering.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not pairing	Earbuds not in pairing mode; Bluetooth off on device; already connected to another device.	Ensure earbuds are in case with lid open. Turn Bluetooth off/on on your device. Forget "LIUP LP1" from previously paired devices and re-pair.
No sound or low volume	Volume too low on device/earbuds; earbuds not properly seated; connection issue.	Adjust volume on both device and earbuds. Ensure earbuds are correctly placed in ears. Reconnect Bluetooth.
Earbuds not charging	Charging contacts dirty; cable/charger faulty; earbuds not properly seated in case.	Clean charging contacts. Try a different USB cable/charger. Ensure earbuds are firmly placed in the case.
Luminous effect is weak or absent	Insufficient light absorption.	Expose the earbuds and case to a strong light source (sunlight or UV flashlight) for at least 3 minutes.

SPECIFICATIONS

- **Model:** LP1
- **Bluetooth Version:** 5.4
- **Speaker Size:** 13.4mm
- **Frequency Range:** 20 Hz - 20,000 Hz
- **Earbud Battery Life:** Up to 6 hours (single charge)
- **Total Playtime (with Charging Case):** Up to 35 hours
- **Charging Time:** Approximately 2 hours (for case and earbuds)
- **Connectivity:** Wireless (Bluetooth)
- **Control Type:** Touch
- **Microphone:** Built-in with ENC Noise Cancellation
- **Water Resistance Level:** Water Resistant
- **Weight:** 6.4 ounces (total package)
- **Compatible Devices:** Smartphones, Tablets, Laptops, Desktops, Gaming Consoles

HIFI SOUND QUALITY AND DEEP BASS

13.4mm

Powerful speaker drive for
clear highs and quality bass



Bass+

High-Bass Balance

Image: Internal view of the 13.4mm speaker driver, responsible for the HiFi sound quality.

WARRANTY AND SUPPORT

LIUP products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included in your product packaging or contact the retailer from whom you

purchased the product.

For technical support or further assistance, please contact your retailer or visit the official LIUP support channels as indicated on the product packaging or the brand's official website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question